

Experion PKS
Series C Fieldbus Interface Module User's Guide

EPDOC-X125-en-432B
March 2018

Release 432

<https://maxautoland.com/>
+86 18030205725
manski@cambid.com.cn

Document	Release	Issue	Date
EPDOC-X125-en-432B	432	0	March 2018

Disclaimer

This document contains Honeywell proprietary information. Information contained herein is to be used solely for the purpose submitted, and no part of this document or its contents shall be reproduced, published, or disclosed to a third party without the express permission of Honeywell International Sàrl.

While this information is presented in good faith and believed to be accurate, Honeywell disclaims the implied warranties of merchantability and fitness for a purpose and makes no express warranties except as may be stated in its written agreement with and for its customer.

In no event is Honeywell liable to anyone for any direct, special, or consequential damages. The information and specifications in this document are subject to change without notice.

Copyright 2018 - Honeywell International Sàrl

<https://maxautoland.com/>
manski@cambodia.cn +86 18030205725

Contents

1 About this guide	11
2 Series C FIM4/FIM8 Purpose	13
2.1 Series C FIM4 versus FIM2	14
2.2 Series C FIM4/FIM8 functional overview	15
3 Getting Started	17
3.1 What Task Do You Want to Complete	18
4 Series C FIM4/FIM8 planning and design	19
4.1 General planning references	20
4.1.1 Planning for system security	20
4.2 Fieldbus network wiring and installation references	21
4.3 Identifying Series C FIM4/FIM8 components	22
4.4 Identifying Series C Mark II FIM4 components	24
4.5 Differences between FIM4 and FIM8	26
4.6 Selecting and calculating Fieldbus wiring requirements	27
4.7 Reviewing intrinsically safe application considerations	28
4.8 Reviewing Series C FIM4/FIM8 performance data	29
4.8.1 Subscription and Publication Rates	30
5 Series C FIM4/FIM8 installation and upgrades	31
5.1 Installation declarations	32
5.2 Installing Input/Output termination assembly CC- or CU-TFB401, CC- or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412, or CC- or CU-TFB811	33
5.3 Installing Input/Output termination assembly DC-TFB402 or DC-TFB412	45
5.4 Setting unique device index for Series C FIM4	52
5.5 Installing Series C FIM4 CC- or CU-PFB401	53
5.6 Installing redundant power conditioner IOTA F660A or F860	54
5.7 Upgrading Series C FIM4/FIM8 firmware	56
5.8 Converting non-redundant Series C FIM4 to redundant Series C FIM4/FIM8	57
5.9 Converting redundant Series C FIM4/FIM8 to non-redundant Series C FIM4/FIM8	59
6 Series C FIM4/FIM8 configuration	61
6.1 Non-Experion interface precautions	62
6.2 Free VCR recommendation	63
6.3 Adding FIM4/FIM8 block to project	64
6.4 Checking FFLink configuration	66
6.5 FFLink configuration parameters reference	68
6.6 Creating a Fieldbus device type from vendor DD	73
6.7 Editing device block parameters	77
6.8 Adding a fieldbus device to project	78
6.9 Assigning a device to a FFLink in Project	79
6.10 Checking device configuration	80
6.11 Making fieldbus block template and assigning function block to device	82
6.12 Configuring advanced alarming	83
6.12.1 Opening the configuration dialog box	83
6.12.2 Configuring/creating a condition	84
6.12.3 Managing the conditions	86

6.12.4	Enabling or disabling a condition	86
6.12.5	Assigning criticalities and priorities	88
6.12.6	Editing an existing condition	88
6.13	Block Offnet diagnostic alarm	90
6.13.1	Behavior of the Block Offnet and Device Offnet System alarms in various communication loss scenarios	90
6.13.2	Behavior of the Block Offnet and Device Offnet System alarms in various operational scenarios	90
7	Series C FIM4/FIM8 configuration form reference	93
7.1	FIM4/FIM8 device Diagnostics tab parameters	94
7.2	FIM4/FIM8 Main tab parameters	95
7.3	FIM4/FIM8 Redundancy tab parameters	97
7.4	FIM4/FIM8 System Time tab parameters	98
7.5	FIM4/FIM8 Statistics tab parameters	99
7.6	FIM4/FIM8 Peer Connections tab parameters	100
7.7	FIM4/FIM8 Hardware Information tab parameters	101
7.8	FIM4/FIM8 FTE tab parameters	102
7.9	FIM4/FIM8 UDP/TCP tab parameters	104
7.10	FIM4/FIM8 IP/ICMP tab parameters	106
7.11	FIM4/FIM8 QVCS tab parameters	108
7.12	FIM4/FIM8 Server History tab parameters	109
7.13	FIM4/FIM8 Server Displays tab parameters	110
7.14	FIM4/FIM8 Control Confirmation tab parameters	112
7.15	FIM4/FIM8 Identification tab parameters	113
8	Block instantiation support	115
8.1	Control Builder supports block instantiation	116
8.2	Instantiable block implementation considerations	117
8.2.1	Adding instantiable block to device in Project tab	117
8.2.2	Checking instantiated block configuration in Project tab	118
8.2.3	Making optional instantiated block resource usage check	119
8.2.4	Adding instantiated block to CM	120
8.2.5	Loading Project device to physical device	121
8.2.6	Deleting (de-instantiate) instantiated block from Project tab	121
8.2.7	Deleting (de-instantiate) instantiated block from physical device	122
8.2.8	Replacing failed device that includes instantiable blocks with like device	122
9	Loading FIM4/FIM8 components online	125
9.1	About load operations	126
9.2	About load dialog	127
9.3	Load order guidelines	128
9.4	General load considerations	130
9.5	About fieldbus device states	131
9.6	Fieldbus device matching rules	132
9.7	Identifying load interactions for fieldbus-related operations	133
9.8	Loading a Series C FIM4/FIM8 and its links	134
9.9	Matching uncommissioned device to Project device or vice versa	135
9.10	Using optional safe handling of new devices	137
9.10.1	About safe handling option	137
9.10.2	Enabling and disabling safe handling	137
9.10.3	Safe handling and previously commissioned devices	137
9.10.4	Removing power during a safe handling operation	137
9.11	Loading FFLink contents or fieldbus device	138
10	Fieldbus device commissioning	139
10.1	Getting started	140

10.1.1	Read this first	140
10.1.2	Initial checks and operations	141
10.2	Connecting devices	143
10.3	Checking device	145
10.4	Checking control strategy	146
10.5	Flowchart summary	147
11	Series C FIM4/FIM8 redundancy functionality	149
11.1	Redundant Series C FIM4/FIM8 overview	150
11.2	Switchover and secondary readiness	151
11.3	Switchover behavior considerations	152
11.4	Failure conditions and switchover	153
11.5	Fieldbus network switchover considerations	154
11.6	Switchover versus fieldbus network activities	155
11.7	Switchover events	156
12	Series C FIM4/FIM8 operation	157
12.1	Series C FIM4/FIM8 startup	159
12.2	Initiating Series C FIM4/FIM8 shutdown	160
12.3	Series C FIM4/FIM8 IOTA display and LED descriptions	161
12.4	Control Builder Block icon descriptions	164
12.4.1	FIM4/FIM8 block icons	164
12.4.2	FIM4/FIM8 link icons	165
12.4.3	Fieldbus Device icons	165
12.4.4	Fieldbus block icons	166
12.5	Activating or inactivating FIM4/FIM8 link	167
12.6	Initiating Series C FIM4/FIM8 link segment commands	168
12.6.1	Initiating a PurgeNVS SEG command	168
12.6.2	Initiating a CompactNVS SEG Command	169
12.6.3	Automated NVS compaction	169
12.7	Activating or inactivating fieldbus block	170
12.8	Checking/changing fieldbus device functional class	171
12.9	Checking live list and commissioning an uncommissioned device	173
12.10	Viewing and optimizing link schedule configuration	174
12.10.1	Calling up Link Schedule	174
12.10.2	Additional Link Schedule terms reference	176
12.10.3	Configuring link schedule optimization	177
12.11	Initiating synchronization command	178
12.12	Initiating switchover command	179
12.13	Using fieldbus methods manager	180
12.14	Using controller menu functions	184
12.15	Using station detail displays	185
12.16	Foundation fieldbus detail displays/faceplates	186
12.16.1	Naming conventions for Detail Displays	186
12.16.2	Detail Displays contents based on FF control points loading	186
12.16.3	Tabs of FF Detail Displays	186
12.16.4	Detail Displays tabs of the different Foundation Fieldbus blocks	187
12.16.5	Common functionalities of faceplates	189
12.16.6	FF Detail Displays example templates for Control Builder	190
12.17	Using Station event summary display	191
13	Experion PKS Host Registration with Foundation Fieldbus	193
13.1	New features	194
13.2	Conditional support for FF devices	196
13.3	About EDDL	197
13.4	About DD View tab	198

13.5	Multi-capability support for FF devices	202
13.6	About Field Diagnostic support	203
13.7	Parameter definitions	207
13.8	Persistent data handling	208
14	Series C FIM4/FIM8 maintenance	209
14.1	Periodic checks	211
14.2	Recommended spare parts	212
14.3	Series C FIM4/FIM8 removal and installation under power	213
14.4	Replacing device template with a different one	214
14.5	Correcting some common UTR errors	220
14.6	Replacing failed Series C FIM4 CC- or CU-PFB401	221
14.7	Replacing IOTA DC-TFB402 or DC-TFB412, CC-or CU-TFB401, CC-or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412	222
14.8	Relocating Series C FIM4/FIM8 or reassigning IP address	224
14.9	Upgrading firmware in uncommissioned device	225
14.10	Replacing a failed device with a like device having the same model name and device revision	226
14.11	Replacing a failed device with a different device using a different block type	227
14.12	Unlike device replacement report	229
14.13	Changing or clearing tag and/or address of uncommissioned device	231
14.14	Preparing Fieldbus device for a move or software migration	232
14.14.1	Migrating Fieldbus device type to a release supporting Enable Block Offnet Diagnostic Alarm	232
14.15	Using fieldbus device simulate function	234
14.16	Checking fieldbus device calibration	236
15	Series C FIM4/FIM8 troubleshooting	239
15.1	Isolating problems	240
15.2	Fault classifications	241
15.3	Initial checks	242
15.3.1	Checking Control Builder error code reference	242
15.3.2	Checking front panel display and LEDs	242
15.3.3	Viewing flash log	242
15.3.4	Viewing release information log	242
15.3.5	Viewing trace log	243
15.3.6	Checking version and revision log	243
15.3.7	Checking server point build log	243
15.3.8	Checking server point build error log	243
15.3.9	Checking error log	243
15.3.10	Viewing link schedule log	243
15.3.11	Checking Fieldbus library manager log	244
15.3.12	Using CTool to capture diagnostic data	244
15.4	Series C FIM4/FIM8 self-test diagnostic codes	245
15.5	FIM link communication error	251
15.6	Fixing common problems	252
15.6.1	Loss of power	252
15.6.2	Poweron Self-Test Fault	252
15.6.3	Fatal ECC error	253
15.6.4	Background Diagnostic failure	253
15.6.5	No IP address	253
15.6.6	No time reference	254
15.6.7	Isolated (lonely) Node	254
15.6.8	Device Index setting does not match displayed value	255
15.6.9	Duplicate Device Index setting	255
15.6.10	Device Index value is zero upon power up	256

15.6.11 Device reload or replacement fails	256
15.6.12 Generation of excessive alarms	256
15.6.13 Alarms not occurring when expected	257
15.6.14 Connected Fieldbus device is not detected by the FF link	257
15.7 Getting further assistance	258
15.7.1 Other troubleshooting sources	258
15.7.2 Guidelines for requesting support	259
16 Fieldbus integration with Experion control reference	261
16.1 Series C FIM4/FIM8 handles data integration	263
16.2 About link object	264
16.3 Network management description	265
16.4 System management description	266
16.5 About device objects	267
16.6 About VFD objects	268
16.7 Type creation makes integration possible	269
16.8 Fieldbus device analog input integration	270
16.9 Fieldbus analog input data manipulation	271
16.10 Fieldbus device analog output or PID integration	272
16.11 Fieldbus analog output or PID data manipulation	274
16.12 Fieldbus device discrete input integration	275
16.13 Fieldbus discrete input data manipulation	276
16.14 Fieldbus device discrete output data integration	277
16.15 Fieldbus discrete output data manipulation	278
16.16 Interface connections summary	279
16.17 About SCM parameter interaction	280
16.18 Fieldbus status data details	281
16.19 Fieldbus status indications	282
16.19.1 Sub status Definitions for Quality Status	286
17 Control mode interaction reference	289
17.1 Fieldbus block modes versus control modes	290
17.2 Control mode priorities and indications	292
17.3 Rotary Switch Model versus Toggle Switch Model	293
17.4 Display indications and mode calculation	294
17.5 Mode change conditions	295
17.6 Access control through GRANT_DENY parameter	297
18 Fieldbus Link Active scheduler and Link Master functions	299
18.1 Link Schedule	301
18.2 Function block execution schedule	302
18.3 About using mixed macrocycles on FF Links	304
18.3.1 About macrocycles	304
18.3.2 About mixed macrocycles	304
18.3.3 Scenarios during which mode shed occurs when using mixed macrocycles	304
19 Tags, Addresses, and Live List Reference	307
19.1 Tag and address assignments	308
19.2 About Fieldbus address assignments in Control Builder	309
19.3 Live list and uncommissioned devices	310
20 Notification Scheme Reference	311
20.1 Fieldbus versus Experion Alarm Priorities	312
20.1.1 Advanced Alarming	312
20.2 Fieldbus Alarm Conditions	314
20.2.1 Loading alarm conditions	316
20.2.2 Alarm server operation	316

21 Fieldbus Technology Overview	317
21.1 Open communications architecture	318
21.2 Communication layer description	319
21.3 Standard Function Blocks	321
21.3.1 Blocks for basic control functionality	321
21.3.2 About modes of operation	322
21.3.3 Analog Input block	323
21.3.4 Analog Output block	325
21.3.5 Bias/Gain block	326
21.3.6 Control Selector block	328
21.3.7 Discrete Input block	330
21.3.8 Discrete Output block	331
21.3.9 Manual Loader block	333
21.3.10 Proportional/Derivative block	335
21.3.11 Proportional/Integral/Derivative block	338
21.3.12 Ratio block	341
21.4 Device Descriptions and Block Parameters	344
21.4.1 About Device Descriptions	344
21.4.2 Device Description Language	344
21.4.3 Device Description infrastructure	344
22 Standard Function Block Parameters Reference	347
22.1 ACK_OPTION	351
22.2 ALARM_HYS	352
22.3 ALARM_SUM	353
22.4 ALERT_KEY	354
22.5 BAL_TIME	355
22.6 BIAS	356
22.7 BKCAL_HYS	357
22.8 BKCAL_IN	358
22.9 BKCAL_OUT	359
22.10 BKCAL_OUT_D	360
22.11 BKCAL_SEL_1	361
22.12 BKCAL_SEL_2	362
22.13 BKCAL_SEL_3	363
22.14 BLOCK_ALM	364
22.15 BLOCK_ERR	365
22.16 BLOCK_ERR_DISABLED	366
22.17 BYPASS	367
22.18 CAS_IN	368
22.19 CAS_IN_D	369
22.20 CHANNEL	370
22.21 CLR_FSTATE	371
22.22 CONFIRM_TIME	372
22.23 CONTROL_OPTS	373
22.24 CYCLE_SEL	374
22.25 CYCLE_TYPE	375
22.26 DEV_REV	376
22.27 DEV_TYPE	377
22.28 DD_RESOURCE	378
22.29 DD_REV	379
22.30 DISC_ALM	380
22.31 DISC_LIM	381
22.32 DISC_PRI	382
22.33 DV_HI_ALM	383

22.34	DV_HI_LIM	384
22.35	DV_HI_PRI	385
22.36	DV_LO_ALM	386
22.37	DV_LO_LIM	387
22.38	DV_LO_PRI	388
22.39	FAULT_STATE	389
22.40	FEATURES	390
22.41	FEATURE_SEL	391
22.42	FF_GAIN	392
22.43	FF_SCALE	393
22.44	FF_VAL	394
22.45	FIELD_VAL	395
22.46	FIELD_VAL_D	396
22.47	FREE_SPACE	397
22.48	FREE_TIME	398
22.49	FSTATE_TIME	399
22.50	FSTATE_VAL	400
22.51	FSTATE_VAL_D	401
22.52	GAIN	402
22.53	GRANT_DENY	403
22.54	HARD_TYPES	404
22.55	HI_ALM	405
22.56	HI_HI_ALM	406
22.57	HI_HI_LIM	407
22.58	HI_HI_PRI	408
22.59	HI_LIM	409
22.60	HI_PRI	410
22.61	IO_OPTS	411
22.62	IN	412
22.63	IN_1	413
22.64	LIM_Notify	414
22.65	L_TYPE	415
22.66	LO_ALM	416
22.67	LO_LIM	417
22.68	LO_LO_ALM	418
22.69	LO_LO_LIM	419
22.70	LO_LO_PRI	420
22.71	LO_PRI	421
22.72	LOW_CUT	422
22.73	MANUFAC_ID	423
22.74	MAX_NOTIFY	424
22.75	MEMORY_SIZE	425
22.76	MIN_CYCLE_T	426
22.77	MODE_BLK	427
22.78	NV_CYCLE_T	428
22.79	OFFNETALM_ENABLED	429
22.80	OUT	430
22.81	OUT_D	431
22.82	OUT_HI_LIM	432
22.83	OUT_LO_LIM	433
22.84	OUT_SCALE	434
22.85	OUT_STATE	435
22.86	PV	436
22.87	PV_D	437

22.88 PV_FTIME	438
22.89 PV_SCALE	439
22.90 PV_STATE	440
22.91 RA_FTIME	441
22.92 RATE	442
22.93 RCAS_IN	443
22.94 RCAS_IN_D	444
22.95 RCAS_OUT	445
22.96 RCAS_OUT_D	446
22.97 READBACK	447
22.98 READBACK_D	448
22.99 RESET	449
22.100 RESTART	450
22.101 ROUT_IN	451
22.102 ROUT_OUT	452
22.103 RS_STATE	453
22.104 SEL_1	454
22.105 SEL_2	455
22.106 SEL_3	456
22.107 SEL_TYPE	457
22.108 SET_FSTATE	458
22.109 SHED_OPT	459
22.110 SHED_RCAS	460
22.111 SHED_ROUT	461
22.112 SIMULATE	462
22.113 SIMULATE_D	463
22.114 SP	464
22.115 SP_D	465
22.116 SP_HI_LIM	466
22.117 SP_LO_LIM	467
22.118 SP_RATE_DN	468
22.119 SP_RATE-UP	469
22.120 ST_REV	470
22.121 STATUS_OPTS	471
22.122 STRATEGY	472
22.123 TAG_DESC	473
22.124 TEST_RW	474
22.125 TRK_IN_D	475
22.126 TRK_SCALE	476
22.127 TRK_VAL	477
22.128 UPDATE_EVT	478
22.129 WRITE_ALM	479
22.130 WRITE_LOCK	480
22.131 WRITE_PRI	481
22.132 XD_SCALE	482
22.133 XD_STATE	483
23 Glossary of Fieldbus Terms	485
24 Notices	489

1 About this guide

This document provides information for planning, installing, configuring, operating, maintaining and troubleshooting hardware components and software function blocks associated with the Series C Fieldbus Interface Modules (FIM4/FIM8). It also includes some basic FOUNDATION Fieldbus technology data for reference.

Revision history

Revision	Date	Description
A	July 2016	B
B	March 2018	Updated PAR # 1-8BWZCWL information in the document.

Intended audience

Personnel who are responsible for integrating Fieldbus devices with the Experion system.

Prerequisite skills

- Familiar with working in a Windows operating environment.
- Familiar with using these Experion applications
- Configuration Studio
- Control Builder
- Series C Platform Analyzer
- Familiar with FOUNDATION Fieldbus technology.

How to use this guide

Choose a topic associated with the task you want to complete on the tree view in the PDF collection or click one of the topic references listed in the What Task Do You Want to Complete section. This guide covers tasks for planning your installation through troubleshooting considerations.

Related documents

For more information about using Control Builder, see *Control Building User's Guide*.

<https://maxautoland.com/>
manski@cambodia.cn +86 18030205725

2 Series C FIM4/FIM8 Purpose

The Series C Fieldbus Interface Module (FIM4/FIM8) serves as the bridge between the Experion control environment and the Fieldbus control functions. It supports both the publish/subscribe and the client/server communication methods to communicate with Fieldbus function blocks. The Fieldbus function blocks implementing control algorithms, such as a PID function block, must be connected downstream from CEE function blocks. For example, a control strategy may use a CEE PID as an upstream PID and a Fieldbus PID as a downstream PID.

! Attention

- With R400, FIM8 is introduced.
 - FIM8 supports up to eight H1 links.
 - The FIM8 IOTA is only available in a redundant form factor. Therefore, a single FIM8 module combined with the redundant FIM8 IOTA can be used for non-redundant operations. A pair of FIM8 modules combined with the redundant FIM8 IOTA can be used for redundant operations.
 - FIM4 and FIM8 have distinct IOTA. A FIM8 module cannot be mounted on a FIM4 IOTA and a FIM4 module cannot be mounted on a FIM8 IOTA.
 - With R431.3, for Series C Mark II, only FIM4 IOTA is available.
 - Series C Mark II does not support Intrinsically Safe (IS) application.
-

Related topics

“Series C FIM4 versus FIM2” on page 14

“Series C FIM4/FIM8 functional overview” on page 15

*https://maxoutland.com/16039205725
manski@cambria.cn*

2.1 Series C FIM4 versus FIM2

The Series C Fieldbus Interface Modules (FIM4/FIM8) is designed to complement the C300 Controller and support Fault Tolerant Ethernet (FTE) communications within Experion R300 (for FIM4)/Experion R400 (for FIM8). While the Series C FIM is functionally equivalent to the Chassis I/O-Series A (FIM2) FIM, its physical design, including mounting and wiring requirements, is drastically different as shown in the following figure. The Series C FIM4/FIM8 support up to four and eight H1 links respectively while the FIM2 only supports upto two. Please refer to the *Series A Fieldbus Interface Module User's Guide* for information that is specific to integrating Fieldbus through a FIM2.

Table 1: Series C FIM4 Mounted on non-redundant Input/Output Termination Assembly (IOTA).



2.2 Series C FIM4/FIM8 functional overview

Like the FIM2, the Series C FIM4/FIM8 features a multi-level function block model based upon the hardware hierarchy and the physical Fieldbus network. The Experion Control Builder application supports integral creation and configuration of Fieldbus function blocks with Experion system function blocks to incorporate Fieldbus devices in a unified Experion Control Strategy. This means Experion function blocks and Fieldbus function blocks can be easily interconnected, so control can reside on the Fieldbus link, in the Control Processor/Control Execution Environment (CEE), or cascaded from CEE to the Fieldbus device. The following figure shows how icons are used to identify Series C FIM, H1 Links, and Fieldbus devices in the Control Builder **Project** tab.

Table 2: Typical Series C FIM4 Hardware/Function Block Hierarchy in Project Tab





Table 3: Typical Series C FIM8 Hardware/Function Block Hierarchy in Project Tab



The Series C FIM4/FIM8 platform block represents the physical module and IOTA. This block is the parent of Link blocks, which represents an H1 link by FIM4/FIM8. Link blocks are instantiated automatically with the creation of FIM4/FIM8. Hence, FIM4 instantiates 4 Link blocks and FIM8 instantiates 8 Link blocks.

3 Getting Started

This section provides a quick reference to topics in this book for a given task related to using the Series C FIM4/FIM8 to integrate Fieldbus devices with the Experion system.

Related topics

“What Task Do You Want to Complete” on page 18

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

3.1 What Task Do You Want to Complete

The following table lists some of the tasks covered in this document that are related to implementing a Series C FIM4 (for Experion R300)/FIM8 (for Experion R400). If you are viewing this document online, just click the reference to jump to the topic in this document.

If you want to . . .	Then, see this topic . . .
Plan and Design a Series C FIM4/FIM8 installation.	“Series C FIM4/FIM8 planning and design” on page 19
Install Series C FIM4/FIM8 hardware.	“Series C FIM4/FIM8 installation and upgrades” on page 31
Wire Series C FIM4/FIM8 hardware.	“Series C FIM4/FIM8 installation and upgrades” on page 31
Add FIM4/FIM8 block with Links to Project .	“Adding FIM4/FIM8 block to project” on page 64
Check FFLink configuration.	“Checking FFLink configuration” on page 66
Make a Fieldbus device Type from vendor DD.	“Creating a fieldbus device type from vendor DD”
Edit device block parameters.	“Editing device block parameters” on page 77
Add a Fieldbus device to Project.	“Adding a fieldbus device to project” on page 78
Assign a device to an FFLink in Project.	“Assigning a device to a FFLink in Project” on page 79
Check a device's configuration.	“Checking FFLink configuration” on page 66
Make Fieldbus block template and assign the block to a device.	“Making fieldbus block template and assigning function block to device” on page 82
Use an instantiable block.	“Control Builder supports block instantiation” on page 116
Load blocks to FIM4/FIM8 components.	“Loading FIM4/FIM8 components online” on page 125
Review a typical scenario for commissioning a Fieldbus device.	“Fieldbus device commissioning” on page 139
Use a redundant Series C FIM4/FIM8 pair.	“Series C FIM4/FIM8 redundancy functionality” on page 149
Power up a Series C FIM4/FIM8.	“Series C FIM4/FIM8 startup” on page 159
Change the functional class of a Fieldbus device.	“Checking/changing fieldbus device functional class” on page 171
Check the current link schedule.	“Other troubleshooting sources” on page 258
Use Fieldbus Methods Manager to interact with vendor supplied Methods for given device.	“Using fieldbus methods manager” on page 180
Review maintenance related requirements.	“Series C FIM4/FIM8 maintenance” on page 209
Investigate the cause of a problem.	“Series C FIM4/FIM8 troubleshooting” on page 239
Know more about how Fieldbus is integrated with Experion control.	“Fieldbus integration with Experion control reference” on page 261
Know more about FOUNDATION Fieldbus technology.	“Fieldbus Technology Overview” on page 317
Check definitions for Fieldbus standard function block parameters.	“Standard Function Block Parameters Reference” on page 347

4 Series C FIM4/FIM8 planning and design

This section includes the following topics on information and tasks associated with planning and designing an Experion System to include Series C FIM4s/FIM8 and Fieldbus devices.

Related topics

“General planning references” on page 20

“Fieldbus network wiring and installation references” on page 21

“Identifying Series C FIM4/FIM8 components” on page 22

“Identifying Series C Mark II FIM4 components” on page 24

“Differences between FIM4 and FIM8” on page 26

“Selecting and calculating Fieldbus wiring requirements” on page 27

“Reviewing intrinsically safe application considerations” on page 28

“Reviewing Series C FIM4/FIM8 performance data” on page 29

<https://maxautol.com/>
manski@cambiala.cn +86 18030205725

4.1 General planning references

Please refer to the following PDF Collection publications for planning and design details for the Experion system in general and the Fault Tolerant Ethernet supervisory network. For the sake of brevity, this Guide does not repeat the applicable general guidelines, considerations, cautions, and so on that are covered in these other Guides.

- Control Hardware Planning Guide
- Server and Client Planning Guide
- Fault Tolerant Ethernet Overview and Implementation Guide

4.1.1 Planning for system security

System security must be achieved at all levels in the Experion system to manage security threats.

For details on security related planning, refer to the *Network and Security Planning Guide*.

For controller hardware specific security planning, refer to the chapter *Securing controller hardware* of the *Network and Security Planning Guide*.

<https://maxautoland.com/>
+86 18030205725
manski@cambid.com.cn

4.2 Fieldbus network wiring and installation references

Please refer to the following publications for guidance in designing and implementing the Fieldbus network to be interfaced to the Experion system through the Series C FIM H1 links.

Publication Number/Title	Scope	Source
AG-140 / Wiring and Installation 31.25 kbit/s, Voltage Mode, Wire Medium Application Guide	Overview of what you need to know to wire, power, and layout network components	Fieldbus Foundation 9005 Mountain Ridge Drive Bowie Building - Suite 190 Austin, Texas 78759-5316 USA http://www.fieldbus.org/
AG-163 / 31.25 kbit/s Intrinsically Safe Systems Application Guide	Complements the previous document, introduces you to the principles of intrinsic safety, and outlines how to apply approved devices in a hazardous area.	Fieldbus Foundation 9005 Mountain Ridge Drive Bowie Building - Suite 190 Austin, Texas 78759-5316 USA http://www.fieldbus.org/
AG-180 / Engineering Guide and Intrinsically Safe Systems Combo	A general comprehensive reference	Fieldbus Foundation 9005 Mountain Ridge Drive Bowie Building - Suite 190 Austin, Texas 78759-5316 USA http://www.fieldbus.org/

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

4.3 Identifying Series C FIM4/FIM8 components

The following table identifies the Series C FIM4/FIM8 components that will be required to provide a non-redundant or redundant Fieldbus interface with an Experion R300 (for FIM4)/Experion R400 (for FIM8) or later system. The CC prefix in a model number means the component's printed wiring boards are coated to provide additional protection from the environment and the CU prefix means the boards are uncoated. For FIM8 the IOTA and the module are manufactured only as CC.

Component	Description	Honeywell Model Number
Series C Fieldbus Interface Module (FIM4)	Module mounts on non-redundant or redundant Input/Output Termination Assembly. Serves as a ' between the Experion system and H1 Fieldbus links.	CC-PFB401
		CU-PFB401
Series C Fieldbus Interface Module (FIM8)	Module mounts on redundant Input/Output Termination Assembly. Serves as a ' between the Experion system and H1 Fieldbus links.	CC-PFB801
Non-Redundant Input/Output Termination Assembly (IOTA) (FIM4)	Provides physical connection to Series C FIM, H1 Links, and FTE cables. Mounts on carrier in Series C cabinet.	CC-TFB401
		CU-TFB401
Non-Redundant Input/Output Termination Assembly (IOTA) (FIM4)	Same as row above - This model supersedes model CC/CC-TFB401.	CC-TFB402
		CU-TFB402
Redundant Input/Output Termination Assembly (IOTA) (FIM4)	Provides physical connection to Primary and Secondary Series C FIMs, H1 Links, and FTE cables. Mounts on carrier in Series C cabinet.	CC-TFB411
		CU-TFB411
Redundant Input/Output Termination Assembly (IOTA) (FIM4)	Same as row above - This model supersedes model CC/CU-TFB411.	CC-TFB412
		CU-TFB412
Non-Redundant Input/Output Termination Assembly (IOTA) (FIM4)	Provides physical connection to Series C FIM, H1 Links, and FTE cables. Mounts on the backplane in Series C Mark II cabinet.	DC-TFB403
Redundant Input/Output Termination Assembly (IOTA) (FIM4)	Provides physical connection to Primary and Secondary Series C FIMs, H1 Links, and FTE cables. Mounts on the backplane in Series C Mark II cabinet.	DC-TFB413
Redundant Input/Output Termination Assembly (IOTA) (FIM8)	Provides physical connection to Primary and Secondary Series C FIMs, H1 Links, and FTE cables. Mounts on the backplane in Series C Mark II cabinet.	DC-TFB813
Redundant Input/Output Termination Assembly (IOTA) (FIM8)	Provides physical connection to Primary and Secondary Series C FIMs, H1 Links, and FTE cables. Mounts on carrier in Series C cabinet.	CC-TFB811
Redundant Power Conditioner IOTA (Optional)	Provides physical connection to Series C FIM IOTA to provide the necessary field power to bus-powered devices on a given link. The models listed below are available from the vendor MTL-Relcom. (The Series C FIM4/FIM8 does not provide power for the H1 network.)	
	Redundant Fieldbus power IOTA	F660A
	8-segment redundant Fieldbus power IOTA	F860
Non-Redundant Power Conditioner IOTA (Optional)	Same as above but in a non-redundant version. The model listed below is available from the vendor MTL-Relcom.	
	Non-Redundant Fieldbus power IOTA	F660A-NR

Component	Description	Honeywell Model Number
Power Conditioner Cable	Provides pre-fabricated cable with 16-pin connectors for power conditioner to Series C FIM IOTA connections. The cables listed below are available from the vendor MTL-Relcom.	
	30 cm (1 ft)	FCAB-05
	1 m (3 ft)	FCAB-06
	2 m (6.5 ft)	FCAB-07
	4 m (13 ft)	FCAB-08
Control Firewall (9 ports)	Provides efficient distribution of FTE cables to multiple Series C FIMs.	CC-PCF901 CU-PCF901
Control Firewall IOTA	Provides physical connection for one uplink and up to eight separate FTE distribution cables Mounts on carrier in Series C cabinet.	CC-TCF901 CU-TCF901
FTE Cable	Provides pre-fabricated STP CAT5 Cable with RJ 45 connectors for FTE connections.	
	2 m (6.5 ft) (Y) = Yellow coded (G) = Green coded	51305482-102 (Y) 513054820202 (G)
	5 m (16 ft)	51305482-105 (Y) 513054820205 (G)
	10 m (33 ft)	51305482-110 (Y) 513054820210 (G)
	20 m (65.5 ft)	51305482-120 (Y) 51305482-220 (G)
	Fieldbus Device Usage Licenses	Total number of FIMs per Server actually in use. (Purchase License model numbers in combinations that support the total number of FIMs required. Licenses must be purchased starting with the first FIM used.)
	1	TC-FFLX01
	5	TC-FFLX05
	10	TC-FFLX10
	50	TC-FFLX50

4.4 Identifying Series C Mark II FIM4 components

The following table identifies the Series C Mark II FIM4 components that will be required to provide a non-redundant or redundant Fieldbus interface with an Experion R431.3 (for FIM4) or later system. The xC prefix in a model number means the component's printed wiring boards are coated to provide additional protection from the environment and the CU prefix means the boards are uncoated.

Component	Description	Honeywell Model Number
Series C Fieldbus Interface Module (FIM4)	Module mounts on non-redundant or redundant Input/Output Termination Assembly. Serves as a 'gateway' between the Experion system and H1 Fieldbus links.	CC-PFB401
Series C Fieldbus Interface Module (FIM8)	Module mounts on non-redundant or redundant Input/Output Termination Assembly. Serves as a 'gateway' between the Experion system and H1 Fieldbus links.	CC-PFB801
Non-Redundant Input/Output Termination Assembly (IOTA) (FIM4)	Provides physical connection to Series C FIM, H1 Links, and FTE cables. Mounts on the backplane in Series C Mark II cabinet.	DC-TFB402
Redundant Input/Output Termination Assembly (IOTA) (FIM4)	Provides physical connection to Primary and Secondary Series C FIMs, H1 Links, and FTE cables. Mounts on the backplane in Series C Mark II cabinet.	DC-TFB412
Non-Redundant Input/Output Termination Assembly (IOTA) (FIM4)	Provides physical connection to Series C FIM, H1 Links, and FTE cables. Mounts on the backplane in Series C Mark II cabinet.	DC-TFB403
Redundant Input/Output Termination Assembly (IOTA) (FIM4)	Provides physical connection to Primary and Secondary Series C FIMs, H1 Links, and FTE cables. Mounts on the backplane in Series C Mark II cabinet.	DC-TFB413
Redundant Input/Output Termination Assembly (IOTA) (FIM8)	Provides physical connection to Primary and Secondary Series C FIMs, H1 Links, and FTE cables. Mounts on the backplane in Series C Mark II cabinet.	DC-TFB813
Control Firewall (9 ports)	Provides efficient distribution of FTE cables to multiple Series C FIMs.*	CC-PCF901
Control Firewall IOTA	Provides physical connection for one uplink and up to eight separate FTE distribution cables. Mounts on carrier in Series C Mark II cabinet.	DC-TCF901
FTE Cable	Provides pre-fabricated STP CAT5 Cable with RJ 45 connectors for FTE connections.	
	2 m (6.5 ft) (Y) = Yellow coded (G) = Green coded	51305482-102 (Y) 513054820202 (G)
	5 m (16 ft)	51305482-105 (Y) 513054820205 (G)
	10 m (33 ft)	51305482-110 (Y) 513054820210 (G)
	20 m (65.5 ft)	51305482-120 (Y) 51305482-220 (G)
Fieldbus Device Usage Licenses	Total number of FIMs per Server actually in use. (Purchase License model numbers in combinations that support the total number of FIMs required. Licenses must be purchased starting with the first FIM used.)	

Component	Description	Honeywell Model Number
	1	TC-FFLX01
	5	TC-FFLX05
	10	TC-FFLX10
	50	TC-FFLX50

<https://maxautoland.com/>
manski@cambodia.ch +86 18030205725

4.5 Differences between FIM4 and FIM8

The following table lists the differences between FIM4 and FIM8:

FIM4	FIM8
The Series C FIM4 provides four interfaces to Fieldbus networks and Fieldbus devices located on each network.	The Series C FIM8 provides eight interfaces to Fieldbus networks and Fieldbus devices located on each network.
The FIM4 IOTA is available in both non-redundant and redundant form factors.	The FIM8 IOTA is available only in a redundant form factor.
The FIM4 has one connector for a Fieldbus Power Conditioner for all four links.	The FIM8 has two Fieldbus Power Conditioners, one for links 1-4 and one for links 5-8.
The FIM4 has four H1 Link Status LEDs.	The FIM8 has eight H1 Link Status LEDs.

<https://maxautol.com/>
 manski@cambiala.cn +86 18030205725

4.6 Selecting and calculating Fieldbus wiring requirements

The preferred cable for connecting Fieldbus devices is #18 AWG (0.8mm²) shielded, twisted pair wire. It is important to calculate how the planned topology for your Fieldbus segment, selected wiring, supplied power and intended mix of Fieldbus devices may affect the overall performance of a Fieldbus network. It is beyond the scope of this document to address all possible Fieldbus wiring scenarios.

You may also want to visit the Relcom Inc. website <http://www.relcominc.com/> for more information on available Fieldbus wiring products and more wiring design and installation data. They also offer a free *Fieldbus Wiring Guide* for downloading.

<https://maxautoland.com/>
manski@cambiala.cn +86 18030205725

4.7 Reviewing intrinsically safe application considerations

The Series C FIM4/FIM8 accepts up to three Intrinsically Safe (IS) mounted field devices on each H1 network it supports.

Ensure you take the reduced current limit of 83 mA into consideration when calculating performance characteristics for the planned IS Fieldbus segment.

You are responsible for adhering to all applicable national codes and local ordinances for applying intrinsically safe equipment in a potentially explosive atmosphere.

<https://maxautoland.com/>
+86 18030205725
manski@cambi.a.cn

4.8 Reviewing Series C FIM4/FIM8 performance data

The following table lists the Series C FIM4/FIM8 performance-related data for quick reference.

<i>Number of Series C FIMs per C300 Controller</i>	<ul style="list-style-type: none"> FIM4: 15 non-redundant or redundant (60 Links) (Regardless of redundancy). FIM8: 8 non-redundant or redundant (64 Links) (Regardless of redundancy).
<i>Number of Series C FIMs per Experion server</i>	125 non-redundant or redundant pairs (In any combination of FIM2, FIM4, and FIM8).
<i>Number of H1 Links per Series C FIM</i>	<ul style="list-style-type: none"> FIM4: Up to 4 <ul style="list-style-type: none"> (Each network defined as a FOUNDATION Fieldbus 31.25 kbps H1 network.) FIM8: Up to 8 <ul style="list-style-type: none"> (Each network defined as a FOUNDATION Fieldbus 31.25 kbps H1 network.)
<i>Number of Devices per H1 Link</i>	<ul style="list-style-type: none"> Up to 16 for non-intrinsically safe applications. Up to 3 for intrinsically safe applications. (See Note 1 below.)
<i>Number of Devices per Experion server</i>	<ul style="list-style-type: none"> FIM4: 8000 maximum FIM8: 12000 maximum
<i>Number of Blocks per Series C FIM</i>	<ul style="list-style-type: none"> FIM4: 1600 maximum (See Note 2 below.) FIM8: 3200 maximum
<i>Maximum Single-Variable Publications per Second on an H1 network</i>	16
<i>Available macrocycle periods</i>	250, 500 milliseconds; 1, 2, 4, 8, 16, and 32 seconds.
<i>Number of Unique Block Types per Series C FIM</i>	200 maximum across all devices connected to all links.
<i>Number of VCRs per H1 Link</i>	128 maximum (See Note 3 below.)
<i>Number of Agents per Link</i>	<ul style="list-style-type: none"> 100 for FIM4/FIM8 50 for FIM2
<i>Number of FB start entries per Link</i>	<ul style="list-style-type: none"> 100 for FIM4/FIM8 50 for FIM2
<i>Number of Blocks per Device</i>	Up to 35
<i>Number of Peer connections per Series C FIM</i>	Up to 5
<i>Link Active Scheduler Capabilities</i>	<p>Series C FIM supports two LAS domains.</p> <p>2000 bytes maximum LAS schedule size.</p> <p>LAS schedule can contain up to four sub-schedules. Each sub-schedule can consist of up to 64 sequences.</p> <p>(See Note 4 below.)</p>

Notes:

1. The maximum number of supportable devices per network is highly dependent on application, bandwidth, devices, available current, bus length, and topology. An understanding of Fieldbus is crucial to system sizing.
2. Blocks are counted whether the Fieldbus device's blocks are being used/loaded or not in the FIM strategy. Resources to support every device's block set must be reserved when the Fieldbus device is configured on one of the FIM4's/FIM8's H1 networks.
3. Each Series C FIM4/FIM8 H1 network uses 2 VCRs, each device uses 2 VCRs, and each published connection to/from a Controller function block uses 1 VCR. Connections between devices do not use Series C FIM4/FIM8 VCRs.
4. A 2-second macrocycle could, for example, have sub schedule periods of 1 second, 500 milliseconds, and 250 milliseconds.
5. Do not use the Series C FIM4/FIM8 with any control module executing more frequently than the Fieldbus device.

4.8.1 Subscription and Publication Rates

Subscription and publication rates are applicable per link. The FIM4 and FIM8 support a subscription rate up to 200 msec.

Note: You cannot configure the subscription rate directly as it varies based on the selected publication rate.

Publication Rate	Subscription Rate
Immediate	200ms
250ms	250ms
500ms	500ms
1 second	1 second

5 Series C FIM4/FIM8 installation and upgrades

This section includes the following topics on information and tasks associated with installing Series C FIM4/FIM8 hardware and upgrading Series C FIM4/FIM8 firmware as well as converting from non-redundant to redundant configuration or vice versa.

Topic
“Installation declarations” on page 32
“Installing Input/Output termination assembly CC- or CU-TFB401, CC- or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412, or CC- or CU-TFB811” on page 33
“Installing Series C FIM4 CC- or CU-PFB401” on page 53
“Upgrading Series C FIM4/FIM8 firmware” on page 56
“Converting non-redundant Series C FIM4 to redundant Series C FIM4/FIM8” on page 57
“Converting redundant Series C FIM4/FIM8 to non-redundant Series C FIM4/FIM8” on page 59

Related topics

- “Installation declarations” on page 32
- “Installing Input/Output termination assembly CC- or CU-TFB401, CC- or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412, or CC- or CU-TFB811” on page 33
- “Installing Input/Output termination assembly DC-TFB402 or DC-TFB412” on page 45
- “Setting unique device index for Series C FIM4” on page 52
- “Installing Series C FIM4 CC- or CU-PFB401” on page 53
- “Installing redundant power conditioner IOTA F660A or F860” on page 54
- “Upgrading Series C FIM4/FIM8 firmware” on page 56
- “Converting non-redundant Series C FIM4 to redundant Series C FIM4/FIM8” on page 57
- “Converting redundant Series C FIM4/FIM8 to non-redundant Series C FIM4/FIM8” on page 59

5.1 Installation declarations

! Attention

This equipment shall be installed in accordance with the requirements of the National Electrical Code (NEC), ANSI/NFPA 70, or the Canadian Electrical Code (CEC), C22.1. It is intended to be mounted within an enclosure or suitable environment acceptable to the local authority having jurisdiction, as defined in the NEC, or authorized person as defined in the CEC.



Electrostatic discharge can damage integrated circuits or semiconductors if you touch connector pins or tracks on a printed wiring board. Follow these guidelines when you handle any electronic component:

- Touch a grounded object to discharge static potential,
- Wear an approved wrist-strap grounding device,
- Do not touch the wire connector or connector pins,
- Do not touch circuit components inside a component,
- If available, use a static safe workstation,
- When not in use, keep the component in its static shield box or bag.



WARNING

Unless the location is known to be non-hazardous, do not perform the following:

- Connect or disconnect cables,
- Install or remove fuses, terminal blocks, and so on,
- While the component is powered.

! Attention

The procedures for installing/upgrading FIM8 module and IOTA is similar to FIM4.

*https://maxautoand.com/
manski@cambiala.cn +86 18030205725*

5.2 Installing Input/Output termination assembly CC- or CU-TFB401, CC- or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412, or CC- or CU-TFB811

Following are the considerations for installing Input/Output termination assembly CC- or CU-TFB401, CC- or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412, or CC- or CU-TFB811.

- You can use a redundant IOTA to support a non-redundant Series C FIM application. You must ensure to install the non-redundant Series C FIM in the upper module slot on the IOTA.
- You are responsible for supplying power, power conditioning and wiring for each Fieldbus H1 link.
- Ensure that the enclosure is connected to a protective earth ground using #8 AWG solid copper wire. There should be contact between the grounding bus bar and the enclosure as well as the carrier.
- The Series C FIM supports connectivity of 350 mA for up to 16 non-intrinsically safe mounted devices or 83 mA for up to three intrinsically safe (IS) mounted devices per H1 link.
- You are responsible for observing all local ordinances governing the wiring and installation of electrical equipment.
- The Series C FIM is designed for removal and insertion under power. Ensure to observe general precautions when working with powered electrical equipment.
- The orientation of the **FTE A** and **FTE B** connectors may be reversed depending on the IOTA version that is installed. Ensure to always connect the **yellow** cable to the **FTE A** connector and the **green** cable to the **FTE B** connector.



Tip

When securing a redundant IOTA to the carrier channel assembly (CCA), install the mounting screws in all locations on one side of the board first and then install the screws in the locations on the other side.

Prerequisites

- Carrier channel assembly for mounting IOTA is installed in a cabinet.
- Series C power supply is installed.
- Control Firewalls (CF9s) are installed.
- All wiring and pre-fabricated cables are available and labeled as applicable.
- You have the mounting hardware supplied with the components.




CAUTION

Ensure that you do **not** fully tighten the IOTA mounting screws before installing and tightening the screws in the 24V+ and COM terminals to keep these screws from binding during IOTA installation.

To mount an IOTA Series C FIM4 Kit

- 1 Select the desired mounting location on carrier channel assembly (CCA) and align mounting holes in IOTA with screw hole locations on the carrier. See the following dimension drawings for details.
 - Ensure that the component side of IOTA is facing up. Secure IOTA to CCA using screws, washers, and spacers provided.
 - Insert spacers and washers between bottom of IOTA and top of CCA.
 - Tighten mounting screws only half way.



- 2 Tighten the screws in terminals **24 Vdc +** and **COM** (logic ground) to the vertical bus bar to connect the cabinet resident 24 Vdc power supply to the IOTA.
- 3 Tighten the mounting screws fully.

<https://maxautoland.com/>
manski@cambodia.ch +86 19039205125




Figure 1: Mounting Dimensions for Non-Redundant IOTA CC- or CU-TFB401 (shown) or CC- or CU-TFB402

<https://maxautorand.com/>
+86 18030205725
manski@cambia.cn





Figure 2: Mounting Dimensions for Redundant IOTA CC- or CU-TFB411 (shown) or CC- or CU-TFB412

To wire a CC/CU-TFB401 or CC/CU-TFB411 IOTA


- 1 Connect yellow FTE cable from Control Firewall (CF9) to J7 FTE A connector on a non-redundant IOTA. For Series C FIM4 mounted in the upper module slot on a redundant IOTA, connect yellow FTE cable from CF9 to J9 FTE A on the IOTA.
- 2 Connect green FTE cable from Control Firewall (CF9) to J8 FTE B connector on a non-redundant IOTA. For Series C FIM4 mounted in the upper module slot on a redundant IOTA, connect green FTE cable from CF9 to J10 FTE B on the IOTA.




Pin Number	Description
1	TD+ (Transmit positive polarity of twisted pair output)
2	TD- (Transmit negative polarity of twisted pair output)
3	RD+ (Receive positive polarity of twisted pair output)
4	2_5V (2.5 V power for magnetics)
5	2_5V (2.5 V power for magnetics)
6	RD- (Receive negative polarity or twisted pair output)
7	NC (No connection)
8	CHASGND (Connection to chassis)
Exterior Shield (Cable/connector chassis ground shield)	

Refer to “Figure 3: Typical Connector Locations on Non-Redundant Model CC/CU-TFB401 IOTA” and “Figure 4: Typical Connector Locations on Non-Redundant Model CC/CU-TFB401412 IOTA” for typical connector locations on a non-redundant model CC/CU-TFB401 and a redundant model CC/CU-TFB411 IOTAs respectively.

- 3 Repeat Step 1 to connect FTE yellow and green cables for partner Series C FIM4 in the lower module slot on a redundant IOTA to **J7 FTE A** and **J8 FTE B** connectors, respectively. Otherwise, go to Step 3.
- 4 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 1** on a non-redundant or a redundant IOTA:
 - Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J2-1 and the negative (-) lead to J2-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 5 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 2** on a non-redundant or a redundant IOTA:
 - Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J3-1 and the negative (-) lead to J3-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 6 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 3** on a non-redundant or a redundant IOTA:
 - Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J4-1 and the negative (-) lead to J4-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 7 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 4** on a non-redundant or a redundant IOTA:
 - Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J5-1 and the negative (-) lead to J5-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 8 If you have the optional redundant power conditioner IOTA, use the cable provided to connect to **J6** on a non-redundant or a redundant IOTA.





BCD switches for setting FTE Device Index number.

Figure 3: Typical Connector Locations on Non-Redundant Model CC/CU-TFB401 IOTA





Figure 4: Typical Connector Locations on Non-Redundant Model CC/CU-TFB401412 IOTA

To wire a CC/CU-TFB402 or CC/CU-TFB412 IOTA


- 1 Connect yellow FTE cable from Control Firewall (CF9) to J8 FTE A connector on a non-redundant CC-TFB412 IOTA. For Series C FIM4 mounted in the upper module slot on a redundant IOTA, connect yellow FTE cable from CF9 to J10 FTE A on the IOTA.
- 2 Connect green FTE cable from Control Firewall (CF9) to J7 FTE B connector on a non-redundant CC-TFB412 IOTA. For Series C FIM4 mounted in the upper module slot on a redundant IOTA, connect green FTE cable from CF9 to J9 FTE B on the IOTA.



Pin Number	Description
1	TD+ (Transmit positive polarity of twisted pair output)
2	TD- (Transmit negative polarity of twisted pair output)
3	RD+ (Receive positive polarity of twisted pair output)
4	2_5V (2.5 V power for magnetics)
5	2_5V (2.5 V power for magnetics)
6	RD- (Receive negative polarity or twisted pair output)
7	NC (No connection)
8	CHASGND (Connection to chassis)
Exterior Shield (Cable/connector chassis ground shield)	

Refer to “Figure 5: Typical Connector Locations on Non-Redundant Model CC/CU-TFB402 IOTA” and “Figure 6: Typical Connector Locations on Redundant Model CC/CU-TFB412 IOTA” for typical connector locations on a non-redundant model CC/CU-TFB402 and a redundant model CC/CU-TFB412 IOTAs respectively.

- 3 For non-redundant FIM4 Kit, connect yellow FTE cable to J10 FTE A connector, and green FTE cable to J9 FTE B connector on the IOTA. For redundant FIM4 Kit, connect yellow FTE cable to J10 and J8 FTE A connectors on a redundant IOTA, and connect green FTE cable to J9 and J7 FTE B connectors on the IOTA.



Pin Number	Description
1	TD+ (Transmit positive polarity of twisted pair output)
2	TD- (Transmit negative polarity of twisted pair output)
3	RD+ (Receive positive polarity of twisted pair output)
4	2_5V (2.5 V power for magnetics)
5	2_5V (2.5 V power for magnetics)
6	RD- (Receive negative polarity or twisted pair output)
7	NC (No connection)
8	CHASGND (Connection to chassis)
Exterior Shield (Cable/connector chassis ground shield)	

- 4 Repeat Step 1 to connect FTE yellow and green cables for partner Series C FIM4 in the lower module slot on a redundant IOTA to **J8 FTE A** and **J7 FTE B** connectors, respectively. Otherwise, go to Step 3.
- 5 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 1** on a non-redundant or a redundant IOTA:
- Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J2-1 and the negative (-) lead to J2-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 6 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 2** on a non-redundant or a redundant IOTA:
- Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J3-1 and the negative (-) lead to J3-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 7 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 3** on a non-redundant or a redundant IOTA:
- Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J4-1 and the negative (-) lead to J4-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 8 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 4** on a non-redundant or a redundant IOTA:
- Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J5-1 and the negative (-) lead to J5-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 9 If you have the optional redundant power conditioner IOTA, use the cable provided to connect to **J6** on a non-redundant or a redundant IOTA.

Pin Number	Description
1	Alarm switch (high side) from power conditioner on H1 Link 1
2	H1 Link 1 - Positive
3	To Common
4	H1 Link 1 - Negative
5	Alarm switch (high side) from power conditioner on H1 Link 1
6	H1 Link 2 - Positive
7	To Common
8	H1 Link 2 - Negative
9	Alarm switch (high side) from power conditioner on H1 Link 1
10	H1 Link 3 - Positive
11	To Common
12	H1 Link 3 - Negative
13	Alarm Switch (high side) from power conditioner on H1 Link 1
14	H1 Link 4 - Positive
15	To Common
16	H1 Link 4 - Negative





Figure 5: Typical Connector Locations on Non-Redundant Model CC/CU-TFB402 IOTA





Figure 6: Typical Connector Locations on Redundant Model CC/CU-TFB412 IOTA

To wire CC/CU-TFB811 IOTA

- 1 Connect yellow FTE cable from Control Firewall (CF9) to J8 FTE A connector on a redundant IOTA. For Series C FIM8 mounted in the upper module slot on a redundant IOTA, connect yellow FTE cable from CF9 to J8 FTE A on the IOTA.
- 2 Connect green FTE cable from Control Firewall (CF9) to J7 FTE B connector on a redundant IOTA. For Series C FIM8 mounted in the upper module slot on a redundant IOTA, connect green FTE cable from CF9 to J7 FTE B on the IOTA.



Pin Number	Description
1	TD+ (Transmit positive polarity of twisted pair output)
2	TD- (Transmit negative polarity of twisted pair output)
3	RD+ (Receive positive polarity of twisted pair output)
4	2_5V (2.5 V power for magnetics)
5	2_5V (2.5 V power for magnetics)
6	RD- (Receive negative polarity or twisted pair output)
7	NC (No connection)
8	CHASGND (Connection to chassis)
Exterior Shield (Cable/connector chassis ground shield)	

Refer to “Figure 7: Typical Connector Locations on Redundant Model CC/CU-TFB811 IOTA” for typical connector locations on redundant model CC/CU-TFB811 IOTAs.

- 3 Repeat Step 1 to connect FTE yellow and green cables for partner Series C FIM8 in the lower module slot on a redundant IOTA to **J10 FTE A** and **J9 FTE B** connectors, respectively. Otherwise, go to Step 3.

- 4 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 1** on a redundant IOTA:
 - Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J2-1 and the negative (-) lead to J2-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 5 Observing polarity and using the molded plug provided in the connector make applicable connections as follows for **FFLINK 2** on a redundant IOTA:
 - Connect the positive (+) lead of the Fieldbus H1 link cable to terminal J3-1 and the negative (-) lead to J3-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 6 Observing polarity and using the molded plug provided in the connector make applicable connections as follows for **FFLINK 3** on a redundant IOTA:
 - Connect the positive (+) lead of the Fieldbus H1 link cable to terminal J4-1 and the negative (-) lead to J4-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 7 Observing polarity and using the molded plug provided in the connector make applicable connections as follows for **FFLINK 4** on a redundant IOTA:
 - Connect the positive (+) lead of the Fieldbus H1 link cable to terminal J5-1 and the negative (-) lead to J5-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 8 Observing polarity and using the molded plug provided in the connector make applicable connections as follows for **FFLINK 5** on a redundant IOTA:
 - Connect the positive (+) lead of the Fieldbus H1 link cable to terminal J13-1 and the negative (-) lead to J13-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 9 Observing polarity and using the molded plug provided in the connector make applicable connections as follows for **FFLINK 6** on a redundant IOTA:
 - Connect the positive (+) lead of the Fieldbus H1 link cable to terminal J14-1 and the negative (-) lead to J14-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 10 Observing polarity and using the molded plug provided in the connector make applicable connections as follows for **FFLINK 7** on a redundant IOTA:
 - Connect the positive (+) lead of the Fieldbus H1 link cable to terminal J15-1 and the negative (-) lead to J15-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 11 Observing polarity and using the molded plug provided in the connector make applicable connections as follows for **FFLINK 8** on a redundant IOTA:
 - Connect the positive (+) lead of the Fieldbus H1 link cable to terminal J16-1 and the negative (-) lead to J16-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 12 If you have the optional redundant power conditioner IOTA, use the cable provided to connect to J17 on a redundant IOTA for **FFLINK 1** to 4 and connect to J18 for **FFLINK 5-8**.




Figure 7: Typical Connector Locations on Redundant Model CC/CU-TFB811 IOTA

<https://maxautorand.manski@cambi.a.cn> +8618008020525

5.3 Installing Input/Output termination assembly DC-TFB402 or DC-TFB412

Following are the considerations for installing Input/Output termination assembly DC-TFB402 or DC-TFB412.

- You can use a redundant IOTA to support a non-redundant Series C FIM application. You must ensure to install the non-redundant Series C FIM in the upper module slot on the IOTA.
- You are responsible for supplying power, power conditioning and wiring for each Fieldbus H1 link.
- Ensure that the enclosure is connected to a protective earth ground using #8 AWG solid copper wire. There should be contact between the grounding bus bar and the enclosure as well as the carrier.
- The Series C FIM supports connectivity of 350 mA for up to 16 non-intrinsically safe mounted devices.
- You are responsible for observing all local ordinances governing the wiring and installation of electrical equipment.
- The Series C FIM is designed for removal and insertion under power. Ensure to observe general precautions when working with powered electrical equipment.
- The orientation of the **FTE A** and **FTE B** connectors may be reversed depending on the IOTA version that is installed. Ensure to always connect the **yellow** cable to the **FTE A** connector and the **green** cable to the **FTE B** connector.



Tip


When securing a redundant IOTA to the backplane, install the mounting screws in all locations on one side of the board first and then install the screws in the locations on the other side.

Prerequisites

- Backplane for mounting IOTA is installed in a cabinet.
- Series C power supply is installed.
- Control Firewalls (CF9s) are installed.
- All wiring and pre-fabricated cables are available and labeled as applicable.
- You have the mounting hardware supplied with the components.

To mount an IOTA Series C FIM4 Kit

- 1 Select the desired mounting location on backplane and align mounting holes in IOTA with screw hole locations on the carrier. See the following dimension drawings for details.
 - Ensure that the component side of IOTA is facing up. Secure IOTA to backplane using screws, washers, and spacers provided.
 - Insert spacers and washers between bottom of IOTA and top of backplane.



- 2 Tighten the mounting screws.




Figure 8: Mounting Dimensions for Non-Redundant IOTA DC-TFB402

<https://maxautorand.com/>
 manski@cambiala.cn +86 18030205125





Figure 9: Mounting Dimensions for Redundant IOTA DC-TFB412

To wire a DC-TFB402 or DC-TFB412 IOTA


- 1 Connect yellow FTE cable from Control Firewall (CF9) to J8 FTE A connector on a non-redundant CC-TFB412 IOTA. For Series C FIM4 mounted in the upper module slot on a redundant IOTA, connect yellow FTE cable from CF9 to J10 FTE A on the IOTA.
- 2 Connect green FTE cable from Control Firewall (CF9) to J7 FTE B connector on a non-redundant CC-TFB412 IOTA. For Series C FIM4 mounted in the upper module slot on a redundant IOTA, connect green FTE cable from CF9 to J9 FTE B on the IOTA.



Pin Number	Description
1	TD+ (Transmit positive polarity of twisted pair output)
2	TD- (Transmit negative polarity of twisted pair output)
3	RD+ (Receive positive polarity of twisted pair output)
4	2_5V (2.5 V power for magnetics)
5	2_5V (2.5 V power for magnetics)
6	RD- (Receive negative polarity or twisted pair output)
7	NC (No connection)
8	CHASGND (Connection to chassis)
Exterior Shield (Cable/connector chassis ground shield)	

Refer to “Figure 5: Typical Connector Locations on Non-Redundant Model CC/CU-TFB402 IOTA” and “Figure 6: Typical Connector Locations on Redundant Model CC/CU-TFB412 IOTA” for typical connector locations on a non-redundant model CC/CU-TFB402 and a redundant model CC/CU-TFB412 IOTAs respectively.

- 3 For non-redundant FIM4 Kit, connect yellow FTE cable to J10 FTE A connector, and green FTE cable to J9 FTE B connector on the IOTA. For redundant FIM4 Kit, connect yellow FTE cable to J10 and J8 FTE A connectors on a redundant IOTA, and connect green FTE cable to J9 and J7 FTE B connectors on the IOTA.



Pin Number	Description
1	TD+ (Transmit positive polarity of twisted pair output)
2	TD- (Transmit negative polarity of twisted pair output)
3	RD+ (Receive positive polarity of twisted pair output)
4	2_5V (2.5 V power for magnetics)
5	2_5V (2.5 V power for magnetics)
6	RD- (Receive negative polarity or twisted pair output)
7	NC (No connection)
8	CHASGND (Connection to chassis)
Exterior Shield (Cable/connector chassis ground shield)	

- 4 Repeat Step 1 to connect FTE yellow and green cables for partner Series C FIM4 in the lower module slot on a redundant IOTA to **J8 FTE A** and **J7 FTE B** connectors, respectively. Otherwise, go to Step 3.
- 5 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 1** on a non-redundant or a redundant IOTA:
- Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J2-1 and the negative (-) lead to J2-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 6 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 2** on a non-redundant or a redundant IOTA:
- Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J3-1 and the negative (-) lead to J3-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 7 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 3** on a non-redundant or a redundant IOTA:
- Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J4-1 and the negative (-) lead to J4-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.
- 8 Observing polarity and using the molded plug provided in the connector, make applicable connections as follows for **FFLink 4** on a non-redundant or a redundant IOTA:
- Connect the positive (+) lead for the Fieldbus H1 link 1 cable to terminal J5-1 and the negative (-) lead to J5-2.
 - Connect the cable shield to the field wiring shield landing bus bar in the enclosure.




Figure 10: Typical Connector Locations on Non-Redundant Model DC-TFB402 IOTA

<https://maxautotrans.com/>
+86 18030205725
manski@cambiala.com




Figure 11: Typical Connector Locations on Redundant Model DC-TFB412 IOTA

https://maxautolamp.com/ +86 18030205325
manski@cambiala.cn

5.4 Setting unique device index for Series C FIM4

Following are the considerations for Setting unique device index for Series C FIM.

- The Device Index setting on a redundant Series C FIM IOTA is assigned to the upper module slot.
- For a redundant Series C FIM application, ensure to set the Device Index to be an odd number. The odd number will be used for the primary Series C FIM and a one (1) will be added to the number to be used as a device index for the secondary Series C FIM. For example, if you set the Device Index to 17 for the primary Series C FIM, the Device Index for the secondary Series C FIM would be 18.
- We recommend setting the Device Index for a non-redundant Series C FIM application to an odd number also, so you can easily upgrade to a redundant Series C FIM application at a later date, if desired.
- For FIM8 you need to set odd device index only.

Prerequisites

You have mounted and wired the IOTA for a given non-redundant Series C FIM or a redundant Series C FIM pair.

To set unique device indexes

- 1 Locate the three binary-coded decimal rotary switches on the left side of the IOTA.
- 2 Use a small flat-bladed screwdriver or your thumbnail to set the left-hand switch (100) to the desired most significant decimal number, middle switch (10) to next desired most significant decimal number and the right-hand (1) switch to the desired least significant decimal number. The applicable setting range is 01 to 509.

<https://maxautoland.com/>
manski@cambiala.cn +86 18320295725

5.5 Installing Series C FIM4 CC- or CU-PFB401

Following are the considerations for Installing Series C FIM4 CC- or CU-PFB401.

- You can install a non-redundant Series C FIM4 on a redundant IOTA. Ensure to install the non-redundant Series C FIM4 in the upper module slot on the IOTA.
- You can install series C FIM8 CC-PFB801 on a FIM8 IOTA only.

It is not applicable for Series C Mark II.

- The IOTA and Series C FIM4 are keyed, so you cannot install any other Series C module on a Series C FIM4 non-redundant or a redundant IOTA.

Prerequisites

You have installed a non-redundant or a redundant IOTA, as applicable.

Only use a #2 Phillips screwdriver to carefully tighten the long gray plastic screw on the Module's face. **Do not use** either a #1 Phillips screwdriver or a battery powered screw driver to remove or install the plastic screw as this can damage the screw head.

To mount a Series C FIM4

- 1 Align Series C FIM4 connector pins over connector/slot on IOTA. On redundant IOTA, ensure that it is the upper slot location.
- 2 Carefully press the Series C FIM until it is fully seated in the connector.
- 3 Use the three screws provided to secure the Series C FIM to the IOTA.
- 4 For redundant applications, repeat Steps 1 to 3 to mount a second Series C FIM on the bottom or secondary connector location on the redundant IOTA.

<https://maxautoland.com/>
+86 15030205725
manski@cambiala.cn

5.6 Installing redundant power conditioner IOTA F660A or F860

! Attention

This section is not applicable for Series C Mark II.

Following are the considerations for Installing redundant power conditioner IOTA F660A or F860

- The optional power conditioner is supplied by the vendor MTL-Relcom. Refer to the vendor supplied documentation for more information about the product.
- The F660A redundant power conditioner includes the following components.
 - One unpopulated IOTA part number F660A-C
 - Eight power modules part number FPS-IPM
 - One Alarm module part number F660A-ALM
- The F660A-NR non-redundant power conditioner includes the following components.
 - One unpopulated IOTA part number F660A-C
 - Four power modules part number FPS-IPM
 - One alarm module part number F660A-ALM
 - Four blanking modules part number FPS-BLK
- The F860 8-segment redundant power conditioner includes the following components.
 - One unpopulated IOTA part number F860-CA
 - Two 8-segment power modules F801
- You should mount the Power Conditioner IOTA above or below the associated Series C FIM IOTA on the carrier.
- The optional power conditioner supplies redundant power to all four H1 links on the associated Series C FIM IOTA as well as alarm contacts to monitor circuit status.
- The following procedure is based on installing a model F660A redundant power conditioner. The procedure is very similar for a model F860 redundant power conditioner except that it has two 16-pin connectors for powering 4-segments on two separate Series C FIMs.

If you use a **non-isolated** power conditioner, you must provide a separate **isolated** input power source for the power conditioner IOTA, since the Series C power subsystem is not isolated.

Prerequisites

You have installed a non-redundant or a redundant IOTA, as applicable.

To mount a power conditioner

- 1 Select the desired mounting location on carrier and align mounting holes in IOTA with screw hole locations on the carrier. See the following dimension drawing for details.
- 2 Ensure that the component side of IOTA is facing up. Secure IOTA to carrier using screws, washers, and spacers provided. Insert spacers and washers between bottom of IOTA and top of carrier.




Figure 12: Mounting Dimensions for Redundant Power Conditioner IOTA F660A

To wire a power conditioner to an IOTA

- 1 Tighten the screws in both sets of terminals for **24 Vdc +** and **COM** (logic ground) to the vertical bus bar to connect to the cabinet resident 24 Vdc power supply.
- 2 Connect the cable plug from the 16-pin connector on the IOTA to the mating 16-pin connector on the associated Series C FIM IOTA.

5.7 Upgrading Series C FIM4/FIM8 firmware

Please refer to the Upgrading Firmware in Multiple Series C Devices section in the *Control Hardware and I/O Module Firmware Upgrade Guide* for information about upgrading firmware in a Series C FIM.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

5.8 Converting non-redundant Series C FIM4 to redundant Series C FIM4/FIM8

Following are the considerations for converting non-redundant Series C FIM4 to redundant Series C FIM4/FIM8


- The Series C FIM4/FIM8 redundant pair must have odd/odd+1 device index number combination, which means the primary or non-redundant Series C FIM4/FIM8 must have an odd address to support an odd+1 address for the secondary Series C FIM4/FIM8. For example, if you set the Device Index to 17 for the primary Series C FIM4/FIM8, the Device Index for the secondary Series C FIM4/FIM8 would be 18.
- You can make the conversion to Series C FIM4/FIM8 redundancy while the process is online.
- The partner Series C FIM4/FIM8 to be added is at the same firmware revision level as the existing primary Series C FIM4/FIM8.

Prerequisites

- The non-redundant Series C FIM4/FIM8 to be converted is currently mounted in the upper module slot on a redundant IOTA.
- The non-redundant Series C FIM4/FIM8 to be converted has an odd number device index.
- You have logged on with sufficient security level to make changes in a control strategy in Control Builder.

To convert to redundant Series C FIM4/FIM8

- 1 The following procedure outlines how to convert an existing non-redundant Series C FIM4/FIM8 to a redundant one given that specified prerequisites are met.
- 2 Install Secondary Series C FIM4/FIM8 in the lower module slot on a redundant IOTA. See previous section on Wiring CC/CU-TFB811 IOTA and procedures for more information.
- 3 In the **Project** tab, double-click the FIM4/FIM8 icon for the current non-redundant Series C FIM4/FIM8 to open the **FIM4/FIM8 Block Parameters** form.
- 4 Click the **Module is redundant** check box.
- 5 Check that **Secondary Tag Name** is specified. The default name is **Tag Name** plus SEC suffix.
- 6 Click **OK** to save the changes and close the form.
- 7 Check that FIM4/FIM8 icon is now redundant and the icon for the secondary FIM4/FIM8 appears in the **Project** tree.
- 8 Double-click the Secondary FIM4/FIM8 icon to open **FIM4SEC Block Parameters** form or **FIM8 SEC Block Parameters** form. Configure block as required. See for reference.
- 9 Click **OK** to save changes and close the form.
 - Right-click the Primary FIM4/FIM8 icon and select **Load** from the list.
 - Click **Continue** to acknowledge the **Warning** prompt, if applicable.
 - Confirm that only the FIM4/FIM8 block is selected for download, as shown in the sample illustration below.
 - Click **OK** to load the block.



- 10 Right-click the Secondary FIM4 icon and select **Load** from the list. Click **Continue** to acknowledge Warning, if applicable; and click **OK** to load the block.
- 11 If both Series C FIM4/FIM8 are installed and auto synchronization is enabled, the modules will synchronize when power is applied.

5.9 Converting redundant Series C FIM4/FIM8 to non-redundant Series C FIM4/FIM8

The following procedure outlines how to convert an existing redundant Series C FIM4/FIM8 to a non-redundant one given that specified prerequisites are met.

! Attention

- You must perform the steps to convert the non-redundant series C FIM4/FIM8 to redundant Series C FIM4/FIM8 and vice versa correctly. If not, when a link is made active, you may see an unexpected Uncommissioned Device which appears on the link in the Control Builder monitoring mode. This device is a representation of the secondary FIM4/FIM8 link and has no functional impact.
- The appearance of the FIM4/FIM8 link as Uncommissioned Device in the Control Builder monitoring mode is suppressed if:
 1. You perform FIM4 switchover if FIM4/FIM8 is redundant.
 2. You remove the secondary FIM4/FIM8 from the IOTA if the FIM4/FIM8 is non-redundant.

Following are the considerations for Converting redundant Series C FIM4/FIM8 to non-redundant Series C FIM4/FIM8.

- Only the Series C FIM4/FIM8 with odd+1 device index number, which is installed in the lower module slot on a redundant IOTA, can be removed from the system.
- If you try to delete a secondary Series C FIM4/FIM8 from the **Monitoring** tab while the redundant Series C FIM4/FIM8 pair is synchronized, the command will be rejected.
- If the secondary Series C FIM4/FIM8 is still installed when the primary/non-redundant Series C FIM4/FIM8 is loaded, an alarm will signal the presence of an unconfigured partner.
- You can use a redundant IOTA to support a non-redundant Series C FIM4/FIM8 application. Just be sure the non-redundant Series C FIM4/FIM8 is installed in the upper module slot on the IOTA.

Prerequisites

- The Primary Series C FIM4/FIM8 has an odd number for its device index.
- The Secondary Series C FIM4/FIM8 has an odd+1 number for its device index and it is installed in the lower module slot on the redundant IOTA.
- You have logged on with sufficient security level to make changes in a control strategy in Control Builder.

To convert to non-redundant Series C FIM4/FIM8

- 1 In the **Monitoring** tab, double-click the Primary FIM4/FIM8 block icon to open the FIM4/FIM8 Block Parameters form.
- 2 On the **Main** tab, confirm that block **Redundancy Role** is Primary and **Device Index** is an odd number.
- 3 If the Series C FIM4/FIM8 with the odd device index number is not the Primary, click the **Redundancy** tab and click **Initiate Switchover** to issue a switchover command.
- 4 On the **Redundancy** tab, click **Disable Synchronization** to disable auto synchronization. Click **Yes** to confirm the action.
- 5 Click **OK** to close the form.
- 6 Loosen the three screws in the secondary Series C FIM4/FIM8 and remove it from the lower module slot on the redundant IOTA. Remove FTE cable connections, as applicable.
- 7 In the **Monitoring** tab, right-click the secondary FIM4/FIM8 icon and select **Delete** from the list. Click **Delete selected object(s)** to confirm the action.
- 8 In the **Project** tab, right-click the secondary FIM4/FIM8 icon and select **Delete** from the list. Click **Delete selected object(s)** to confirm the action.

- 9 In the Project mode, clear the **Module is Redundant** check box.
 - Right-click the primary/non-redundant FIM4/FIM8 icon and select **Load** from the list.
 - Click **Continue** to acknowledge the **Warning** prompt, if applicable.
 - Confirm that only the FIM4/FIM8 block is selected for download.
 - Click **OK** to load the block.

<https://maxautoland.com/>
manski@cambiala.cn +86 18030205725

6 Series C FIM4/FIM8 configuration

This section includes the following topics on information and tasks associated with Configuring FIM4/FIM8, FFLinks, and Fieldbus Devices for use in control strategies created in Control Builder.

Topic
“Adding FIM4/FIM8 block to project” on page 64
“Checking FFLink configuration” on page 66
“FFLink configuration parameters reference” on page 68
“Creating a fieldbus device type from vendor DD”
“Editing device block parameters” on page 77
“Adding a fieldbus device to project” on page 78
“Assigning a device to a FFLink in Project” on page 79
“Checking device configuration” on page 80
“Making fieldbus block template and assigning function block to device” on page 82
“Configuring advanced alarming” on page 83

Please refer to the *Control Building User's Guide* for basic functionality details about calling up, navigating and interacting with the application. Also, be aware that menus, selections, tree views, and configuration forms may vary depending upon the licensed options installed on your system.



Attention

The procedures for Configuration FIM8 module and IOTA is similar to FIM4.

Related topics

- “Non-Experion interface precautions” on page 62
- “Free VCR recommendation” on page 63
- “Adding FIM4/FIM8 block to project” on page 64
- “Checking FFLink configuration” on page 66
- “FFLink configuration parameters reference” on page 68
- “Creating a Fieldbus device type from vendor DD” on page 73
- “Editing device block parameters” on page 77
- “Adding a fieldbus device to project” on page 78
- “Assigning a device to a FFLink in Project” on page 79
- “Checking device configuration” on page 80
- “Making fieldbus block template and assigning function block to device” on page 82
- “Configuring advanced alarming” on page 83
- “Block Offnet diagnostic alarm” on page 90

6.1 Non-Experion interface precautions

You can use available non-Experion **handheld** and **standalone** Fieldbus **interfaces** to change parameters in Fieldbus devices. These interfaces are particularly useful for bench configuration and calibration functions. You can connect third-party interfaces to the Fieldbus network through one of the four data link visitor addresses (252 to 255) reserved for them. While some interface products appear to successfully co-exist with the Experion Fieldbus Interface Module, others may impede or disrupt the ability to perform some system operations. Be sure you review the following precautions before using a non-Experion interface with Fieldbus devices in an Experion system.



CAUTION

- Why you need to be very careful when using non-Experion handhelds and non-Experion standalone Fieldbus interfaces with devices in an Experion system:
- They **do not honor Experion access rights** and they may or may not have their own independent personnel access control mechanisms.
- They **do not record changes in Experion event log files** and they may or may not have their own independent change recording mechanisms.
- If they are used to **change the values of parameters**, the stored values for those parameters may **not** be updated in the Experion Control Builder 'Monitor' or 'Project' databases. In this case, a reload of the device may result in loss of changed values. Users are responsible for uploading and/or updating Experion databases manually to maintain up-to-date values.
- They **might be able to affect the configuration of Fieldbus devices** beyond the control of Experion systems. The alternations could include changes to link publication schedules, backup link publication schedules, function block execution schedules, function block connections, tag names, and so on. Users are responsible for making sure that no alteration could occur from using a non-Experion interface, since Honeywell **cannot** guarantee that an alteration will **not** occur.
- **Only highly trained individuals** who completely understand Foundation Fieldbus and the Experion configuration and support role for Foundation Fieldbus should use non-Experion interfaces with devices in an Experion system.
- **Never connect** non-Experion interfaces while commissioning devices and/or loading (or reloading) Control Modules containing Fieldbus function blocks.
- Never make any parameter changes without the knowledge and cooperation of plant/mill operations personnel.
- Never use non-Experion interfaces to load or commission devices.
- Always connect non-Experion Interfaces to the network as visitor only at one of these four addresses: 252, 253, 254, or 255.
- Always connect non-Experion Interface to the network as Basic Device Type. Never connect as Link Master Type.
- You can use any spare connection terminal on the bus to connect non-Experion interfaces; but you must make sure that the connection is secure or it could disrupt link communications.
- Carefully consider the need for using a non-Experion interface in the field, since most of them are very SLOW in comparison to Experion operations.
- Be aware that non-Experion interfaces can use significant bandwidth that could affect Experion performance.
- Always remove non-Experion interfaces from the network when their intended task is completed.

6.2 Free VCR recommendation

We recommend that you leave at least **one** VCR free during configuration so that device replacement will not require you to free a VCR first. Each Fieldbus segment requires at least one free VCR to support reloading or replacing a device on the segment. If you configure each segment with the maximum number of VCRs allowed, 128 per segment for Series C FIM, you will need to free a VCR before you can complete a device replacement on the given segment. Typically, you can free a VCR by deleting a Control Module or device from the Monitoring tab in Control Builder. Control Builder displays a Warning message when a segment is low on free VCRs.

Attention

- When the number of VCRs used on an FF Link is greater than 64, you must clear the Update Parameter checkbox, as Update to Project must be performed in several steps. For each step, select the CMs such that the total number of VCRs used by these CMs is less than the available VCRs on the link, which is (128 - total number of VCRs) used on the Project mode.
 - When the number of VCRs used on an FF Link is greater than 50% of the maximum VCR (128) link count, the Update to Project or Upload operation clears all existing connections between the FF and Experion blocks in the Project mode. Therefore, to prevent this, you must select the Parameters Only checkbox when performing an Update to Project or Upload. This updates only the parameter values from the Monitoring mode.
-

<https://maxautoland.com/>
manski@cambiala.cn +86 18030205185

6.3 Adding FIM4/FIM8 block to project

Following are the considerations for adding FIM4/FIM8 block to project.

- You cannot add a FIM4/FIM8 block to the **Project** tab without first configuring the applicable IP addresses for the FTE network and NTP servers.
- You can only view FIM4/FIM8 blocks in **Project** tab set for the **Assignment view**. The **Assignment view** shows the relationship among all blocks while the **Containment view** only shows templates that contain other templates or Control Modules (CM), Sequential Control Modules, (SCM) and basic blocks. To toggle the view, right-click in an open area of the tab window and select **Assignment View** or **Containment View** from the list, as applicable.
- You can configure a FIM4/FIM8 block in the Control Builder **Project** tab without the FIM4/FIM8 hardware being installed. However, it is good idea to have the FTE communications driver and hardware that is going to be used for the system installed, configured, and running. The FIM4/FIM8 needs its device index number specified on its configuration form to complete its IP address data. Like the C300 Controller, the Series C FIM4/FIM8 represents a hardware module and the block configuration specifies the communication path to the hardware.
- Each FIM4/FIM8 block is automatically assigned a unique default tag name when it is created. If your system will include multiple FIM4s/FIM8, you may want to adopt a more structured syntax for naming them.
- The block tag name can be up to 16 characters long and must contain at least one letter (A-Z). It must not contain an embedded space or leading space, and dots are allowed in parameter naming only.
- The item name can be up to 40 characters long and must contain at least one letter (A-Z). It is a name by which an entity is known within the context of the enterprise model. The Item name must be unique among children of the same containment parent in the Enterprise Model Builder hierarchy and should conform to the standard convention for names within the system.
- The Series C FIM4/FIM8 module includes a temperature sensor that monitors its ambient temperature. If the module's ambient temperature exceeds the configurable Temperature High Alarm value, it will trigger an alarm. The module's temperature sensing function automatically compensates for wild swings in the ambient to minimize nuisance alarms.
- If you are using a power conditioning solution that is not integrated with the Series C FIM4/FIM8 and does not connect to the power conditioner connector on the IOTA, check the Suppress H1 Power Alarm check box on FIM4s/FIM8s Main tab to suppress power alarms.

Prerequisites

- You have started Configuration Studio and launched the Control Builder application.
- You have logged on with sufficient privileges to create control strategies using Control Builder.
- You have configured the applicable IP addresses when you set up your FTE network.
- You have configured applicable Base IP address and IP addresses for network time protocol (NTP) servers through the **System Preferences** dialog in Control Builder. See the Control Building User's Guide for more information about setting IP addresses.

To create a FIM4/FIM8 block

- 1 On the **File** menu from the Control Builder, click **New > Interface Modules > FIM4 - Fieldbus Interface Module**. Calls up the FIM4 block parameters configuration form **Main** tab with **Tag Name** box highlighted.



Attention

- To create FIM8, you must click **New > Interface Module > FIM8-Fieldbus Interface Module**.

- 2 In the **Tag Name** box, key in desired block tag name or accept the default one.
- 3 Click the **Item Name** box and key in the name of the item that this object will be associated with in the Enterprise Model Builder hierarchy.

- 4 Click the **Device Index** box and key in the device index number set on the Series C FIM's IOTA.
- 5 Click **Alarming Enabled** to enable the alarming option for the block.
- 6 Click **Temperature High Alarm (deg. C)** box and key in desired threshold at which an alarm is generated for Series C FIM hardware temperature, or accept the default setting of 80 deg. C.
- 7 Click **CPU Free Low Alarm Limit (%)** box and key in desired threshold at which an alarm is generated for Series C FIM CPU availability in percent, or accept the default value of 15 percent.
- 8 If Series C FIM4/FIM8 is to be part of a redundant pair, click **Module is redundant** check box to select it. Otherwise, go to Step 10.
- 9 For redundant FIM4/FIM8, the **Secondary Tag Name** is a combination of configured Tag Name plus SEC suffix.
- 10 If you want to suppress H1 power alarms, click the **Suppress H1 Power Alarm** check box to select it. Otherwise, go to the next step.
- 11 If you want to enable the safe handling of new devices option, click the **Safe Handling of New Devices Enable** check box to select it. Otherwise, go to the next step.
See "Using optional safe handling of new devices" on page 137 for more information.
- 12 If you want to set a delay time for the device drop off link alarm, click the **Device Drop Off Alarm Delay** box and key in the desired delay time in seconds. Otherwise, go to the next step.
- 13 Refer to the *Control Building User's Guide* and/or the *online help* to complete configuration data on the **Redundancy**, **Server History**, **Server Display**, **Control Confirmation**, and **Identification** tabs. The **Statistics** and **Version** tabs only contain read-only parameters.
- 14 When you completed entering configuration data, click **OK** to close the configuration form and add icon for non-redundant or redundant FIM4/FIM8 to the **Project** tab. The FIM4/FIM8 also includes icons for the four H1 Fieldbus links that it can support.
- 15 If you have redundant FIM4/FIM8 configuration, right-click the Secondary FIM4/FIM8 icon and select **Module Properties** from the list to call up the **Parameters** configuration form. Configure as required and click **OK** to close the form.


https://maxautoland.com/18030205125
 manski@cambid.com

6.4 Checking FFLink configuration

Following are the considerations for checking FFLink configuration


- Like the Series C FIM, you can configure a FFLink through the **Project** tab of Control Builder without having the H1 link installed. However, some parameters on the FFLink configuration form can only be viewed through the **Monitoring** tab with the Series C FIM4/FIM8 and FFLink installed and communicating with the system.
- Be sure to click the plus sign in front of the FIM4/FIM8 icon to open its directory tree and expose the FFLink icons. With the Hierarchal Building license option, must have the Assignment View active to view FIM4/FIM8 and FFLink blocks.
- In a redundant Series C FIM application, the FFLink blocks are shown with the primary FIM4/FIM8 block only.
- We recommend that you accept the default values listed for parameters on the **System Management** and **Network Management (LM)** tabs, unless you have prior experience with the devices you are adding to the FFLink. The default settings were carefully chosen to provide the most logical initial settings for most applications. It is more efficient to make any needed adjustments to these parameters in the **Monitoring** mode.
- A wizard will guide you through the FFLink configuration process.
- The block name can be up to 16 characters long and must contain at least one letter (A-Z). It must not contain an embedded space or leading space, and dots are allowed in parameter naming only.
- The item name can be up to 40 characters long and must contain at least one letter (A-Z).
- The following illustration shows the entry fields that are common for time related values. The values shown are the maximums for the given field. Use the Left and Right Arrow keys on the keyboard to move the cursor left or right in the field and use the increase and decrease buttons provided to adjust values in the selected field.

Table 4: Typical Entry Fields for Time Related Values.

**Prerequisites**

You have completed the previous procedure to add a FIM4/FIM8 block to the **Project** tab.

To check FFLink values

- 1 Right-click the FFLink icon  and select Module Properties from the list. Calls up the FFLink Block Parameters configuration form with the Name box highlighted.
- 2 In the **Name** box, key in desired block tag name or accept the default one.
- 3 Click the **Item Name** box and key in the name of the item that this object will be associated with in the Enterprise Model Builder hierarchy.
- 4 Click the **Description** box, key in desired descriptive text of up to 132 characters. This text will appear in applicable detail and group displays associated with this block.
- 5 Click the **Link Schedule Optimization** box, select desired setting from the list: **OPT**, **OPT_NOFORCE**, or **NO_OPT**. Default selection is **OPT**.
- 6 Click the **Sample Skew** box; select the desired setting from the list: **SKEW** or **NOSKEW**. The default selection is **SKEW**.
- 7 Refer to the *Control Building User's Guide* and/or the *online help* to complete configuration data on the **Server History**, **Server Display**, **Control Confirmation**, and **Identification** tabs. The **Network Management (Basic)**, **Statistics**, and **Version** tabs only contain read-only parameters.
- 8 When you completed entering configuration data, click **OK** to close the configuration form.
- 9 Repeat this procedure for Links 2, 3, and 4, as required.

6.5 FFLink configuration parameters reference

The following table summarizes the Fieldbus related parameters that are user configurable through the **FFLINK Block** configuration form. These parameters let you uniquely identify the FFLink component in the control strategy and tune the performance of FFLink communications. Only the FFLink parameters that are user configurable are listed. Some parameters are only available in the **Monitoring** mode and they are identified as Monitor Only in the table.

Tab	Parameter	Description
Main	Acting Primary Link Master (ACTINGLM)	Monitor Only This read-only parameter indicates whether or not this node is the acting primary Link Master. A check mark in the check box means that the node is the acting primary Link Master. A blank check box means that the node is not the acting primary Link Master.
	Link Schedule Optimization (SCHDOPTIMIZE)	Specifies if the link schedule is to be automatically optimized or not. Use the OPT selection for Link Scheduling Optimization that changes ORDERINCM values. The optimized schedule is used to update the natural schedule details. The ORDERINLINK/ORDERINCM parameter values are updated to match the sequence of the optimized schedule. The next time that the schedule is viewed/loaded, no prompt asks for confirmation of the action. Use the OPT_NOFORCE selection for Link Scheduling Optimization that ignores ORDERINCM values. The optimized schedule is used to update the natural schedule details. The ORDERINLINK/ORDERINCM parameter values are left unchanged. The next time that the schedule is viewed/loaded, a prompt will ask for confirmation of this action. Use the NO_OPT selection to disable Link Schedule Optimization for this Link and use ORDERINCM values. The natural schedule is used. The DISABLELINKOPT is set true so that an optimized schedule is no longer created for the link. If an optimized schedule is required later, change this parameter selection to OPT or OPT_NOFORCE .
	Sample Skew (SAMPLESKEW)	Determines when input blocks will execute. Use the SKEW selection to schedule each input block to execute at the time closest to where they converge on a common block like an input selector (minimum loop latency). Use the NO_SKEW selection to schedule input blocks to execute at the same time where they converge on a common block like an input selector (minimum scan skew).
System Management	Step Timer Preset (T1)	Specifies the preset time for the System Management step timer in seconds. The default value is specified by the communications profile for the application area. This is an inter-sequence timer. It ensures that devices responding to system management requests have sufficient time to carry out necessary actions and transmit a response.
	Preset Set Addr Seq Timer (T2)	Specifies the preset value for the System Management set address sequence timer in seconds. The default value is specified by the communications profile for the application area. This is a sequence duration timer. It ensures that incorrectly executed or incomplete sequences are aborted in the SMK.

Tab	Parameter	Description
	Preset Addr Wait Timer (T3)	Specifies the preset value for the set address wait timer in seconds. The default value is specified by the communications profile for the application area. This timer allows time for a device at a new address to be accessed and added to the delegated token list of the LAS.
Network Management (LM)	Def Min Token Delegation Time (LMINFREC.DMDT)	Defines the default minimum amount of local link capacity that the LAS allocates to a single Pass Token Data Link Protocol Data Unit (PT DLPDU) sent to the Data Link Entity (DLE). Its range is 32 to 32767, its default value is 84 + Data Link Protocol Data Units (DLPDU) Physical Layer Overhead (PhLO) value, which permits the sending of one URGENT DLPDU, and its unit is the transmission duration of one octet.
	Def Token Hold Time (LMINFREC.DTHT)	Defines the default initial amount of local link capacity that the LAS DLE allocates to each DLE, in one cycle of 'circulating the token', when the LAS sends one or more PT DLPDUs to the DLE. Its range is 276 to 65000 and its default value is 276 + Data Link Protocol Data Units (DLPDU) Physical Layer Overhead (PhLO) value, which permits the sending of one URGENT DLPDU, and its unit is the transmission duration of one octet.
	Target Token Rotation Time (LMINFREC.TTRT)	Specifies the desired upper bound on the time required for one cycle of the 'circulating the token' to all the DLEs on the local link that the LAS DLE uses. One cycle of 'circulating the token' is measured as the interval between successive occurrences of the LAS DLE sending a PT DLPDU with a token-use sub field specifying Restart to the lowest numbered node address represented in the local link live list. Its range is 1 to 60000. The unit is one millisecond.
	Link Maint Token Hold Time (LMINFREC.LTHT)	Specifies the initial amount of local link capacity that the LAS DLE should allocate to LAS related link maintenance activities in one cycle of 'circulating the token'. Its range is 292 to 65000 and its default value is 292 + Data Link Protocol Data Units (DLPDU) Physical Layer Overhead (PhLO) value + Immediate Response Recovery Delay (IRRD) value + Slot Time (ST) value, which permits the probing of one node address and the sending of one time available DT DLPDU. The unit is the transmission duration of one octet.
	Time Distribution Period (LMINFREC.TDP)	Determines the minimum frequency of time distribution on the local link. Its initial value is the minimum value required for the link's time synchronization class and its range is 5 milliseconds to 55 seconds. The unit is one millisecond.
	LAS DB Status Distribution Period (LMINFREC.LDP)	This parameter is used by the LAS to determine the time between two successive distributions of the LAS' database by means of the LAS database status SPDUs sent on the local link. Its range is 100 milliseconds to 55 seconds. The unit is one millisecond.

Tab	Parameter	Description
	Slot Time (LMLSTREC.ST)	<p>Indicates the configured slot time value. It is a fundamental link parameter with multiple uses. Each Link Master DLE connected to the link uses Slot-time to determine how long that DLE monitors the link for inactivity before sending a CLAIM LAS (CL) DLPDU. Slot-time is defined such that the nominal link-inactivity monitoring periods of two DLEs that have consecutive node addresses and do not hold any token differ by exactly one slot time. Its range is 1 to 4095, and its unit is the transmission duration of one octet. The default value is 8, which should be valid for most applications.</p> <p>Slot-time defines the minimum upper bound on the maximum two-way asynchronism in immediate communications among interacting DLEs on the local link when trying to initialize the link, maximized across all pairs of DLEs on that local link. It is an aggregate measure of the worst-case implementation delays within the intervening media, the PhL, and the PhL/DLL interfaces, all of which limit the speed of two-way DLE interaction on the local link.</p>
	DLPdu Physical Layer Overhead (LMLSTREC.PHLO)	Indicates the configured Data Link Protocol Data Units (DLPDU) Physical Layer Overhead (PhLO) value. The DLE uses it to account for the Physical Layer induced delay between the end of the last octet of one DLPDU, as it appears on the link, and the beginning of the first octet of any other DLPDU, as it appears on the link. It is measured in units of one octet-duration. Its range is 2 to 63.
	Max Response Delay (LMLSTREC.MRD)	Indicates the configured maximum response delay value. It is a measure, in units of one slot time, greater than the worst-case period of local Physical Entity inactivity that a DLE can observe. The DLE uses it to record the link's maximum response delay. Its range is 1 to 11.
	First Unpolled Node ID (LMLSTREC.FUN)	Indicates the first unused node address value. It is the first node address of a series of consecutive node addresses, which are to be omitted from the orderly probe of node addresses for DLE's not specified by the local link live list. Its range is 21 to 247.
	This Link (LMLSTREC.TL)	This parameter is a two-octet primary identifier for the local link, within the extended link, whose values are constrained. The DLE uses it to record the local link ID. Its default un-initialized value is zero, which does not permit a bridge to forward to another link. Its range is 0, and 4096 to 65279.
	Minimum Inter Pdu Delay (LMLSTREC.MID)	Specifies the minimum duration for an interval of non-transmission that a DLE provides after either receiving or transmitting a DLPDU. It is measured in units of the transmission duration of one octet. The default value is 16 and its range is 0 to the smaller of 120 or (Maximum Response Delay -1) x Slot Time.
	Number of Consecutive Unpolled (LMLSTREC.NUN)	Specifies the number of consecutive unused node addresses, which are to be omitted from the orderly probe of node addresses for DLE's not specified by the local link live list. Its range is 0 to 228 and its default value is 196
	Preamble Extension (LMLSTREC.PMBEXTN)	Specifies an extension period for the preamble. A preamble is transmitted at the beginning of each Physical Layer Protocol Data Unit (PhPDU) to synchronize bit times. The period may be extended, but not reduced. It is an Unsigned8 variable with allowable values between 0 and 7.

Tab	Parameter	Description
	Post Trans Gap Extension (LMLSTREC.PTGEXTN)	Specifies an extension to the minimum period during which a subsequent transmission shall not commence after transmission of a PhPDU. For the same minimum period after reception of a PhPDU, the receiving Physical Layer entity shall ignore all received signaling. A Medium Dependent Sublayer (MDS) entity shall set a minimum post transmission period of four nominal bit times. The period may be extended, but not reduced. It is an Unsigned8 variable with allowable values between 0 and 7.
	Max Inter Channel Signal Skew (LMLSTREC.MXICSSW)	Defines the maximum accepted differential delay between any two active channels, as measured from the first PhPDU of a start delimiter, if the device is to receive concurrently on more than one channel. The delay shall not exceed five nominal bit times. This period may be extended, but not reduced. The value of the post transmission gap shall be greater than the value of inter channel skew. It is an Unsigned8 variable with allowable values between 0 and 7.
	Time Sync Class (LMLSTREC.TIMSCLS)	Specifies one of the time synchronization classes. The DLE uses it to record the Link's time synchronization class and to determine the DLE's own requirement for the minimum time distribution period it needs to maintain the specified level of time synchronization. Its default value is 10 ms. The eight classes are None, 1microsecond, 10 microseconds, 100 microseconds, 1 millisecond, 10 milliseconds, 100 milliseconds, and 1 second.
	Primary Link Master (PRIM_LM_FLG)	<ul style="list-style-type: none"> • Monitor Only • Indicates whether or not this node is the primary Link Master. A check mark in the check box means that the node is the primary Link Master. A blank check box means that the node is not the primary Link Master. • A write to this parameter orders the receiving Link Master to try to become the Link Active Scheduler (LAS). If the Link Master becomes the LAS, it returns an FMS Write.rsp(+), which turns the flag On (check mark). If this attempt fails, it returns an FMS Write.rsp(-), which keeps the flag Off (blank). <p>Notes:</p> <ul style="list-style-type: none"> • It is a configuration error to have more than one device on a link configured as the primary Link Master. • The Series C FIM is the designated primary Link Master for both of its Links. • The value of this parameter may only be set to On (check mark) through a FMS Write or a local interface. • When this parameter is On and the device is attached to the network at one of the default addresses, the NMA regards the value as a configuration value and does not attempt to acquire the LAS. • When this parameter is On or it receives a FMS Write.ind to turn it On from the NMA of a Link Master device that is not the LAS and is at an assigned address instead of a default one on the network, the NMA instructs the Data Link Management Entity (DLME) to acquire the LAS. The two possible outcomes are as follows. • If the DLME indicates that the attempt failed, the NMA sets the value of this parameter to Off. If a FMS write response is pending, the NMA returns a negative response. • If the request succeeds on either the first or the second attempt, the NMA sets the value of the parameter to On (if not On already). If an FMS write response is pending, the NMA returns a positive response.

Tab	Parameter	Description
	Boot Operational Function Class (BOOT_OPER)	Specifies the Operational Function Class that the device assumes when it is powered up. The class selections are Basic, Link Master, and Bridge. The Series C FIM is the Primary Link Master for all Links.
Device Diagnostics	Alarm Conditions Status	To enable/disable the alarm conditions status.
	Non-Cache parameters	The parameter's real time values are available from the devices and not from the FIM memory after configuring non-cache parameters in FIM.
Maintenance tab	Enable Block Offnet Diagnostic Alarm (OFFNETALM_ENABLED)	This parameter is used for enabling or disabling the Block Offnet Diagnostic Alarm. By default, this parameter is disabled.

<https://maxautoland.com/>
 manski@cambiala.cn +86 18030205725

6.6 Creating a Fieldbus device type from vendor DD

Following are the considerations for creating a Fieldbus device type from vendor DD

- The DD or EDD files can be stored in this directory location *C:\Program Files\Honeywell\Experion PKS\Engineering Tools\system\ER\Release*. This directory must include these three files:
The *.FFO file is the DD binary file, or *.FF5 file is the EDD binary file.
The *.SYM file is the device symbol file
The *.CFF file is the device capability file.
- You can skip this procedure, if a block for the given device type already exists in the Control Builder **Library** database.
- If you use a version 4.02.02 or older Honeywell Fieldbus device or a version 2.02.02 or older FlowServe Fieldbus device as a backup Link Master node with redundant Series C FIMs, we recommend that you assign the device to address **40** (decimal).
- Do not assign addresses below **30** to any backup Link Master devices.

Prerequisites


You must have the Device Description (DD) files or Enhanced Device Description (EDD) files for the Fieldbus device either on a disk supplied by the manufacturer or downloaded from the vendor's web site. This means you can make a device block type without being connected to a device.

Attention

- Experion supports DD files and EDD files and continues to process the DD to create a device block type in the Control Builder library.
- As part of importing a DD file, if the DD file contains parameters in a no_download list, then the parameter load destination will be set as "No load."

To create Fieldbus device type


- 1 On the **File** menu, click **New** → **Type** → **Fieldbus Device**.
- 2 In the **Select Device Type** dialog box, Click to browse for the applicable DD file location in the Device DD Files box.
Or
In **Device List** box, click the device you want to add to the Control Builder Library.



A dialog box appears displaying information about the DD version files which are equal to or more than version 5.

3 Click **OK**.


If a device supports single or multi-capability feature, then the following dialog box appears.



4 Select any one of the capability levels supported for the device and then click **OK**.

Attention


- If the DD file template already exists, the following message appears.



- Click **Save As** to save the device with a different name for device type.
Or
- Click **OverWrite** to select a device type and overwrite that device type with a new device type.
To select a device type, under **Select a Device Template to Overwrite (or) Refresh**, select a device type that you want to overwrite with a new device type.
Or
- Click **Refresh** to select a device type that you want to refresh with the changes.
To select a device type, under **select a Device Template to Overwrite (or) Refresh**, select a device type that you want to refresh with the changes.

- Click **OK** to acknowledge the version of DD files.

A dialog box appears displaying information about the DD files, which have Conditionals.



- Click **OK** to import the DD files. Monitor progress through the **Opening Device Honeywell Files, Creating Definition Files, and Importing the Block Type to ERDB** progress dialog boxes that open in succession.

Attention

- If the DD files do not contain Conditionals, then the process of importing DD files continues without displaying a message about the presence of Conditionals.

- 7 Click **OK**.
In the **Library** tab, a new device block type is created under the Honeywell's name and the DD files with constructs are supported.
- 8 In the **Library** tab, select a new device block type under the Honeywell's name.
This completes the procedure. Go to the next section *Editing device block parameters*.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

6.7 Editing device block parameters

Following are the considerations for editing device block parameters

- Be sure you review the **Load Destination** column for manufacturer specific parameters listed on the **Honeywell** tab in the Parameter Definition Editor.

The NOLOAD setting essentially means that the parameter will not be loaded to the device, when the device is downloaded from the **Project** tab in Control Builder, so the corresponding parameter in the device itself will not be overwritten.

The LOAD setting means that the parameter will be loaded to the device and will overwrite the corresponding parameter in the device itself. Re-set the Load Destination to LOAD, if you want to change the settings for any given parameter during block configuration.

- Be very judicious about selecting what parameters to edit. By keeping the default values, you may use the same block type for like vendor devices used in multiple locations in your application. You can make adjustments to selected device parameters through Control Builder configuration access. Honeywells usually supply a text file that includes definitions for each function block used in their device.

Prerequisites

You have completed the previous procedure to add Fieldbus device type to the **Library** tab.

To make edits

- 1 On the **Library** tab, click the plus sign (+) for the Fieldbus device type that includes the blocks you want to edit. Do the same for the device icon to expose its blocks.
- 2 Double-click the block you want to edit to open the **Parameter Definition Editor** in the Control Drawing view pane of Control Builder.
- 3 View or edit parameters for the selected block in the **Parameter Definition Editor**. Refer to the *Parameter Definition Editor Reference* for more information about using the Parameter Definition Editor.
- 4 Click the close button on upper right-hand corner of the **PDE** to close it.
- 5 If prompted to save changes, click **Yes** to save edits or **No** to cancel them.
- 6 Repeat the procedure for other device blocks, as required.

https://maydaybolana.com/18030205725
 manski@cambria.cn +86

6.8 Adding a fieldbus device to project

Following are the considerations for adding fieldbus device to Project.

- Devices created in **Project** tab automatically include only their fixed function blocks, transducer blocks, and resource blocks. If the device block type includes instantiable blocks, you must drag and drop the instantiable block from the block type in the **Library** tab to the device icon in the **Project** tab to instantiate (create) it in the device in **Project**. See “Instantiable block implementation considerations” on page 117 for reference.
- You can use drag and drop or menu selections method to assign a device to an FFLink in the **Project** tab.
- We suggest that you wait to check all block configuration parameters until after the device is assigned to a FFLink.

Prerequisites

You have completed the previous procedures to add FIM4/FIM8, Links, and device Type through Control Builder.

To use drag and drop method

- 1 Click sign in front of the applicable vendor type directory in the **Library** tab to show stored device block types.
- 2 Drag the device icon to an open area in the **Project** tab. (Note that cursor appears with + sign, when positioned in a valid location.) Calls up the **Name New Function Block(s)** dialog box.
- 3 In the **Destination** box, key in desired name consisting of up to 16 characters or accept the default name for the device. Click **Finish**.
- 4 Check that device instance with given name is created in **Project** tab under the Unassigned category.
- 5 Repeat this procedure to add other devices or go to the next section *Assigning a device to an FFLink in Project*.

To use the file menu method

- 1 On the **File** menu, click **New-> Devices- > Some Honeywell Name Fieldbus Device**. (Note that the **Devices** menu is dynamically updated to include the vendor and device data for block types created through the Type function.) Calls up the **Block Parameters** configuration form for given device with **Name** box highlighted
- 2 In the **Name** box, key in desired name consisting of up to 16 characters or accept the default name for the device. Click **OK**.
- 3 Check that device instance with given name is created in **Project** tab under the Unassigned category.
- 4 Repeat this procedure to add other devices or go to the next section *Assigning a device to an FFLink in Project*.

6.9 Assigning a device to a FFLink in Project



Following are the considerations for assigning a device to a FFLink in Project

- An alternate method to the following procedure is to just drag and drop the device to the applicable FFLink in Project.
- If duplicate address error message appears, go to the next section *Checking device configuration* for details on changing the device's network node address. It is possible for device addresses to be set to the same default value of 20.

Prerequisites

You have created a Series C FIM block in the **Project** tab.

To assign a device to a FFLink

- 1 Click **Edit** -> **Execution Environment Assignment**. Or, click the assign button  in the toolbar. Calls up the **Execution Environment Assignments** dialog box.
- 2 Click **Devices** tab. Shows all devices currently in **Project** tab.
 - Click the device you want to assign to a FFLink to highlight it.
 - Confirm that the desired FFLink is selected in the **Assign To** list box.
 - Click the **Assign** → button to assign the selected device to the selected FFLink.
 - Check that device is added to the **Assigned Modules** list box with the assign state icon .
- 3 Repeat Steps 3 and 4 of other devices as required.
- 4 Click **Close**.

https://maxautoland.com/18939205725
 manski@cambid.com +86 18939205725

6.10 Checking device configuration

Following are the considerations for Checking device configuration.

- While the device has been assigned to a FFLink, this is still *offline* configuration of a matching physical device that is to be connected to this FFLink.
- Each device on the link must have a unique physical device tag (PD_TAG) that the Fieldbus system relates to a node address. The physical device tag, node address, and the manufacturer device identifier (DEV_ID) are used to match a configured device to a physical device.
- The preferred address range for Fieldbus devices is 20 to 40 decimal (0x14 to 0x28 hexadecimal). This provides the most optimized default network range where the first unused node address (FUN) is 41 decimal (0x29 hexadecimal) and the number of unused addresses is (NUN) is 206. We recommend that the Fieldbus device designated as the backup Link Master be given 21 decimal (0x15 hexadecimal) as its assigned address. All address number entries and displays are based on the decimal system in Control Builder, but the Fieldbus Foundation uses the hexadecimal system.
- The Device Identification field is blank until the Project device is matched to an uncommissioned device.
- The Physical Device Tag (PD_TAG) and Device State (DEVSTATE) parameters on the **Main** tab are unavailable, since they are only active in the **Monitoring** tab after the FIM4/FIM8/FFLINK/DEVICE is loaded and communicating with the system.
- In the Experion system, each independent component in the control strategy must have a unique tag name (NAME). This is automatically enforced through the Control Builder application. For this reason, the unique name that was assigned to the device when it was created in **Project** is also assigned as the device's physical device tag. This is done to assure that the names are unique within the system. This means a change in NAME results in an automatic change in PD_TAG to keep them the same. However, a change in PD_TAG does not result in an automatic change in the assigned NAME.
- Note that the name and physical device tag can be different. Since it is possible to change a physical device tag configuration using a handheld communicator, you **must** be sure the device name specified on device configuration form matches the device name configured in the device.
- We recommend that you do **not** change the default value settings for the active parameters on the **System Management** tab unless you are familiar with tuning the performance of Fieldbus links. In most cases, the parameter values will mirror those configured for the FFLink. The unavailable parameters are only accessible in the **Monitoring** tab with the FIM4/FIM8/FFLINK communicating with the system.
- If the form includes a **Block Instantiation** tab, this device supports instantiable blocks. Please see “Instantiable block implementation considerations” on page 117 in this book for more information.



Tip

You can simplify the retrieval of important diagnostic information from any Fieldbus device by configuring meaningful information in the *Description* field on the configuration form of all associated transducer and resource blocks in the **Project** tab. Operators can quickly trace any device-specific alarms to the applicable block through the device name and *description* that is displayed on the Alarm Summary in Station. This is especially useful for diagnosing problems in devices with several transducer blocks, like temperature multiplexers.

Prerequisites

You have assigned the device to a FFLink in the **Project** tab.

To configure a fieldbus device

- 1 Double-click the device icon in the **Project** tab. Calls up the parameter configuration dialog box with **Tag Name (Tag NAME)** box highlighted.
- 2 Accept the assigned name or key in a new one of up to 16 characters. Must be unique within the system.
- 3 Click the **Item Name (Item Name)** box. Key in the name of the Entity that this object will be associated with in the Enterprise Model Builder hierarchy.
- 4 Click the **Description** box. Key in desired description for the device consisting of up to 59 characters or leave it blank.

- 5 Click the **Device Network Node Address (ADDR)** box. Accept the default or key in the device's current address assignment.
- 6 Click the Continue button to the right of the **Associated Asset (ASSOCASSET)** box to call up the **Point Selection** dialog. Select an asset from those configured in the Enterprise Model Database to set the Scope of Responsibility (SOR) for the device/Fieldbus point.
(No validation is done at configuration time. If you enter an asset that does not exist in the points database, the associated asset for the Fieldbus point reverts to the server point. If the asset does exist but is not an area enabled asset, then the first area-enabled asset up the tree is used for the SOR of that Fieldbus device. A subsequent upload of that Fieldbus device point to Control Builder returns the area-enabled asset and not the original non-assignable asset entered.)
- 7 Click the **System Management** tab to display it.
- 8 Click the **Step Timer Preset (T1)** box. Accept the default value or key in a new value. This is the preset value for the System Management step timer. The default value is 15. 0000s.
- 9 Click the **Preset Set Addr Seq Timer (T2)** box. Accept the default value or key in a new value. This is the preset value for the System Management set address sequence timer. The default value is 01:30. 0000s.
- 10 Click the **Preset Set Addr Wait Timer (T3)** box. Accept the default value or key in a new value. This is the preset value for the SM set address wait timer. The default value is 45. 0000s.
- 11 Click the **Network Management (LM)** tab to display it. We recommend that you accept the default values for the parameters on this tab, and revisit this tab in the **Monitoring** mode, when the FIM4/FIM8/FLLINK is communicating with the system.
- 12 Refer to the *Control Building User's Guide* and/or the *online help* to complete configuration data on the **Server History**, **Server Display**, **Control Confirmation**, and **Identification** tabs. The **Network Management (Basic)** and **Version** tabs only contain read-only parameters.
- 13 Click **OK**.
- 14 Repeat this procedure for another device, as required.

https://maxautoland.com/18030203125
 manski@cambiala.cn +86 18030203125

6.11 Making fieldbus block template and assigning function block to device

Following are the considerations for making fieldbus block template and assigning function block to device

- The following procedure makes and assigns a Fieldbus analog input block template for example purposes only. You can easily adapt this procedure to apply to another Fieldbus Library block.
- When assigning a user template to a non-Honeywell Fieldbus device, warning messages may be generated because of *manufacturer specific parameters* associated with the device. Be sure that default values for manufacturer specific parameters are applicable for your given application.

Prerequisites

- You have created a Control Module in the **Project** tab.
- You have created a Fieldbus device and assigned it to a FIM4/FIM8 link in the **Project** tab.

To configure fieldbus block template

- 1 In **Project** mode, click **Library** tab, click + sign for **FIELDBUS** icon, and click **AI block** icon.
- 2 Click **Templates > Make Template** to call up AI Block configuration form.
- 3 On the **Process** tab, fill in configuration data in the appropriate boxes to configure the block for operation in your application using the *Control Building User's Guide and online Help for reference*.
- 4 Repeat Step 3 for the other tabs: **Alarm, Maintenance, Tune, Ranges, Identification, Block Pins, Configuration Parameters, Monitoring Parameters, Block Preferences, and Template Defining**, as applicable.
- 5 When configuration entries are completed, click **OK** to close the **AI Block** configuration form and add the configured AI block as a template under its assigned name in the **USER Library** on the **Library** tab.
- 6 In the **Project** tab, select and double-click an instantiated Control Module (CM) that is to contain the **AI** block template to open the CM in the control drawing of Control Builder. .
- 7 Drag and drop the **AI** block icon from the **USER Library** to the open Control Module in the control drawing to add the **AI** block to the CM.
- 8 Right-click the **AI** block in the open CM and select **Function Block Assign** from the list to open **Function Block Assignment Dialog** that lists all compatible device blocks that have been assigned to a FIM4/FIM8 Link. .
- 9 Click the check box to select the desired device. Click **Assign**.
 - If **Block Assignment Validation** dialog appears with warning message(s), Go to the next Step.
 - Otherwise, Go to Step 11.
- 10 Note the warning message and click **Continue**.
- 11 The **AI** block is assigned to the selected device as noted on the face of the block.
- 12 Click the close **X** button to close the CM. Click **Yes** to save the changes to the CM.

6.12 Configuring advanced alarming

Advanced alarming provides the ability to monitor the diagnostic parameters and generate the system alarms. The definition of the conditions, association between conditions and diagnostic parameters are user-defined. The condition configuration is configured in the Control Builder and saved in ERDB and loaded to FIM.

Note: Advanced alarming feature monitors device parameters on a slow schedule.

! Attention

- If advanced alarming and Field Diagnostics are configured for a device, then while loading the device, a message appears informing you to use either advanced alarming or Field Diagnostics and then proceed with the load operation.

Following are some of the considerations for configuring diagnostic parameters.

- You can generate alarms based on the conditions which are configured. These conditions are user-defined aggregations of device diagnostics that are individually generated in Experion.
- You can assign criticalities after the device specific conditions are created to generate the alarms.
- Each condition is loaded to the FIM and is associated with a unique diagnostic parameter to generate alarm. The alarm server similar to the existing system alarms tracks such alarms.
- Each condition has up to 5 parameter references that are used to select bits for alarm generation. Each reference selects one or more bits from the parameter.
- You can enable or disable each condition during the run time. When an active condition is disabled then it is removed from the alarm summary display.
- By default, all conditions are enabled when they are created.
- Based on the system performance, you can reconfigure the alarms to eliminate the conditions that cause redundant or unnecessary alarms to appear.
- Only the condition status can be modified from the device instance.
- You can define a maximum of 32 conditions per device and configure only five parameters per condition.
- For 32 conditions, parameter references must not exceed 36.
- You can configure only ten unique parameters per device template.

! Attention

- Fieldbus parameters used to generate Advanced Alarms must be periodically read from the device. This increases the utilization of unscheduled traffic bandwidth. Ensure to select only those parameters, which are to be monitored. Ensure that you select only those parameters that are to be monitored.

Group the bit strings which have similar meaning. For example, calibration conditions, temperature conditions, and so on.

Related topics

- “Opening the configuration dialog box” on page 83
- “Configuring/creating a condition” on page 84
- “Managing the conditions” on page 86
- “Enabling or disabling a condition” on page 86
- “Assigning criticalities and priorities” on page 88
- “Editing an existing condition” on page 88

6.12.1 Opening the configuration dialog box

The default configuration of an advanced alarming for a device template is performed in the configuration dialog box. Configuration of alarm conditions is limited to the device template in the template library.

Note:

- The configuration for a device type can be used by all instances of the same type of devices.
- You cannot invoke the Configuration dialog box from the List View.

For more information on creating a device template, see “Creating a fieldbus device type from vendor DD”.

To open the Configuration form from device template/device instance

- On the Field Devices menu, select Configure Advanced Alarming.
 - Or
 - In the Library mode, right-click on the device template to select Configure Advanced Alarming.
 - Or
 - Press Ctrl+Alt+A.


! Attention

- It is not possible to generate any default values for this configuration from the DD, as such; it is a Honeywell-specific function.
- You can invoke the Configuration dialog box in view only mode from the device instance.
- For more information to open the Configuration dialog box, see “Opening the configuration dialog box” on page 83.


6.12.2 Configuring/creating a condition

To configure a condition

- 1 From the **Configure Advanced Alarming Dialog**, click **Condition Listing** tab.



- 2 Click **New**.
The **Condition Configuration** dialog box appears.



- 4 Type the name for the condition in the **Condition**.

Attention

- The condition name must be unique.
- The condition name must be within the maximum limit of 32 characters.
- The condition name must contain alphanumeric characters. If the condition name contains only numeric or special characters, then an error message appears displaying the information to provide a valid name.
- An error message appears when you want to configure more than 32 conditions.
- Click **OK** to continue.

- 5 The default values for Alarm Criticality and Priority are **Failed** and **Urgent** respectively. From the **Alarm Criticality** tab, select the appropriate criticality for the condition.
- 6 From the **Priority** tab, select the appropriate priority for the condition.
- 7 From the **FF Conditions**, select the appropriate check box to choose the parameters. The selection of parameters is based on the Parameter Reference selection.

To select a parameter/multiple parameters for a condition:

- Select a parameter from the list and the list of available bits are seen.
- Select one or more bits from the list, the summary of all the selections for the condition appears as a tree view.

Attention

- It is highly recommended that you must select only a single parameter bit for each condition to easily identify the cause of the alarm that is generated and to identify the bit transition in the alarm and event summary.
- You must enter an appropriate condition name to reflect the failure mode of the selected bitstrings.
- You must select the appropriate bits from one or more device parameters.
- To clear the selected parameters/bits from the available list, clear the check box.
- Click **Clear** to clear all the selected options or clear the check box to clear the selected parameters/bits from the available list. An error message appears displaying the information to clear all the configuration information selected for the condition. Click **Yes** to continue.

8 Click Save.**Attention**

- While exporting/importing the device, the configured alarm conditions are also exported/imported automatically.

6.12.3 Managing the conditions

After you invoke the configuration dialog box, you can manage the conditions by creating, editing and deleting the conditions. In the **Criticality Mapping** tab, invoked from the Configuration dialog box, you can view the list of conditions assigned for a particular criticality. Therefore, you can manage the conditions created for each device.

6.12.4 Enabling or disabling a condition


You can disable an active alarm condition, which causes it to clear the corresponding alarm from the Alarm Summary. Similarly, enabling a condition, which consists of at least one data bit string, generates the corresponding alarm.

Attention

- By default, all the conditions are enabled in the **Configure Advanced Alarming** dialog box.
- When you enable/disable alarm conditions, the device instance updates the changes from the template as long as the alarm conditions are not manually changed directly on the device instance.
- When you enable/disable alarm conditions on the device instance, the device instance stops updating changes from the template. However, if you perform an 'Upload' and 'Update to Project' from the Monitoring view, and if the project instance matches the template, the device instance again starts updating changes from the template. Therefore, caution must be exercised when enabling/disabling alarm conditions on the device instance as the instance will start replicating the template.
- For example, consider a scenario where an engineer changes the value on the device instance (to have it different from the template). Coincidentally, the engineer sets the device instance value same as the template even though the intention was not to follow the template. In such a case, the device instance value changes when the value is changed in the template. However, the engineer would be assuming that the value what was set is retained on the device instance.

To enable/disable a condition


- 1 From the **Configure Advanced Alarming Dialog**, click **Condition Listing** tab.
- 2 Select the condition that you want to disable and clear the check box under the **Enable** column.
Or
Select the condition that you want to enable and select the check box under the **Enable** column.



The selected condition is disabled and the changed setting is saved in the database.

Attention

- The conditions can be enabled/disabled in the **Device Diagnostics** tab in the configuration form of FF devices from Project /Monitoring modes.



- To enable/disable a condition in Project mode, perform the following steps:
 1. Right-click the device instance to select **Module Properties**.
The configuration form appears.
 2. Click the **Device Diagnostics** tab.
 3. Under the **Alarm Conditions Status**, select or clear the check box to enable/disable the conditions.


6.12.5 Assigning criticalities and priorities

After defining the conditions, you can view the summary of all the criticality assignments.

You can assign criticality from the list. This attribute remains with the condition and appears on the alarm summary when the alarm is generated. The criticalities that are available are failure, Maintenance, Check function, and OffSpecification.

Note: You cannot change the criticality assignments in this view.


For example, when you select **Maintenance** criticality, the conditions, which are assigned to the same criticalities, are listed.



6.12.6 Editing an existing condition

To edit an existing condition

- 1 From the **Configure Advanced Alarming Dialog**, click **Condition Listing** tab.
- 2 Double-click a condition.
Or
Click a condition and Click **Edit**.
The **Condition Configuration** dialog box appears.



- 3 Perform through steps 4 to step 7 of the section “Configuring/creating a condition” on page 84.

! Attention

- You can delete an alarm condition, based on the required alarms to be generated.
- To delete a condition in the **Condition Listing** tab
 1. Select the condition to click **Delete**.
 2. Click **Yes** to confirm the deletion of the selected condition or press **DELETE** on the keyboard.

https://maxautoland.com/+86-1803205725
manski@cambi.cn

6.13 Block Offnet diagnostic alarm

Fieldbus function block can optionally be configured to generate a high-priority alarm, when the device containing the block is disconnected from the network. This is accomplished with the introduction of a new parameter OFFNETALM_ENABLED. When this parameter is set to 'True' and if the device is off the network, the Block Offnet Diagnostic Alarm is generated. If you set this parameter to 'False' when the Block Offnet Alarm is active, the alarm returns to normal. This parameter can be configured before load and can be changed at runtime, even if the device is offline.

! Attention

- When you load the fieldbus block, the value of the Enable Block Offnet Diagnostic Alarm parameter is written to the Fieldbus Interface Module if;
 - the partial load option is selected or cleared.
 - the physical device is online or offnet.
- It is not possible to load a CM containing a function block while the device is offnet.

6.13.1 Behavior of the Block Offnet and Device Offnet System alarms in various communication loss scenarios

The following table lists the behavior of the Block Offnet and Device Offnet System alarms in the various communication loss scenarios.

Communication loss scenario	Behavior of Block Offnet Alarm	Behavior of Device Offnet System Alarm
Loss of communication between C300 and FIM (This condition occurs if both the FTE cables are disconnected.)	Block Offnet Alarm is not reported for each loaded function block in the device.	Device Offnet System Alarm is not reported for the device.
Loss of communication between an FF device and FIM	A high-priority Block Offnet Alarm is reported for only those loaded function blocks in the device, which are configured to report the Block Offnet Alarm.	A high-priority Device Offnet System Alarm is reported for the device.
Communication resumes between an FF Device and FIM	Previously reported Block Offnet Alarms change from 'Active' to 'Returned to Normal' in the Alarm Summary Display.	The Device Offnet System Alarm changes from 'Active' to 'Returned to Normal' in the System Alarm Summary Display.

6.13.2 Behavior of the Block Offnet and Device Offnet System alarms in various operational scenarios

The following table lists the behavior of the Block Offnet and Device Offnet System alarms in the various operational scenarios. These behaviors are also dependent on whether the devices are online or off the network.

Scenario	Behavior of Block Offnet Alarm	Behavior of Device Offnet System Alarm
Inactivating a Fieldbus Link when the device is online.	A Block Offnet Alarm is not reported for each loaded function block.	A high-priority Device Offnet System Alarm is reported for the device.
Inactivating a Fieldbus Link when the device is off the network.	Previously reported Block Offnet Alarms changes from 'Active' to 'Disabled' in the Alarm Summary.	A high-priority Device Offnet System Alarm is reported for the device.

Scenario	Behavior of Block Offnet Alarm	Behavior of Device Offnet System Alarm
Activating a Fieldbus Link.	Previously reported Offnet Alarms changes to 'Disabled' when the Link is inactivated in the Alarm Summary. When activated, these alarms are regenerated to indicate the current condition of the alarm. If the Offnet condition does not exist, the previously reported alarms remain in the Alarm Summary as 'Disabled'.	Previously reported Offnet Alarms changes to 'Disabled' when the Link is inactivated in the Alarm Summary. When activated, these alarms are regenerated to indicate the current condition of the alarm. If the Offnet condition does not exist, the previously reported alarms remain in the Alarm Summary as 'Disabled'.
Activating or Inactivating a CM containing a FF function block.	Changing the EXECSTATE parameter value has no effect on the alarms reported by Fieldbus blocks.	Changing the EXECSTATE parameter value has no effect on the alarms reported by Fieldbus blocks.
Changing the state of a CEE containing a FF function block to 'Idle' or 'Run.'.	Changing the state of a CEE containing Control Modules, which contain Fieldbus blocks, has no effect on the alarms reported by the Fieldbus blocks.	Changing the state of a CEE containing Control Modules, which in turn contain Fieldbus blocks, has no effect on the alarms reported by the Fieldbus blocks.
Deleting a Device, Link, FIM or CM containing an FF function block	No alarms are reported for device offnet conditions.	No alarms are reported for device offnet conditions.
Enabling the reporting of the Block Offnet Diagnostic Alarm for an individual FF function block when the device is online. (The precondition is that the Block Offnet Diagnostic Alarm is configured not to be reported for the function block, when the device goes off the network.)	A change event is logged in the Event Summary indicating OFFNETALM_ENABLED is set to ON.	
Enabling the reporting of the Block Offnet Diagnostic Alarm for an individual FF function block when the device is off the network. (The precondition is that the Block Offnet Diagnostic Alarm is configured not to be reported for the function block, when the device goes off the network.)	A high-priority Block Offnet Alarm is reported for that function block. A change event is logged in the Event Summary indicating OFFNETALM_ENABLED is set to ON.	A high-priority Device Offnet System Alarm is reported for the device, when the device goes offnet. There is no change in the system alarm.
Disabling the reporting of the Block Offnet Diagnostic Alarm for an individual FF function block when the device is online.	A change event is logged in the Event Summary indicating OFFNETALM_ENABLED is set to OFF.	

Scenario	Behavior of Block Offnet Alarm	Behavior of Device Offnet System Alarm
Disabling the reporting of the Block Offnet Diagnostic Alarm for an individual FF function block when the device is off the network.	The previously reported Block Offnet Alarm for that function block changes from 'Active' to 'Disabled' in the Alarm Summary. A change event is logged in the Event Summary indicating OFFNETALM_ENABLED is set to OFF.	There is no change to the Device Offnet System Alarm.

! Attention

Block alarm disable settings are not retained during device replacement. Hence, you must manually update the block alarm disable setting configuration or reload the configuration from the ERDB.

*https://maxautoland.com/
manski@cambodia.cn +86 18030205725*

7 Series C FIM4/FIM8 configuration form reference

Related topics

- “FIM4/FIM8 device Diagnostics tab parameters” on page 94
- “FIM4/FIM8 Main tab parameters” on page 95
- “FIM4/FIM8 Redundancy tab parameters” on page 97
- “FIM4/FIM8 System Time tab parameters” on page 98
- “FIM4/FIM8 Statistics tab parameters” on page 99
- “FIM4/FIM8 Peer Connections tab parameters” on page 100
- “FIM4/FIM8 Hardware Information tab parameters” on page 101
- “FIM4/FIM8 FTE tab parameters” on page 102
- “FIM4/FIM8 UDP/TCP tab parameters” on page 104
- “FIM4/FIM8 IP/ICMP tab parameters” on page 106
- “FIM4/FIM8 QVCS tab parameters” on page 108
- “FIM4/FIM8 Server History tab parameters” on page 109
- “FIM4/FIM8 Server Displays tab parameters” on page 110
- “FIM4/FIM8 Control Confirmation tab parameters” on page 112
- “FIM4/FIM8 Identification tab parameters” on page 113

<https://maxautoblog.com/>
manski@cambria.com 18030205725

7.1 FIM4/FIM8 device Diagnostics tab parameters

Device Diagnostics tab is common to all configuration forms for tagged blocks in Control Builder. The following table summarizes the parameter data you can monitor and configure on this tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
Alarm Conditions Status	Alarm Conditions Status	Yes	To enable/disable the alarm conditions status.
Non-cache	Non-cache Parameters	Yes	The parameter's real time values are available from the devices and not from the FIM memory after configuring non-cache parameters in FIM.

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

7.2 FIM4/FIM8 Main tab parameters

The following table summarizes the parameter data you can monitor and/or configure on the **Main** tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
Tag Name	NAME	Project Only	System assigned or user configured unique name. Consisting of up to 16 characters and at least one character must be a letter (A-Z).
Item Name	Item Name	Project Only	A non-unique name by which an entity is known within the context of the enterprise model.
Application Image Version	IMAGEVER	No	Identifies current version of firmware installed in module.
Controller Command	FIMCOMMAND	Monitoring Only	Allows user to initiate commands to a Series C FIM4/FIM8.
Device Index	DEVICEIDX	Project Only - Matches Hardware Setting	Unique FTE device index of the Series C FIM4/FIM8. Set on Series C FIM4/FIM8 IOTA switches.
Ethernet IP Address	IPADDRESS	No	IP address of the Series C FIM4/FIM8, derived as the Embedded FTE Base Ethernet IP Address plus configured Device Index.
Temperature High Alarm (deg C)	OVERTEMPHLD	Yes	Set threshold value for modules Temperature High alarm.
CPU Free Low Alarm (%)	CPULOLM	Yes	Set CPU Free Low Capacity alarm limit, in percent.
CPU Free Low Low Alarm (%)	CPULOLOLM	No	Set CPU Free Low Low Capacity alarm limit, in percent.
Controller State	FIMSTATE	No	Shows Series C FIM4//FIM8 current state.
Redundancy Role	RDNROLESTATE	No	Shows Series C FIM4/FIM8 current redundancy role.
Synchronization State	RDNSYNCSTATE	No	Shows Series C FIM4/FIM8 current synchronization state.
Module is redundant	MODISREDUN	Project Only	Module is part of redundant pair.
Secondary Tag Name	SECMODNAME	Project Only	System assigned name based on tag name with sec suffix for secondary block.
Suppress H1 Power Alarm	NOPWRDIAG	Yes	Suppresses H1 Link Power Diagnostic alarms. This option should be selected if integrated power alarming functionality is not to be used.
Enable Safe Handling of New Devices	SAFEHANDLINGENABLED	Yes	Enables safe handling of new uncommissioned field devices. Devices previously loaded are not safe handled when rejoining the link. See “Using optional safe handling of new devices” on page 137 for more information

Plain Text	Parameter Name	User Configurable	Notes
Device Drop Off Alarm Delay	DEVDRPOFFDELAY	Yes	Sets the amount of time, in seconds, a device must be offnet before Device Offnet and Block Offnet Diagnostic Alarms are generated.

<https://maxautoland.com/>
 manski@cambodia.cn +86 18030205725

7.3 FIM4/FIM8 Redundancy tab parameters

The following table summarizes the parameter data you can monitor on the **Redundancy** tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
<i>Redundancy Status</i>			
Auto Synchronization State	RDNAUTOSYNC	No	Shows current auto synchronization state
Redundancy Compatibility	RDNCMPT	No	Shows redundant partner compatibility
Inhibit Sync Reason	RDNINHIBITSYNC	No	Shows reason that redundancy synchronization is inhibited
Initial Sync. Progress (%)	RDNSYNCPROG	No	Shows current synchronization progress in percent
Last Synchronization Time	SYNCTIMEBEG	No	Shows system time when initial synchronization was completed.
Last Loss of Sync. Time	SYNCTIMEEND	No	Shows system time when last synchronization was lost.
Redundancy Controllability	RDNCTLABILITY	No	
<i>Redundancy Statistics</i>			
Redundancy Traffic (bytes/sec)	RDNXFERAVG	No	
Max Redun. Traffic (bytes/sec)	RDNXFERMAX	No	
Redundancy Delay (%)	RDNDELAYAVG	No	
Max Redundancy Delay (%)	RDNDELAYMAX	No	
Max Initial Sync Time (sec)	RDNINSTIMEMAX	No	
Max Switchover Time (msec)	RDNSQTIMEMAX	No	
Disable Synchronization	DSBLSYNCCMD	No	Button to initiate command in Monitoring mode
Alternate Sync. Over FTE	ALTSYNCCMD	No	Button to initiate command in Monitoring mode.
Become Primary	BECMPRICMD	No	Button to initiate command in Monitoring mode.
Enable Synchronization	ENBLSYNCCMD	No	Button to initiate command in Monitoring mode.
Initiate Switchover	SWITCHCMD	No	Button to initiate command in Monitoring mode.
<i>Redundancy History</i>			
Time	RDNHISTTIME	No	Show time of related state.
State	RDNHISTSTATE	No	List the last 16 redundancy related activities.
Reason	RDNHISTREASON	No	Identify reason for redundant history state
Redundancy Link Failed	RDNLINKFAILED	No	Status indicator to signal link failure

7.4 FIM4/FIM8 System Time tab parameters

The following table summarizes the parameter data you can monitor on the **System Time** tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
<i>System Time</i>			
Current System Time	CURTIME	No	Shows current system time.
Current System Time Source	TIMESOURCE	No	Shows source of system time. Default is Simple Network Time Protocol.
<i>SNTP Status</i>			
SNTP Status	SNTPSTAT	No	Shows status for time source.
SNTP Skew Limit (msec)	SNTPSKEWTHLD	No	
SNTP Skew Limit Exceeded	NUMSNTPSKEWEX	No	Shows number times SNTP knew threshold was exceeded.
Max. SNTP Skew (msec)	MAXSNTPSKEW	No	Shows maximum skew recorded.
<i>System Time Synchronization Status</i>			
Time Synchronization Status	TIMESYNCSTAT	No	
Time of Last Time Sync	TIMELASTSYNC	No	Shows time Controller Time Synced with time source
Skew at Last Time Sync (msec)	TIMELASTSKEW	No	Shows time skew from last synced time.

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205723

7.5 FIM4/FIM8 Statistics tab parameters

The following table summarizes the parameter data you can monitor on the **Statistics** tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
Reset All Statistics	STATSRESET	No	Button to initiate reset in Monitoring mode.
<i>CPU Utilization</i>			
CPU Free (%)	CPUFREEAVG	No	
Minimum CPU Free (%)	CPUFREEMIN	No	
Notification Statistics			
Notification Rate	TNUMNTRQUAVG	No	
Maximum Notifications Rate	TNUMNTRQUMAX	No	
Hardware Temperature			
Current Temperature (deg C)	CTEMP	No	
Maximum Temperature (deg C)	CMASTEMP	No	
Maximum Temperature (deg C)	CMINTEMP	No	

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

7.6 FIM4/FIM8 Peer Connections tab parameters

The following table summarizes the parameter data you can monitor on the **Peer Connections** tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
Peer Initiator Connections			
Initiating to ACEs	TNUMACEINCON	No	
Initiating to C300s	TNUMC3INCON	No	
Initiating to C200s	TNUMCPMINCON	No	
Initiating to FIM4/FIM8	TNUMSCFIMINCON	No	
Initiating to SIM-C200s	TNUMSCEINCON	No	
Initiating to LIOMs	TNUMLIOMINCON	No	
Peer Responding Connections			
Responding to ACEs	TNUMACEOUTCON	No	
Responding to C300s	TNUMC3OUTCON	No	
Responding to C200s	TNUMCPMOUTCON	No	
Responding to FIM4/FIM8	TNUMSCFMOUTCON	No	
Responding to SIM-C200s	TNUMSCEOUTCON	No	
Responding to LIOMs	TNUMLIOMOUTCON	No	

<https://maxautoland.com/>
 manski@cambodia.ch +86 18030205725

7.7 FIM4/FIM8 Hardware Information tab parameters

The following table summarizes the parameter data you can monitor on the **Hardware Information** tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
Firmware Version			
Boot Image Version	BOOTIMAGEVER	No	
Application Image Version	IMAGEVER_D	No	
Hardware Factory Information			
Module Type	MODTYPE	No	
Serial Number	SERIALNUM	No	
Programmable Logic Set Version	FWREVISION	No	
Hardware Major Revision	HWREVMAJ	No	
Hardware Minor Revision	HWREVMIN	No	
Network Interface Address Information			
FTE Interface A MAC Address	MACADDRA	No	
FTE Interface B MAC Address	MACADDRB	No	
Redun. Interface MAC Address	MACADDRR	No	

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

7.8 FIM4/FIM8 FTE tab parameters

The following table summarizes the parameter data you can monitor on the **FTE** tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
<i>FTE Mart Statistics</i> (Provides statistics related to the MAC Address Resolution Table (MART). This deals with on-line media access control (MAC) address mapping. Two separate tables are maintained - One for FTE nodes and one for non-FTE nodes. The media access control address entry information is obtained by extracting the source media access control address from received diagnostic messages.)			
Address Count	FTEMARTADDRCOUNT	No	Number of IP addresses contained in FTE MART.
Max Depth	FTEMARTMAXDEPTH	No	Maximum depth that the FTE MART has reached (largest number of entries in table).
Average Depth	FTEMARTAVGDEPTH	No	Average depth of FTE MART (average number of entries in table).
Address Collisions	FTEMARTCOLLCOUNT	No	Number of collisions that have occurred when hashing the FTE MART.
<i>Current FTE Traffic</i>			
LAN_A Tx Rate (kBit/sec)	LANATXRATE	No	Indicates communication transmission rate in kilobits per second (kbps) for port A (Yellow Tree Port) on the FTE Bridge.
LAN_B Tx Rate (kBit/sec)	LANBTXRATE	No	Indicates communication transmission rate in kilobits per second (kbps) for port B (Green Tree Port) on the FTE Bridge.
LAN_A Rx Rate (kBit/sec)	LANARXRATE	No	Indicates communication receive rate in kilobits per second (kbps) for port A (Yellow Tree Port) on the FTE Bridge.
LAN_B Rx Rate (kBit/sec)	LANBRXRATE	No	Indicates communication receive rate in kilobits per second (kbps) for port B (Green Tree Port) on the FTE Bridge.
FTM Statistics			
Number of FTE nodes	NUMFTENODES	No	Current number of FTE nodes within FTE community.
Max number of FTE nodes	MAXFTENODES	No	Maximum number of FTE nodes that have been detected within FTE community.
Max node ID	MAXNODEID	No	Highest Device Index supported within FTE community.
IP checksum errors	BADIPCSUM	No	Number of FTE IP messages which were received but determined as having bad IP checksums.
UDP checksum errors	BADUDPCSUM	No	Number of FTE UDP messages which were received but determined as having bad UDP checksums.

Plain Text	Parameter Name	User Configurable	Notes
Non-FTE Mart Statistics			
Address Count	NONFTEMARTADDRCOUNT	No	Number of IP addresses contained in non-FTE MART.
Max Depth	NONFTEMARTMAXDEPTH	No	Maximum depth that non-FTE MART has reached (largest number of entries in table).
Average Depth	NONFTEMARTAVGDEPTH	No	Average depth of non-FTE MART (average number of entries in table).
Address Collisions	NONFTEMARTCOLLCOUNT	No	Number of collisions that have occurred when hashing non-FTE MART.
<i>Peak FTE Traffic</i>			
LAN_A Tx Rate Max (kBit/sec)	LANATXRATEMAX	No	Indicates maximum communication transmission rate in kilobits per second (kbps) for port A (Yellow Tree Port) on the FTE Bridge.
LAN_B Tx Rate Max (kBit/sec)	LANBTRATEMAX	No	Indicates maximum communication transmission rate in kilobits per second (kbps) for port B (Green Tree Port) on the FTE Bridge.
LAN_A Rx Rate Max (kBit/sec)	LANARXRATEMAX	No	Indicates maximum communication receive rate in kilobits per second (kbps) for port A (Yellow Tree Port) on the FTE Bridge.
LAN_B Rx Rate Max (kBit/sec)	LANBRXRATEMAX	No	Indicates maximum communication receive rate in kilobits per second (kbps) for port B (Green Tree Port) on the FTE Bridge.
Number of FTE Nodes	NUMFTENODES	No	
Max Number of FTE Nodes	MAXFTENODES	No	
Max Device Index	MAXNODEID	No	
IP Checksum Errors	BADIPCSUM	No	
UDP Checksum Errors	BADUDPCSUM	No	
LAN_A (Yellow) failed	LANAFAILED	No	Status indicator for port A (Yellow Tree Port) on the FTE Bridge. If this LED is lit, it is an indication that communications have failed on Port A.
LAN_B (Green) failed	LANBFAILED	No	Status indicator for port B (Green Tree Port) on the FTE Bridge. If this LED is illuminated it is an indication that communications have failed on Port B.
InterLAN comm. failed	INTERLANFAILED	No	Status indicator for Inter-LAN communications - indicates that inter-LAN communications have failed.
Crossover cable failed	XOVERFAILED	No	Status indicator for Crossover cable - indicates that the Crossover cable has failed.

7.9 FIM4/FIM8 UDP/TCP tab parameters

The following table summarizes the parameter data you can monitor on the FTE tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
<i>UDP Statistics (Provides unreliable connectionless packet delivery service between clients.)</i>			
Datagrams Delivered	UDPINDGRAMS	No	Total number of User Datagram Protocol (UDP) datagrams delivered to destination protocol ports.
Datagrams for Unknown Ports	UDPNOPORTS	No	Total number of received UDP datagrams for which there was no application at the destination port.
Datagrams Dropped for errors	UDPINERRORS	No	Number of received UDP datagrams that could not be delivered.
Datagrams Sent to Applications	UDPOUTDGRAMS	No	Total number of UDP datagrams sent from this entity.
<i>TCP Statistics (Provides reliable stream delivery service between clients.)</i>			
Active Opens	TCPACTIVEOPEN	No	Number of times TCP connections have made a direct transition to the SYN-SENT state from the CLOSED state.
Passive Opens	TCPPASSIVEOPENS	No	Number of times TCP connections have made a direct transition to the SYN-RCVD state from the LISTEN state.
Failed Connection Attempts	TCPATTEMPTFAILS	No	Number of times TCP connections have made a direct transition to CLOSED state from either SYN-SENT state or SYN-RCVD state, plus number of times TCP connections have made a direct transition to LISTEN state from SYN-RCVD state.
Connections Resets	TCPSTABRESETS	No	Number of times TCP connections have made a direct transition to CLOSED state from either ESTABLISHED state or CLOSE-WAIT state.
Current Connections	TCPCURRESTAB	No	Number of TCP connections for which current state is either ESTABLISHED or CLOSE-WAIT.
Segments Received	TCPINSEGS	No	Total number of segments received, including those received in error.
Segments Sent	TCPOUTSEGS	No	Total number of segments sent, including those on current connections but excluding those containing only retransmitted octets.
Segments Retransmitted	TCPRETRANSSEGS	No	Total number of segments retransmitted - that is, number of TCP segments transmitted containing one or more previously transmitted octets.

Plain Text	Parameter Name	User Configurable	Notes
Segments Discarded For Errors	TCPINERRS	No	Total number of segments received in error (for example, bad TCP checksums).
Reset Segments Sent	TCPOUTRESETS	No	Number of TCP segments sent containing the RST flag.
Local UDP Listeners	<PJ>UDPLISTENERS</PJ>	No	Shows path information for all open ports on the FTE Bridge module.
Current TCP Connections	<PJ>TCPCONNTABLE</PJ>	No	Shows path information for all currently connected clients of the FTE Bridge module.

<https://maxautoland.com/>
 manski@cambiala.cn +86 18030205725

7.10 FIM4/FIM8 IP/ICMP tab parameters

The following table summarizes the parameter data you can monitor on the IP/ICMP tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
<i>IP Statistics (Provides packet delivery services between nodes.)</i>			
Datagrams Received from Below.	IPINRECEIVES	No	Total number of input datagrams received from connected nodes, including those received in error.
Datagrams Format Errors Drops	IPINHDRERRORS	No	Number of input datagrams discarded due to errors in their Internet Protocol (IP) headers, including bad checksums, version number mismatch, other format errors, time-to-live exceeded, errors discovered in processing their IP options, etc.
Datagrams Misdelivery Drops	IPINADDRERRORS	No	Number of input datagrams discarded because the IP address in their IP header's destination field was not a valid address to be received at this entity.
Unknown Protocol Datagrams	IPINUNKNOWNPORTS	No	Number of locally-addressed datagrams received successfully but discarded because of an unknown or unsupported protocol.
Datagrams Discarded for Resrcs	IPINDISCARDS	No	Number of input IP datagrams for which no problems were encountered to prevent their continued processing, but which were discarded; for example, for lack of buffer space.
Datagrams Delivered Above	IPINDELIVERS	No	Total number of input datagrams successfully delivered to IP user-protocols, including Internet Control Message Protocol (ICMP).
Datagrams Sent Out	IPOUTREQUESTS	No	Total number of IP datagrams which local IP user-protocols (including ICMP) supplied to IP in requests for transmission.
Out Datagrams Discarded	IPOUTDISCARDS	No	Number of output IP datagrams for which no problem was encountered to prevent their transmission to their destination, but which were discarded; for example, for lack of buffer space.
Datagrams Drops for No Routes	IPOUTNOROUTES	No	Number of IP datagrams discarded because no route could be found to transmit them to their destination.
Fragments Needing Reassembly	IPREASSEMREQS	No	Number of IP fragments received which needed to be reassembled at this entity.
Fragments Reassembled	IPREASSEMOKS	No	Number of IP datagrams successfully reassembled.

Plain Text	Parameter Name	User Configurable	Notes
Fragments Reassembly Fails	IPREASSMFAILS	No	Number of failures detected by the IP reassembly algorithm, for whatever reason: timed out, errors, etc.
Datagrams Fragmented	IPFRAGOKS	No	Number of IP datagrams that have been successfully fragmented at this entity.
Datagrams Fragmentation Fails	IPFRAGFAILS	No	Number of IP datagrams that have been discarded because they needed to be fragmented at this entity but could not be. For example, because their do not Fragment flag was set.
Fragments Created	IPFRAGCREATES	No	Number of IP datagram fragments that have been generated as a result of fragmentation at this entity.
Routing Entries Discarded	IPROUTINGDISCARDS	No	Number of routing entries which were chosen to be discarded even though they are valid.
<i>ICMP Statistics (Controls transmission of error and control messages between hosts and gateways.)</i>			
Messages Received	ICMPINMSGS	No	Total number of ICMP messages which the entity received.
Messages with Format Errors	ICMPINERRORS	No	Number of ICMP messages which entity received but determined as having ICMP-specific errors such as bad ICMP checksums and bad length.
Dest. Unreachable Msgs Recvd	ICMPINDESTUNREACHS	No	Number of ICMP Destination Unreachable messages received.
Echo Messages Recvd	ICMPINECHQS	No	Number of ICMP Echo (request) messages received.
Echo Reply Messages Recvd	ICMPINECHOREPS	No	Number of ICMP Echo Reply messages received.
Messages Sent	ICMPOUTMSGS	No	Total number of ICMP messages which this entity attempted to send.
Out Error Messages	ICMPOUTERRORS	No	Number of ICMP messages which this entity did not send due to problems discovered within ICMP such as a lack of buffers.
Dest. Unreachable Msgs Sent	ICMPOUTDESTUNREACHS	No	Number of ICMP Destination Unreachable messages sent.
Echo Messages Sent	ICMPOUTECHOS	No	Number of ICMP Echo (request) messages sent.
Echo Reply Messages Sent	ICMPOUTECHOREPS	No	Number of ICMP Echo Reply messages sent.

7.11 FIM4/FIM8 QVCS tab parameters

The **QVCS** tab is common to all configuration forms for tagged blocks in Control Builder. If you have a Qualification and Version Control System (QVCS) license, this tab shows current QVCS information for the selected FIM4/FIM8 block. Please refer to the online help and the Qualification and Version Control System User's Guide for more information about the data on this tab.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

7.12 FIM4/FIM8 Server History tab parameters

The **Server History** tab is common to all configuration forms for tagged blocks in Control Builder. The following table summarizes the parameter data you can monitor and configure on this tab of the configuration form for the selected FIM4//FIM8 block.

Attention

- The configuration settings you make for Server Load Options on the **System Preferences** dialog determines whether or not the data entered on the **Server History** tab is loaded to the Experion server. See the *Control Building User's Guide* for information about setting system preferences.

Plain Text	Parameter Name	User Configurable	Notes
<i>Access Levels</i>			
Control Level	SCANCTRLVL	Yes	Indicates Server control level to be associated with this function.
<i>History Configuration</i>			
Number of History Parameters	HIST.NUMPARAMS	Yes	Defines number of history parameters to be included in History Configuration table.
Parameter	HIST.PARAM	Yes	Valid parameter name for a parameter associated with the given point that is to be collected and stored as historical data at predetermined intervals.
Description		No	Provides a brief description of the entered parameter.
FAST	HIST.FAST	Yes	Select the Fast type of history collection.
STD	HIST.STD	Yes	Select the Standard type of history collection.
EXTD	HIST.EXTD	Yes	Select the Extended type of history collection.
EXC	HIST.EXC	Yes (Station only)	Select the Exception type of history collection.
Gating Parameter	HIST.GATEPARAM	Yes	Optional gating parameter to define conditions under which data for this parameter should be collected.
Gate State	HIST.GATEPARAM	Yes	Defines gate state for configured gating parameter.
Create New or Edit Existing Server Scripts (Button)		N/A	Launch the Server scripting configuration utility.

7.13 FIM4/FIM8 Server Displays tab parameters

The **Server Displays** tab is common to all configuration forms for tagged blocks in Control Builder. The following table summarizes the parameter data you can monitor and configure on this tab of the configuration form for the selected FIM4/FIM8 block.

Attention

- The configuration settings you make for Server Load Options on the **System Preferences** dialog determines whether or not the data entered on the **Server Displays** tab is loaded to the Experion server. See the *Control Building User's Guide* for information about setting system preferences.

Plain Text	Parameter Name	User Configurable	Notes
Point Detail Display	SCANPNTDTL	Yes	By default, a Display template is already entered into Point Detail Display box (for example, sysDtlFTEB.dsp). This template can be used for creating your own display or it can be used as is, provided that your function block name matches name built into detail display that is supplied as a template.
Group Detail Display	SCANGRPDTL	Yes	By default, a Display template is already entered into the Group Detail Display box (for example, sysGrpFTEB.dsp). This template can be used for creating your own display or it can be used as is, provided that your function block name matches name built into detail display that is supplied as a template.
Associated Display	SCANASSOCDSP	Yes	Name of the Server display to be associated with this function block.
<i>Trends</i>			
Number of Trends	TREND.NUMPARAMS	Yes	Defines the number of trend parameters to be included in the Trends Configuration table.
Trend #		Yes	Defines Trend number to be associated with this trend parameter.
Pen		Yes	Defines color of pen that will be used to trace assigned parameter on Station Trend display.
Trend Parameter		Yes	Valid parameter name for a parameter associated with given point that is configured for history collection.
Description		No	Provides a brief description of the entered parameter.
<i>Groups</i>			
Number of Groups	GROUP.NUMPARAMS	Yes	Defines the number of group parameters to be included in Groups Configuration table.
Group #	GROUP.NUMBER	Yes	Defines Group number to be associated with this group parameter.

Plain Text	Parameter Name	User Configurable	Notes
Pos #	GROUP.POSITION	Yes	Defines number of position configured parameter will occupy in the Station Group display.
Group Parameter	GROUP.PARAM	Yes	Valid parameter name for a parameter associated with the given point that is configured in the system.
Description		No	Provides a brief description of the entered parameter.

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

7.14 FIM4/FIM8 Control Confirmation tab parameters

The **Control Confirmation** tab is common to all configuration forms for tagged blocks in Control Builder. If you have an optional Electronic Signature license, you can configure electronic signature information for the tagged block through this tab on the block's configuration form in Control Builder. Please refer to the online help and the *Server and Client Configuration Guide* for information about the data on this tab.

The Electronic Signature function aligns with the identical Electronic Signatures function that is initiated through Quick Builder and Station for Server points. When this block is loaded to a controller, its control confirmation configuration (electronic signatures) is also loaded to the Server. This means you can view the control confirmation configuration for this tagged object in Station and make changes to it. If you make changes through Station, you must initiate an **Upload** or **Upload with Contents** function through the **Controller** menu in Control Builder for the object in the **Monitoring** tab to synchronize changes in the Engineering Repository Database (ERDB).

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

7.15 FIM4/FIM8 Identification tab parameters

The **Identification** tab is common to all configuration forms for tagged blocks in Control Builder. The following table summarizes the parameter data you can monitor and configure on this tab of the configuration form for the selected FIM4/FIM8 block.

Plain Text	Parameter Name	User Configurable	Notes
Name	NAME	Yes	Unique block name consisting of up to 16 characters to identify the block. At least one character in the name must be a letter (A-Z).
Description	DESC	Yes	Descriptive text appears on detail and group displays to uniquely describe this particular function block
Block Comment 1	BLCKCOMMENT1	Yes	Comment to be associated with this block consisting of up to 40 characters.
Block Comment 2	BLCKCOMMENT2	Yes	Comment to be associated with this block consisting of up to 40 characters.
Block Comment 3	BLCKCOMMENT3	Yes	Comment to be associated with this block consisting of up to 40 characters.
Block Comment 4	BLCKCOMMENT4	Yes	Comment to be associated with this block consisting of up to 40 characters.
Library		No	Identifies Control Builder Library that is source of template.
System Template		No	Identifies System Template that is source for this block.
Base Template		No	Identifies Base Template that is used for this block.
Created By	CREATEDBY	No	Identifies user who created block, if operator security is implemented. Otherwise, may just show Default login.
Date Created	DATECREATED	No	Shows date and time template was created. If this block is in Version Control System, shows date and time initial version of template was created.
Last Modified By	MODIFIEDBY	No	Identifies user who made last modifications to block, if operator security is implemented. Otherwise, may just show default login. If this block is in Version Control System, modifications apply to last version of block.
Date Last Modified	VERSIONDATE	No	Shows date and time last modification was made to block's configuration. If this block is in Version Control System, modification date and time applies to last version of block.

<https://maxautoland.com/>
manski@cambodia.ch +86 18030205725

8 Block instantiation support

In addition to the permanent or fixed function blocks that manufacturer's define for their **Foundation** Fieldbus (FF) devices, they can define optional instantiable function blocks. This gives users the ability to instantiate (create) additional function blocks within the Function Block Application Process for the given Fieldbus device. The Fieldbus Foundation refers to this function as Block Instantiation and they include it in their Host Interoperability Support Test (HIST).

Please refer to the *Fieldbus Technology Overview* section for more information about Standard Function Blocks in general.

This section includes the following topics on information related to block instantiation support in Control Builder.

Related topics

“Control Builder supports block instantiation” on page 116

“Instantiable block implementation considerations” on page 117

<https://maxautoland.com/>
manski@cambia.cn +86 18030205725

8.1 Control Builder supports block instantiation

! Attention

- The Type function in Control Builder only supports Block Instantiation in Fieldbus devices with single Capability Levels. It does not support Fieldbus devices with multiple Capability Levels.

The **Type** function in Control Builder supports the functions associated with instantiable blocks in Fieldbus devices with single capability levels. It lets you build block types for devices that support block instantiation that include both the fixed function blocks and the instantiable function blocks. This means you can view the instantiable blocks as part of the device's block hierarchy in the **Library** tab of Control Builder. The icon for an instantiable function block has a slash across it and a letter **I_** tag prefix as illustrated below, so you can easily distinguish it from a fixed function block




Figure 13: Typical icon for Instantiable block in Fieldbus device.

! Attention

- A manufacturer may choose to define Transducer blocks as **instantiable** instead of fixed. In this case, be sure you **instantiate** a Transducer block for each physical sensor that is to be used in the device. A Transducer block usually corresponds to a physical sensor in the vendor's device.

8.2 Instantiable block implementation considerations

The following topics review considerations that are unique to implementing control strategies that include Fieldbus devices with optional instantiated blocks. Please use these considerations to supplement the appropriate procedures in other parts of this document that are tailored to Fieldbus devices with only fixed function blocks including resource and transducer blocks.

Attention

- When you perform upload/update to Project for FF block instantiable parameters, the parameters will not be updated to the Project view.

Related topics

- “Adding instantiable block to device in Project tab” on page 117
- “Checking instantiated block configuration in Project tab” on page 118
- “Making optional instantiated block resource usage check” on page 119
- “Adding instantiated block to CM” on page 120
- “Loading Project device to physical device” on page 121
- “Deleting (de-instantiate) instantiated block from Project tab” on page 121
- “Deleting (de-instantiate) instantiated block from physical device” on page 122
- “Replacing failed device that includes instantiable blocks with like device” on page 122

8.2.1 Adding instantiable block to device in Project tab

Following are the considerations for adding instantiable block to device in Project tab

- Devices created in **Project** tab automatically include only their **fixed** function blocks, transducer blocks, and resource blocks. If the device block type includes **instantiable** blocks, you **must** add the instantiable block from the block type in the **Library** tab to the device icon in the **Project** tab to instantiate (create) it in the device in **Project**.
- Default name of instantiated block may be appended with a letter. For example, a block with default name I_AI becomes I_AIA.
- Device does not have to be connected to the link to instantiate a block.
- An error message is generated, if device cannot support an additional block.

Prerequisites

- You have logged onto Control Builder with sufficient security privileges to make changes in control strategies.
- You have created a device type that includes instantiable blocks.

To add instantiable block to device in Project tab

- See Adding a Fieldbus Device to Project for reference.
- Open corresponding manufacturer's device hierarchy in the **Library** tab.
- Drag the instantiable block onto the applicable device icon in the **Project** tab.
- Key in desired name for the block or accept the default in the open **Name New Function Block(s)** dialog.
- Click **Finish** to close the dialog and add the block to the device hierarchy in **Project**, as shown in the following illustration.




Figure 14: Instantiated block added to device in Project tab.

8.2.2 Checking instantiated block configuration in Project tab

Following are the considerations for checking instantiated block configuration in Project tab

- The **Instantiation** tab only appears if the device supports Block Instantiation.
- See “Checking device configuration” on page 80 for reference.

Prerequisites

You have completed the previous procedure.

To check instantiated block configuration in Project tab

- 1 In the **Project** tab, right-click applicable device instantiable block and select **Block Properties** from list to open the form.
- 2 Click **Block Instantiation** tab.
- 3 Check **Block Template Type** column for list of instantiated blocks in device.
- 4 Check **Block Tag** column to view assigned tag to see if block is used in a Control Module or not as shown in the following illustration.
- 5 Click **OK** to close the form.




Figure 15: Block Instantiation tab for instantiable block included with device in Project tab.

8.2.3 Making optional instantiated block resource usage check

Following are the considerations for making optional instantiated block resource usage check

- Some vendors provide resource information as an option. You can use this information to determine if the configured block contents will fit within the available resources of the device.
- A resource represents a finite entity used by a device such as Central Processing Unit (CPU) or Memory.

To make optional instantiated block resource usage check

- 1 In the **Project** tab, right-click applicable device instantiable block and select **Block Properties** from list to open the form.
- 2 Click **Block Instantiation** tab.
- 3 Check **Resource #** column for the amount of resource used by a particular block. The # (1, 2, ...) columns can vary depending on vendor and function block type.
- 4 In **Resource Statistics** grid, check **Limit** and **Used** columns to view resource allocations against assigned limits, as shown in the following illustration.
- 5 Click **OK** to close the form




Figure 16: Block Instantiation tab with optional resource information.

8.2.4 Adding instantiated block to CM

Following are the considerations for adding instantiated block to CM.

- You add instantiated blocks to a Control Module the same way you do fixed blocks. They also are configured in the same way and have the same graphical appearance as shown in the following figure.






Figure 17: Typical graphical representation of instantiated block in Control Builder.

- See the Control Building User's Guide for reference.

To add instantiated block to CM

- 1 In **Project** tab, double-click the icon for the Control Module that is to contain a Fieldbus block in its strategy to open the CM in the control chart drawing area.
- 2 In **Project** tab, click the  plus sign for the FIM4/FIM8, the FFLINK, and the contained device to expand the directories down to the device block level.
- 3 Drag the applicable instantiated block to the open CM.
- 4 Double-click the instantiated block to open its configuration form and configure the block, as desired.
- 5 Click the close  button on the CM and click **Yes** to save the changes and close the CM.

**CAUTION**

A physical device may go offline while its instantiable blocks are being instantiated through a device load.

8.2.5 Loading Project device to physical device

Following are the considerations for loading Project device to physical device.

- Block instantiation in a physical device only occurs during a load.
- Be sure you load a device from **Project** before you load a Control Module that contains instantiable blocks. If you load a Control Module that contains instantiable block(s) before the associated device in **Project** is loaded and its blocks instantiated, the Control Module load will fail.
- The existing load order, FIM4/FIM8/FFLink load, and device match functions also apply for devices with instantiable blocks.
- Device load from **Project** synchronizes the contents of the **Project** device with the physical device and instantiates applicable instantiable blocks in the physical device.
- You must load the Control Module(s) containing fixed and/or instantiated blocks associated with the device for the fixed and instantiated blocks to appear in the device hierarchy in **Monitoring** tab.
- After loading a device from **Project** or **Monitoring** tab, the physical device function block contents matches that of the corresponding Project or Monitoring device. This means necessary blocks will be instantiated and unnecessary Blocks will be removed or de-instantiated.

To load Project device to physical device

- 1 See “Load order guidelines” on page 128 for reference.
- 2 See “Loading a Series C FIM4/FIM8 and its links” on page 134 for reference.
- 3 See “Matching uncommissioned device to Project device or vice versa” on page 135 for reference.
- 4 Right-click device icon and select **Load** from list.
- 5 Review information on **Load** dialog for load details and any warning messages identifying pre-load considerations.
- 6 Click **OK** to initiate the load and monitor **Load Progress** dialog for load related activities.
- 7 Upon successful device load, open device icon in **Monitoring** tab to view block hierarchy. Only transducer and resource blocks appear in the device hierarchy after an initial load.
- 8 Right-click device icon and select **Upload** from the list. Click **Continue** to load device data into the Monitor database.

8.2.6 Deleting (de-instantiate) instantiated block from Project tab**Prerequisites**

- You cannot delete an Instantiable block from **Project**, if it is loaded and viewable in the **Monitoring** tab. See the next section to delete an instantiated block for a physical device.

- You cannot delete an instantiated block that is contained in a Control Module unless you un-assign or delete the block from the CM first.

To delete (de-instantiate) instantiated block from Project tab

- 1 In **Project** tab, click the + plus sign for the FIM4/FIM8, the FFLINK, and the contained device to expand the directories down to the device block level.
- 2 Right-click applicable instantiated block icon in the hierarchy and select **Delete** from the list.
- 3 Click **Continue** to initiate action and track progress in **Delete** dialog.
- 4 Upon successful deletion the instantiated block icon is removed from the device hierarchy.

8.2.7 Deleting (de-instantiate) instantiated block from physical device

Following are the considerations for deleting (de-instantiate) instantiated block from physical device

- Deleting a block from **Monitoring** tab, does not de-instantiate a block in a device. Only a load of a device will achieve this
- You must re-load **Project** device to re-synchronize contents with physical device after any control strategy changes or physical device maintenance that may alter contents in either device.

Prerequisites

You cannot delete an instantiated block directly from a physical device.

To delete (de-instantiate) instantiated block from physical device

- 1 In the **Monitoring** tab, locate the CM that contains the instantiated block that is to be deleted and delete the CM.
- 2 In the **Project** tab, unassign or delete the instantiated block from the CM that was deleted in the **Monitoring** tab, and then delete the block from the device in **Project**, as noted in the previous procedure. Make any control strategy changes, as required.
- 3 Load device from **Project** to re-synchronize contents with physical device.
- 4 Load device from **Project** to re-synchronize contents with physical device.
- 5 Load reconfigured CM.
- 6 Right-click device icon and select **Upload** from the list. Click **Continue** to load device data into the **Monitoring** database.

8.2.8 Replacing failed device that includes instantiable blocks with like device

Following are the considerations for Replacing failed device that includes instantiable blocks with like device

- A device replacement can cause changes in a device's block layout, since the Object Dictionary (OD) index for an instantiated block can change.
- If connections to instantiable blocks of the **replaced** field device are through SCM expressions, such an SCM will not be automatically shown as a part of the Load List under the device in the **Load Dialog**. This means that the SCM will not be automatically loaded. In this case, you must inactivate the SCM and reload it as a separate procedure.
- If a Control Module (CM) or a Sequential Control Module (SCM) has connections to **contained** Fieldbus parameters, they will appear as a part of the Load List under the device in the **Load Dialog** and will be automatically loaded. See the **Load Dialog** example in the following illustration. However, special consideration must be given to inactive Sequential Control Modules.

Prerequisites

- See “Replacing a failed device with a like device having the same model name and device revision” on page 226 for general replacement procedure.




Figure 18: Typical Load Dialog for Fieldbus device.

<https://maxautoland.com/>
manski@cambodia.cn +86 18030205725

9 Loading FIM4/FIM8 components online

The Experion system provides the ability to build control strategies offline, without being connected to the actual field components. The process of transferring the Control Strategy to the 'live' working components in the field is called the load operation. This section includes the following topics on information and tasks associated with loading FIM4/FIM8 components through Control Builder.

Topic
“About load operations” on page 126
“About load dialog” on page 127
“Load order guidelines” on page 128
“General load considerations” on page 130
“About fieldbus device states” on page 131
“Fieldbus device matching rules” on page 132
“Identifying load interactions for fieldbus-related operations” on page 133
“Loading a Series C FIM4/FIM8 and its links” on page 134
“Matching uncommissioned device to Project device or vice versa” on page 135
“Using optional safe handling of new devices” on page 137

Related topics

- “About load operations” on page 126
- “About load dialog” on page 127
- “Load order guidelines” on page 128
- “General load considerations” on page 130
- “About fieldbus device states” on page 131
- “Fieldbus device matching rules” on page 132
- “Identifying load interactions for fieldbus-related operations” on page 133
- “Loading a Series C FIM4/FIM8 and its links” on page 134
- “Matching uncommissioned device to Project device or vice versa” on page 135
- “Using optional safe handling of new devices” on page 137
- “Loading FFLink contents or fieldbus device” on page 138

9.1 About load operations

The load operation functionally copies configuration data from the control strategy that is stored in the Engineering Repository Database (ERDB) to the assigned field component in the system architecture. The load operation has been expanded to include Fieldbus components. It indirectly assures that the planned system matches the actual one. The communication addresses and physical location assignments specified for components through Control Builder configuration must match the actual addresses and locations of components in the system. The following illustration shows a simplified graphical representation of what happens during a load operation.




Figure 19: Overview of load operations used to initiate FIM4 components online.

9.2 About load dialog

The following figure shows a sample Load Dialog invoked for a load with contents operation for a Series C FIM. It provides a brief description of the dialog features for quick reference.



CAUTION

The load operation is still an offline function. The **Load Dialog** provides the ability to automatically inactivate a component during a load and then return the component to its active state. Do **not** use this automatic inactivate/activate function, if your process **cannot** tolerate the load disruption and consequent delay in activation. In this case, you must manually toggle the component state through the **Monitoring** tab in Control Builder.

The screenshot shows the 'Load Dialog' window with a table of components and their states. Annotations point to various features:

- Lists components to be loaded:** Points to the 'Load' column checkboxes.
- Chance to select partial load, if applicable:** Points to the 'Partial Load' column checkboxes.
- Shows current state of component:** Points to the 'Current State' column.
- Specifies state component must be in during load:** Points to the 'State To Load' column.
- Specifies state component will assume after load is completed:** Points to the 'Post Load State' column.
- Individual checkboxes let you edit list of components to be loaded:** Points to the 'Load' column checkboxes.
- Shaded area flags components in Active State:** Points to the shaded rows in the table.
- Can select another state from dropdown menu for this field:** Points to a dropdown menu in the 'Post Load State' column.
- Select whether or not component is to be automatically put into Inactive/Out-Of-Service state for the load:** Points to the checkbox 'Automatically change ALL highlighted control elements to INACTIVE/OUT_OF_SERVICE before load'.
- Select whether or not component is to be automatically put into selected Post Load State after the load:** Points to the checkbox 'Automatically change ALL control elements to the state selected in "Post Load State" after load is completed'.
- Components in Active state are flagged:** Points to the warning icon and message 'Some control elements currently in INACTIVE/IN-SERVICE state!'.

Load	Load List	Partial Load	Current State	State To Load	Post Load State
<input checked="" type="checkbox"/>	FIM105		CEERUN	N/A	N/A
	LINK10105		ONLINE	N/A	N/A
	LINK20105		ONLINE	N/A	N/A
<input checked="" type="checkbox"/>	ST101		N/A	N/A	N/A
	pidloop/FFAI101	<input checked="" type="checkbox"/>	OOS	NORMAL	NORMAL
	ST101 RESOURCE	<input checked="" type="checkbox"/>	OOS	NORMAL	NORMAL
	ST101 TRANSDUCER	<input checked="" type="checkbox"/>	OOS	NORMAL	NORMAL
<input checked="" type="checkbox"/>	ST102		Not Loaded	N/A	N/A
	ST102 RESOURCE	<input checked="" type="checkbox"/>	Not Loaded	OOS	NORMAL
	ST102 TRANSDUCER	<input checked="" type="checkbox"/>	Not Loaded	OOS	NORMAL

Figure 20: Load Dialog provides more load choices.

<https://maxautoland.com/>
 manski@cam.ac.uk +86 1803020512

9.3 Load order guidelines

Load control strategy components from the **Project** tab in the following order to avoid possible load interaction generated error messages.

Order	Component	Typical Loaded Icon in Monitoring Tab
1	C300/CEEC300*	<p>C300_133 CEEC300_134 IOLINK_135 IOLINK_136</p>
2	FIM4 /FFLINK	<p>FIM4_150 FFLINK_151 FFLINK_152 FFLINK_153 FFLINK_154</p>
3	FIM8 /FFLINK	<p>FIM8_143 FFLINK_144 FFLINK_145 FFLINK_146 FFLINK_147 FFLINK_148 FFLINK_149 FFLINK_150 FFLINK_151</p>
4	Check for Uncommissioned Fieldbus devices and initiate match function, as applicable	<p>FIM4_150 FFLINK_151 ST101 ST104</p>
5	Fieldbus Device	<p>ST101</p>
6	IOM*	<p>I/O AO101</p>
7	CM or SCM*	<p>pidloop</p>

*Please refer to the *Control Building User's Guide* for more information about loading these components.

<https://maxautoland.com/>
manski@cambodia.cn +86 18030205725

9.4 General load considerations

The following are some general load considerations to keep in mind, when you are loading Fieldbus components. In most cases, the Load Dialog box will quickly guide you through the load operations and will alert you to potential load problems.

If you are loading . . .	Then, consider this . . .
A FIM4/FIM8.	Be sure ALIV does not appear in the LED display on the front of the FIM4/FIM8. If it does, you must first load the FIM4/FIM8 personality firmware using the Series C hardware firmware tool (Ctool) utility supplied with Experion Engineering Tools.
A CM that contains only Fieldbus function blocks.	We recommend that CMs containing only Fieldbus function blocks be assigned and loaded to the appropriate FIM4/FIM8 LINK. They will only take up unnecessary memory and execution time in the CEE. .
A CM that contains both Experion and Fieldbus function blocks.	Be sure CMs that contain Experion function blocks are assigned and loaded to a CEE. Control Builder enforces this.
A Fieldbus device.	Be sure the device configuration in Project tab has the proper PD_TAG specified. While you can load a device to the FFLink from Project , you cannot load and commission a device until it is connected to the link and its PD_TAG and address agree with those specified in Project . Please see the next two sections <i>Fieldbus device states</i> and <i>Fieldbus device matching rules</i> for more information.

https://maxautol and.com/180300525
 manski@cambid.com +86 180300525

9.5 About fieldbus device states

A Fieldbus device is unaware of the steps being executed to configure a network. Its System Management Kernel (SMK) does sense the completeness of its configuration to determine what services it can provide. The following table shows the three major states a SMK in a field device must go through and the associated services for each state before a device can fully function on the network.

SMK State	System Management Services
Unitialized	<ul style="list-style-type: none"> • SM_IDENTIFY • SET_PD_TAG (Clear = False)
Initialized	<ul style="list-style-type: none"> • SM_IDENTIFY • SET_ADDRESS • SET_PD_TAG (Clear = True)
Operational	<ul style="list-style-type: none"> • SM_IDENTIFY • CLEAR_ADDRES • FIND_TAG_QUERY • FIND_TAG_REPLY • FB_START • SMIB_Access

In the **uninitialized** state, a Fieldbus device has neither a physical device tag nor a node address assigned by a master configuration device. The only access to the device is through system management, which permits identifying the device and configuring the device with a physical device tag.

In the **initialized** state, a Fieldbus device has a valid physical device tag, but no node address has been assigned. The device is ready to be attached to the network at a default system management node address. Only system management services for assigning a node address, clearing the physical device tag, and identifying the device are available.

In the **operational** state, a Fieldbus device has both a physical device tag and an assigned node address. Its application layer protocols are started to allow applications to communicate across the network. Additional network management configuration and application configuration may be needed for the device to become operational.

<https://mayautotronics.com/18930203125>
 manski@cambria.cn

9.6 Fieldbus device matching rules

The Series C FIM initiates the following matching rules depending upon whether or not the device identification (DEV_ID) is specified, when a device is loaded from Control Builder.

If the Device ID is . . .	And, the Device State is . . .	Then, the matching rule is . . .
Specified.	Uninitialized	The device ID (DEV_ID) must match. If the desired physical device tag (PD_TAG) and node address (ADDR) are available, FIM4/FIM8 will assign them to the device.
	Initialized	The device ID (DEV_ID) and physical device tag (PD_TAG) must match. If the desired address is not in use, FIM4/FIM8 will assign it to the device.
	Operational	The device ID (DEV_ID), physical device tag (PD_TAG), and node address (ADDR) must match those specified through configuration in Control Builder. Any mismatch results in an error.
Not specified.	Initialized	The physical device tag (PD_TAG) must match. If the desired node address (ADDR) is not in use, FIM4/FIM8 will assign it to the device.
	Operational	The physical device tag (PD_TAG) and node address (ADDR) must match those specified through Control Builder. Any mismatch results in an error.

<https://maxautol.com/>
 manski@cambid.com +86 1803029275

9.7 Identifying load interactions for fieldbus-related operations

The following table provides a matrix of load interactions for given Fieldbus related operations.

! Attention

If you make on-line changes to parameter values in Fieldbus devices, the changed values are not written to the **Monitoring** or **Project** copy of the control strategy. You must initiate an **Upload** function to write the new values to **Monitoring** followed by an **Update to Project** function to write the **Monitoring** values to the **Project** copy.

Operation	Build Link Schedules	Load Schedule into FIM4/FIM8s Link	Load LM Schedules into LM-Capable Devices	Load Used Function Blocks	State Required for Operation
Load Device <i>or</i> Replace Device	No	No	This device only, if LM-capable	Yes	Blocks in device = OOS, Device = OOS, FFLink = Active
Delete Device from Loaded	No	No	No	No	Blocks in device = OOS, Device = OOS, FFLink=Active
Load FFLink with Contents	Yes	Yes	All LM-capable	Yes	Blocks in related CMs = OOS, Device = OOS, FFLink = N/A
Load FFLink (without contents)	No	Yes	No	No	FFLink = N/A
Load CM (from Project)	Yes	Yes	All LM-capable	Yes	Blocks in CM = OOS CM = Inactive, FFLink = Active, Device = N/A
Load CM (from Monitor)	No	No	No	Yes	Blocks in CM = OOS CM=Inactive, FFLink=Active, Device=N/A
Delete CM from Loaded	Yes	Yes	All LM-capable	No	Blocks in CM = OOS CM=Inactive, FFLink=Active, Device=N/A

9.8 Loading a Series C FIM4/FIM8 and its links

Following are the considerations for loading a Series C FIM4/FIM8 and its links

- If **ALIV** appears in the Series C FIM's 4-character, alphanumeric display, you must load the Series C FIM's personality firmware before proceeding.
- The associated Series C FIM Links are included with a FIM4/FIM8 load even if the selected action is **Load** instead of **Load with Contents**. We suggest just loading the FIM4/FIM8 without all of its contents first to be sure communications paths are working.

Prerequisites

All Series C FIM components are installed and capable of communicating with the system.

To initiate FIM4/FIM8 load

- 1 Click the FIM4/FIM8 block icon in the **Project** tab. On the **Controller** menu, click **Load** to call up the Load dialog.
- 2 Be sure a check mark appears in the check box for the FIM4/FIM8 listed in the **Load** Column? Click **OK** to initiate the load.
- 3 Track load status in the **Load Progress** dialog box that appears.
- 4 When load is completed, click the **Monitoring** tab to open it.
- 5 Confirm that the FIM4/FIM8 icon now appears in the **Monitoring** tab. Click + plus sign for FIM4/FIM8 icon to open the directory and expose the FFLINK icons.

<https://maxautoland.com/>
+86 18030205125
manski@cambid.com.cn

9.9 Matching uncommissioned device to Project device or vice versa

Following are the considerations for matching uncommissioned device to Project device or vice versa

- It is best to match devices before you download the Fieldbus device from **Project** to the FFLink.
- On the H1 network, if you install a device with an address below 20 (hexadecimal 14), the FIM4/FIM8 will clear the device's address. The device returns to the link at a temporary address and may be reassigned as needed.
- If you install a **Link Master** class device on the H1 network, the FIM4/FIM8 performs the following actions to protect the network from an unconfigured or incorrectly configured device disturbing or becoming the **Link Master** of the segment.
 - **Clears** the link schedule,
 - **Clears** the primary link master flag variable,
 - **Sets** the configured link settings,
 - **Sets** the device class to basic, and
 - **Restarts** the device.
- Refer to *Using Optional Safe Handling of New Devices* section for more information about adding an uncommissioned to a loaded Fieldbus link with the optional safe handling function enabled.
- If the device template and capability level of an uncommissioned device and a Project device are same, then you can match the device.

Prerequisites

- You have installed H1 link segments to provide proper power and conditioning for Fieldbus devices.
- You have completed the previous procedure to load the FIM4/FIM8 and its links.

To match an uncommissioned device to a Project device or vice versa

- 1 On the Monitoring view, confirm that the applicable FFLink icon is active (green).
 - If the FFLink is active (green icon), go to Step 4.
 - If the FFLink is inactive (blue icon), go to Step 2.
- 2 Click the applicable FFLink icon and then click **Toggle State** icon to toggle the state. The **Change State** dialog box appears.
- 3 Click **Yes** to initiate FFLink startup. The FFLink appears as active (green icon).
- 4 On the Project view, click the FIM4/FIM8 block and the FFLink that has uncommissioned device template.
- 5 On the **Field Devices** menu, click **Device Match**. The **FFLink Parameters** form appears with the **Device Match Dialog** tab selected.
- 6 Check for the block type matches between listed **Uncommissioned Devices** and **Project Devices** in the **Template** column and the **Capability Level** column.

Note:

- If the **Template** column and the **Capability Level** column match, then **Match from Uncommissioned Device to Project Device** and **Match from Project Device to Uncommissioned Device** are enabled.
- In the **Capability Level** column, the capability level of the device is displayed based on the Capability Level parameter in the DD file.

 **Attention**

- If the Capability Level parameter is not available at the device level, it displays as zero. Therefore, you have to manually enter the capability level of the device.
 - Ensure to type the correct capability level of the device. If the value is incorrect, then commissioning errors appear and template or device replacement must be performed to correct the error.
 - If you want to change the tag name or address for the devices that are listed under **Uncommissioned Devices** or **Project Devices**, then perform the following:
 1. In the **Tag** or **Address** column, double-click and type the required values.
 2. Press **ENTER**.

A confirmation message appears before initiating the change in the tag and address in the **Uncommissioned Device to match the Project Device.**
 3. Click **Continue**.
 - If an uncommissioned device is previously configured through a hand-held communicator or third-party configuration to contain correct tag and address data, click **Match from Uncommissioned Device to Project Device** to preserve the **Uncommissioned Device** information and change the **Project Device** information.
 - If an uncommissioned device contains factory default data, then click **Match from Project Device to Uncommissioned Device** to retain the **Project Device** information and change the **Uncommissioned Device** information.
-
- 7 Select the devices to **Match from Uncommissioned Device to Project Device** or to **Match from Project Device to Uncommissioned Device**.

<https://maxautoland.com/>
manski@cambodia.cn +86 18030205725

9.10 Using optional safe handling of new devices

Related topics

“About safe handling option” on page 137

“Enabling and disabling safe handling” on page 137

“Safe handling and previously commissioned devices” on page 137

“Removing power during a safe handling operation” on page 137

9.10.1 About safe handling option

If you enable the safe handling option for the Series C FIM through its configuration form in Control Builder, the following actions are automatically initiated when you add a new device to a loaded Fieldbus link.

- Clears any existing VCRs configured in the device.
- Clears any existing link schedule.
- Clears the primary link master flag on the device.
- Sets the link settings in the device to the current link settings of the segment.

If required, changes the device to a basic one and restarts the device.

9.10.2 Enabling and disabling safe handling

You enable and disable the safe handling option through the **Safe Handling of New Devices Enabled** check box on the **Main** tab of the FIM4/FIM8 Block's configuration form in Control Builder. The default is selected or checked check box, which means safe handling is enabled.

9.10.3 Safe handling and previously commissioned devices

The safe handling option does not apply when removing and adding a previously commissioned device to the Fieldbus link. However, if you remove a commissioned device from one link and add it to another link, the device is treated as an uncommissioned device and the safe handling option applies. If this same device is later moved back to its original link, it will appear as an uncommissioned device and will require a reload.

9.10.4 Removing power during a safe handling operation

The safe handling operation can take up to 30 seconds to complete after adding a new device to a link. If you remove a device while the safe handling operation is in progress, it may have its configuration partially cleared.

Moving a commissioned device to another link and then back to its original link after only 1 to 20 seconds has expired, may leave the device in a half safe handled state. If the FBAP VCR was cleared, the FIM4/FIM8 and Control Builder may not be able to talk to the device. If this occurs, Fieldbus blocks will appear gray on the **Monitoring** tab. In this case, you will need to delete and reload the device or remove the device from the link and put it back on another link for at least 30 seconds to allow the safe handling operation to complete.

To avoid partial safe device handling, do **not** move previously commissioned devices to other links in the system too quickly.

9.11 Loading FFLink contents or fieldbus device

Following are the considerations for Loading FFLink contents or fieldbus device

- It is a good idea to load the Fieldbus device before you load the Control Modules containing its associated function blocks to the CEE or FIM4/FIM8. If you load the Control Module first, you may get an error message indicating that the parent block is not available.
- If you just want to load a given Fieldbus device, click the device icon and click **Controller > Load**. We suggest using **FFLINK/Load With Contents** so you can load more than one device at a time.
- A **Partial Load** selection means that the *contained* or internal block parameters will not be loaded to the device, which reduces the overall load time. It is generally not necessary to load these types of parameters, since no connections are made to them.
- If errors are detected during the load, they will be listed and you will be prompted to select whether or not you want to continue the load with errors. It is a good idea to note the errors and abort the load (close), so you can go back and correct the errors before completing the load.
- The device's resource and transducer blocks are dedicated to the device and loaded with the device, and can be viewed in the device directory in the **Monitoring** tab. The device's other function blocks will not appear in its directory until the Control Module containing them is loaded to the CEE or FIM4/FIM8, as applicable.

Prerequisites

You have completed the previous procedures to load the FIM4/FIM8 and match Project and Uncommissioned devices.



CAUTION

If the load generates errors identifying **sub schedule** problems, you must reconfigure the Link Master capable device to become a **Basic** one through **Control Builder**, and restart the device to initiate the change. Otherwise, if the Series C FIM fails, the potential for a 'no schedule' condition exists. Since the schedule is cleared from the Link Master capable device upon the detection of sub schedule load errors, it cannot function as the backup LAS without a schedule.

Please see the "Checking/changing fieldbus device functional class" on page 171 section for details on reconfiguring a device as a **Basic** type.

To initiate a device load

- 1 In the **Project** tab, click the desired FFLINK icon. In the **Controller** menu, click **Load With Contents** to open the **Load Dialog**.
- 2 Confirm that checks appear in the **FFLINK** and **Device** check boxes listed in the **Load?** column. If you do not want to load a given device, just click it to remove the check from its check box.
- 3 Accept the default **Partial Load** check box selections for the Resource and Transducer blocks for a device.
- 4 To change the **Post Load State** for selected components, click the appropriate **Post Load State** row and select another state from the list.
- 5 Click the check boxes to inactivate the Fieldbus devices automatically for the load and to return Fieldbus devices automatically to post load state after the load.
- 6 Click **OK** to Initiate the *Load* and open **Load Dialog** to show load progress.
- 7 Once the load is complete, click the **Monitoring** tab to open it.
- 8 Confirm that blocks now appear in given device hierarchy.
- 9 Repeat Steps 1 to 8 to load another FFLink or device, as required.

10 Fieldbus device commissioning

This section outlines a typical process to follow to commission a Fieldbus loop in an Experion system. This section does not provide detailed procedures for each stage in the process. Please reference appropriate sections in this document or applicable vendor documentation for detailed information, if required.

The following table lists the topics included in this section. If you are viewing this information online, just click the topic title to jump to the information location.

Topic
“Getting started” on page 140
“Connecting devices” on page 143
“Checking device” on page 145
“Checking control strategy” on page 146
“Flowchart summary” on page 147

Related topics

- [“Getting started” on page 140](#)
- [“Connecting devices” on page 143](#)
- [“Checking device” on page 145](#)
- [“Checking control strategy” on page 146](#)
- [“Flowchart summary” on page 147](#)

https://mexautoland.com/
manski@cambiocn +86 18030205725

10.1 Getting started

10.1.1 Read this first

The Series C Fieldbus Interface Module (FIM4/FIM8) sets many parameters within a Fieldbus device during its initial setup and commissioning in an Experion system. While you can change some parameters, such as calibration ones, when the device is being operated on a workbench or at a location apart from the system, you must **not** change certain other parameters. The following table outlines the functions you must consider before commissioning a device.

For This Function. . .	Consider This . . .
<i>Link Settings</i>	<p>These parameters can affect whether or not a device can communicate with other devices on the link, or whether it communicates efficiently and can recover properly from errors. They must not be changed, by another host device.</p> <p>If the Experion system notices that these parameters have been changed after a device has been off the network, the Series C FIM takes the following action:</p> <ol style="list-style-type: none"> 1. Changes the parameters back. 2. De-commission the device (assuming other parameters have been changed also). 3. Change a Link-Master-capable device to a Basic device. <p>To recover, the (now uncommissioned) device must be changed back to a Link-Master device, if desired, and re-loaded from the Project or Monitoring tab in Control Builder.</p>
<i>Link Schedule</i>	<p>The Link Schedule controls the publication schedule, if no Series C FIM is available on the link. If the device was moved from another link or to another host and was loaded with a different schedule, the link schedule is not the current schedule version number for this link. In this case, the Series C FIM will take the following action.</p> <ol style="list-style-type: none"> 1. De-commission the device. 2. Change a Link Master capable device to a Basic device. <p>To recover, the (now uncommissioned) device must be changed back to a Link-Master device, if desired, and re-loaded from the Project or Monitoring tab in Control Builder.</p>
<i>Virtual Communication Relationships (VCRs)</i>	<p>The Virtual Communication Relationships (VCRs) are communication connections that are established for a given link. They should not be re-configured on another link or by another Host. Otherwise, they will very likely not be configured correctly and could interfere with communications when the device is restored to the desired link. When the Series C FIM first encounters a new uncommissioned device, it will clear its VCRs.</p>
<i>Link-Master Capable</i>	<p>A Link-Master-Capable device can take over control of a link. When Series C FIM first encounters a new uncommissioned device, it checks to see if it is configured as a Link-Master capable device and re-configures it as a Basic device. (When the device is commissioned, it can be changed back to Link-Master capable, since it will be loaded with the correct backup link schedule.)</p>

For This Function. . .	Consider This . . .
<i>Binding of Fieldbus Devices to the Experion database</i>	<p>The three most important identification parameters for a Fieldbus device are its:</p> <ul style="list-style-type: none"> • Device_ID, • PD_Tag, and • Link Address. <p>The Device_ID is required by Fieldbus Foundation specifications to be device-unique and unchangeable. But, if either the Physical Device Tag (PD_Tag) or the Link Address is changed while the device is off the network, the device is de-commissioned and will have to be re-commissioned when it is returned to the link.</p> <p>If a device is removed from the link and another device is placed on the link at the same address (second device will have different Device_ID and possibly different PD_Tag), the original device will appear de-commissioned upon return to the link.</p> <p>To recover, the (now uncommissioned) device must be re-commissioned or matched again to its device object and then re-loaded.</p>
<i>Number of Fieldbus Device parameters to receive periodic (sustained) stores</i>	<p>Sustained stores are intended for parameters such as FF_VAL, RCAS_IN, TRK_IN_D, and TRK_VAL. Sustained stores should not be used on static parameters or parameters stored in non-volatile memory on a device, such as SP. Performing sustained stores to static or non-volatile parameters may lead to a shortened lifetime for the EPROM or flash memory in a device. Each Fieldbus device will behave differently, so it is best to consult the device manual for information on sustained store limitations.</p>

10.1.2 Initial checks and operations

Stage	Function	Completed
1	<p>Check and test all physical wire connections and verify correct voltage on H1 segment.</p> <p><i>References:</i></p> <p>“Selecting and calculating Fieldbus wiring requirements” on page 27</p>	
2	<p>Load FIM4/FIM8 block only.</p> <p><i>References:</i></p> <p>“Adding FIM4/FIM8 block to project” on page 64</p> <p>“Loading a Series C FIM4/FIM8 and its links” on page 134</p>	
3	<p>Was FIM4/FIM8 download successful?</p> <p>NO > Go to Stage 4</p> <p>YES > Go to Stage 7</p>	
4	<p>Is IOTA and Series C FIM powered?</p> <p>NO > Go to Stage 5</p> <p>YES > Go to Stage 6</p>	
5	<p>Be sure required voltage is present at the power supply and it is turned On.</p> <p>Replace power supply, if required.</p> <p>Return to Stage 2.</p>	
6	<p>Verify network connections.</p> <p>Replace Series C FIM, if required.</p> <p>Return to Stage 2.</p>	
7	<p>Measure and establish H1 segment baseline with Fluke Scopemeter and Relcom FTB-3 or equivalent equipment.</p>	

Stage	Function	Completed
	Go to Stage 8 in the next section <i>Connecting Devices</i> .	

<https://maxautoland.com/>
manski@cambodia.ch +86 18030205725

10.2 Connecting devices

Stage	Function	Completed
8	Connect the next device. <i>References:</i> “Fieldbus network wiring and installation references” on page 21	
9	Does device appear on link? NO > Go to Stage 10 YES > Go to Stage 23 in the next section <i>Checking Devices</i> .	
10	Be sure cable is connected to proper segment terminals on IOTA. <i>References:</i>	
11	Connect Relcom Tester and/or Fluke Scopemeter to Link's cable.	
12	Is voltage over 9 volts? NO > Go to Stage 13 YES > Go to Stage 14	
13	Test the power supply, check that terminators are Installed properly and check for short circuits. Return to Stage 9	
14	Does proper number of devices appear on tester? NO > Go to Stage 16 YES > Go to Stage 15	
15	Check that proper FFLink is downloaded and that device is connected to proper link. <i>References:</i> “Loading a Series C FIM4/FIM8 and its links” on page 134 Return to Stage 9	
16	Are noise average and peak under 75 millivolts? NO > Go to Stage 17 YES > Go to Stage 18	
17	Check the integrity of all cable connections, cables and verify the design of the link. Return to Stage 9	
18	Is lowest signal level over 150 millivolts? NO > Go to Stage 19 YES > Go to Stage 20	
19	Insufficient power for device. Check power supply and link design. Return to Stage 9	
20	Is there an addressing issue? NO > Go to Stage 21 YES > Go to Stage 22	
21	Device should be present. Replace the device. Return to Stage 9	

Stage	Function	Completed
22	Check if address is in unpolled range, check for too many devices with temporary address. <i>References:</i> “Tags, Addresses, and Live List Reference” on page 307 Return to Stage 9	

<https://maxautoland.com/>
manski@cambiala.cn +86 18030205725

10.3 Checking device

Stage	Function	Completed
23	Does firmware - DD Revision match device revision? NO > Go to Stage 24 Yes > Go to Stage 25	
24	Upgrade firmware or import new DD file <i>References:</i> “Upgrading Series C FIM4/FIM8 firmware” on page 56 “Creating a fieldbus device type from vendor DD”	
25	Match device. <i>References:</i> Matching Uncommissioned Device to Project Device or Vice Versa	
26	Load (Partial Load) the new device from Project tab. <i>References:</i> “Using optional safe handling of new devices” on page 137	
27	Measure and compare H1 segment baseline with Fluke Scopemeter and Relcom FTB-3 or equivalent equipment.	
28	Are measurements within specifications? NO > Go to Stage 29 YES > Go to Stage 30	
29	Identify source of noise or communication problems and repair or replace equipment as required. Return to Stage 27	
30	Do you need to add more devices on this segment? NO > Go to Stage 31 in the next section <i>Checking Control Strategy</i> . YES > Return to Stage 8 in previous section <i>Connecting Devices</i> .	

https://www.autoland.com/ +86 18030205725
manski@camoia.cn


10.4 Checking control strategy

Stage	Function	Completed
31	Is control strategy configured? NO > Go to Stage 32 Yes > Go to Stage 33	
32	Configure control strategy. <i>References:</i> “Series C FIM4/FIM8 configuration” on page 61	
33	Load control strategy to device. <i>References:</i> About load operations	
34	Are parameters correct? NO > Go to Stage 35 YES > Go to Stage 36	
35	Make required parameter changes on-line to device.	
36	Upload device to project. <i>References:</i> Identifying Load Interactions for Fieldbus Related Operations	


<https://maxautol.com/>
manski@cambid.com +86 18030205725

10.5 Flowchart summary

The commissioning stages outlined above are summarized in the following flowchart.



<https://maxautol.com/>
 +86 18030205725
 manski@cambia.cn



<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205115

11 Series C FIM4/FIM8 redundancy functionality

This section provides information about using a redundant Series C FIM pair. The following table lists the topics included in this section. If you are viewing this information online, just click the topic title to jump to the information location.

Topic
“Redundant Series C FIM4/FIM8 overview” on page 150
“Switchover and secondary readiness” on page 151
“Switchover behavior considerations” on page 152
“Failure conditions and switchover” on page 153
“Fieldbus network switchover considerations” on page 154
“Switchover versus fieldbus network activities” on page 155
“Switchover events” on page 156

Related topics

- [“Redundant Series C FIM4/FIM8 overview” on page 150](#)
- [“Switchover and secondary readiness” on page 151](#)
- [“Switchover behavior considerations” on page 152](#)
- [“Failure conditions and switchover” on page 153](#)
- [“Fieldbus network switchover considerations” on page 154](#)
- [“Switchover versus fieldbus network activities” on page 155](#)
- [“Switchover events” on page 156](#)

11.1 Redundant Series C FIM4/FIM8 overview

If you have a Series C FIM (FIM4/FIM8) redundant Input/Output Termination Assembly (IOTA), you can implement redundant Series C FIM4/FIM8 operation through a redundant Series C FIM4/FIM8 pair. The following figure shows a typical hardware configuration for a redundant Series C FIM4/FIM8 pair that includes a C300 Controller. You do not need the C300 Controller to support Series C FIM redundancy.




Figure 21: Redundant Series C FIM Pair With Redundant C300 Controller.

This is considered a dual redundant system, which is characterized by the following two main redundancy states.

- Primary - Refers to the Series C FIM executing the assigned control functions.
- Secondary (or Backup) - Refers to the Series C FIM in some state of readiness to assume the responsibilities of the Primary.

11.2 Switchover and secondary readiness

A switchover describes the process where a Secondary Series C FIM assumes the Primary state, and the Primary Series C FIM assumes the appropriate Secondary state of readiness, depending upon what triggered the switchover. A switchover can be triggered immediately upon the detection of a fault in the Primary or upon the receipt of an operator command.

The ability of a Secondary Series C FIM to take over the assigned control functions of the Primary depends upon which one of the following readiness states reflects its current state.

If Secondary Series C FIM State Is . . .	Then, the Secondary Series C FIM . . .
<i>Not synchronized</i>	Cannot assume the Primary state. This is a state of non-readiness.
<i>Synchronizing</i>	Cannot assume the Primary State. In this state, the Secondary Series C FIM is copying database information from the Primary.
<i>Synchronized</i>	Can assume the Primary state upon switchover. In this state, the database in the Secondary is aligned with the database in the Primary. The Secondary closely tracks database changes to maintain its synchronization with the database of the Primary. Otherwise, the Secondary will revert to a Not Synchronized state.

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

11.3 Switchover behavior considerations

The following table lists some display and control data behaviors in response to a Series C FIM4/FIM8 switchover action.

For This Series C FIM Related Function . . .	The Related Switchover Behavior Is . . .
<i>Fieldbus to Fieldbus Device Communication</i>	The 'on-the-wire' control is not affected by a switchover. The new Primary FIM immediately takes over as a Link Master and resumes execution of the link schedule.
<i>Control Data for Fieldbus/Experion Control Integration</i>	Control data is available immediately after switchover. This includes data for connections in the Fieldbus to C300 and in the C300 to Fieldbus directions. The FIM may substitute a last known good value for publication to Fieldbus devices, while network connections reform to C300 controllers. Substitute value functionality is bounded to a maximum of five seconds to account for worse case timing.
<i>Display Data</i>	<p>Display data may not be available for several seconds during switchover. Typically, five seconds is the time required to refresh a display after switchover. Exact behavior of display data during switchover will be different on a per-configuration and per-device basis. After a FIM switchover, display clients such as Control Builder and Station must reform connections to the new primary FIM. The FIM then processes requests from reconnected clients. It populates the FIM parameter cache by issuing read requests on the H1 network for device parameter data. As the read requests complete and the FIM parameter cache is filled, display traffic resumes. The time to recover display data is affected by the following things:</p> <ul style="list-style-type: none"> • The bandwidth available on the H1 link for unscheduled traffic, • The number of display requests received by the FIM, • Use of views within the Fieldbus device, and • Third-party Fieldbus device behavior, including time required to reopen client/server VCRs.

<https://maxautol.com>
 manski@cambiala.cn
 +861803515712

11.4 Failure conditions and switchover

The following table identifies failure conditions that result in a switchover and those that do not.



Attention

- When any failure that results in a switchover occurs in a Secondary, the Secondary Series C FIM loses synchronization.

In addition to the failure conditions, this event is reported as diagnostic notification:

- Loss of view of redundant partner on H1 network (applies to Series C FIM link).
- Loss of private path connection from Primary to Secondary (lonely event).

Failure Conditions That Result in a Switchover	Failure Conditions That Do Not Result in a Switchover
Power to Primary Series C FIM fails.	One or all H1 cables fail.
Both FTE links to Primary Series C FIM are lost.	One or all H1 network conditioners fail.
Primary Series C FIM fails.	The 24-Volt power supply for the H1 link fails.

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

11.5 Fieldbus network switchover considerations

The Series C Fieldbus Interface Module (FIM4/FIM8) is a Link Master device running the link schedule, performing network maintenance activities, publishing control data and subscribing to control data, listening to alerts, and so on. All of these activities must be transferred from one module to another during switchover. The redundant Series C FIM operation accounts for the following key considerations associated with initiating a H1 network switchover.

For this Switchover Consideration . . .	Series C FIM Redundancy Operation . . .
Bumpless Switchover	<p>Assures that Fieldbus devices do not:</p> <ul style="list-style-type: none"> • Initiate a fault state, • Remote shed, or • Mode shed, during switchover. <p>The new Primary Series C FIM does not publish any data on the network until all switchover actions are completed and it has good data from the Control Data Access (CDA) server.</p>
Device Index number	<p>Does not transition the Device Index for the Primary Series C FIM to the Secondary Series C FIM. The Device Index stays with the physical Series C FIM.</p>
MAC Addresses	<p>Does not transition the MAC addresses for the FTE links on the Primary Series C FIM to the Secondary Series C FIM. The MAC addresses stay with the physical Series C FIM.</p>
IP Address	<p>Does swap IP addresses for Primary and Secondary Series C FIMs during switchover as follows.</p> <ul style="list-style-type: none"> • During initial synchronization, Primary and Secondary Series C FIMs exchange their IP addresses over the private redundancy link. This is for verification purpose only, since the odd-even convention allows both modules to determine their partner's address based on their own address. • During switchover or swap, both Primary and Secondary Series C FIMs replace their current IP address with their partner's IP address. This puts redundant pair into transient state in which peer modules are temporarily unable to communicate with either one of them, since their address tables are no longer valid due to the IP address swap. <p>After IP address swap, both Primary and Secondary Series C FIMs construct Address Resolution Protocol (ARP) request packets with updated IP-to-Ethernet address mapping and broadcast them on the network. Upon reception of ARP packets, peer nodes update their address tables.</p> <p>The swapping of IP addresses is transparent to the higher-level protocols such as Transmission Control Protocol (TCP) or User Datagram Protocol (UDP).</p> <ul style="list-style-type: none"> • TCP packets sent to either Primary or Secondary Series C FIM during switchover will be re-tried. Once retry limit is exceeded, connection breaks and gets re-established by application based on updated address information. • UDP packets sent to either Primary or Secondary Series C FIM during switchover and before client address table is updated will be lost.

11.6 Switchover versus fieldbus network activities

The following table summarizes how given Fieldbus network activities behave during a switchover.

! Attention

Depending upon the link communication load, number of devices, and type of parameter, fresh viewed data from field devices may be delayed for up to 20 seconds during a Series C FIM switchover. This does not apply to control data.

If Network Activity Is . . .	Then, Behavior During Switchover Is . . .
Link Maintenance	<p>Since Secondary Series C FIM link is a backup Link Active Scheduler (LAS), it resumes network management activities as soon as it detects that the old Primary Series C FIM is no longer there.</p> <p>Both Primary and Secondary C FIM links have the same knowledge of current time. When new Primary takes over as acting Link Master, it also becomes acting time publisher.</p>
System Management Operations	Any System Management operation that is in progress is interrupted. For example, the new Primary does not know anything about pending change tag or address operation. As a result, device whose address or tag is being changed will timeout and abort the operation.
Link Active Scheduler (LAS)	The Primary LAS runs the link schedule by telling devices to publish their data at specific times. The Secondary Series C FIM link is a backup LAS with a valid copy of the link schedule. During switchover, it skips the remainder of the current macrocycle and starts running its schedule from time zero of next macrocycle. Unlike backup LAS devices, the Secondary FIM has full LAS schedule with Series C FIM publications.
Alert Queued, User Triggered, Unidirectional Multicast (QUU) VCR	<p>Both Primary and Secondary Series C FIM links subscribe to alerts from devices and receive them in parallel. Only the Primary Series C FIM link reports received alerts through the CDA server to the operator interface.</p> <p>After switchover, the new Primary Series C FIM starts and the old Primary Series C FIM stops submitting alerts to the CDA server. The new primary Series C FIM regenerates its alarms. This action covers whatever alarms might have been acknowledged just prior to switchover but did not get submitted to Server as a result of event throttling.</p>
Subscriber Buffered, Network scheduled, Unidirectional broadcast (BNU) VCR	Both Primary and Secondary links subscribe to the same data published by a given device. Secondary has its VCR open and receives publications in parallel with the Primary. No specific action needs to be taken during switchover or swap.
Publisher Buffered, Network scheduled, Unidirectional broadcast (BNU) VCR	Only acting Primary Series C FIM link can publish data to Fieldbus devices. Both Primary and Secondary can be configured with the same publication endpoint connection, but only the Primary link has this connection open and active at a time. During switchover, the old Primary closes its connection and consequently stops publishing. The old Secondary, that is becoming new Primary, opens its connection and consequently starts publishing.
Client Queued, User triggered, Bi-directional peer-to-peer (QUB) VCR	<p>All client-server connections are broken and re-established. This way new Primary builds fresh connection context.</p> <p>QUB connections are point-to-point and therefore can only be opened from the primary.</p> <p>Series C FIM maintains one Management Information Base (MIB) connection to a device, one Function Block Application Process (FBAP) connection and possibly one control connection.</p>

11.7 Switchover events

Switchover results in several Experion system events and alarms. All of them are system information or diagnostics type. No process alarms are generated due to switchover.

Typical events generated during switchover include:

- Connection failure to secondary module alarm
- Switchover event
- Not synchronized alarm

Each of these events appears for Series C FIMs where switchover occurred.

<https://maxautoland.com/>
manski@cambia.cn +86 18030205725

12 Series C FIM4/FIM8 operation

This section includes the following topics on information and tasks associated with operating Series C FIM, FFLinks, and Fieldbus Devices included in control strategies created in Control Builder.

Topic
“Series C FIM4/FIM8 startup” on page 159
“Initiating Series C FIM4/FIM8 shutdown” on page 160
“Series C FIM4/FIM8 IOTA display and LED descriptions” on page 161
“Activating or inactivating FIM4/FIM8 link” on page 167
“Initiating Series C FIM4/FIM8 link segment commands” on page 168
“Activating or inactivating fieldbus block” on page 170
“Checking/changing fieldbus device functional class” on page 171
“Checking live list and commissioning an uncommissioned device” on page 173
“Viewing and optimizing link schedule configuration” on page 174
“Initiating switchover command” on page 179
“Using fieldbus methods manager” on page 180
“Using controller menu functions” on page 184
“Using station detail displays” on page 185
“Using Station event summary display” on page 191

Related topics

- “Series C FIM4/FIM8 startup” on page 159
- “Initiating Series C FIM4/FIM8 shutdown” on page 160
- “Series C FIM4/FIM8 IOTA display and LED descriptions” on page 161
- “Control Builder Block icon descriptions” on page 164
- “Activating or inactivating FIM4/FIM8 link” on page 167
- “Initiating Series C FIM4/FIM8 link segment commands” on page 168
- “Activating or inactivating fieldbus block” on page 170
- “Checking/changing fieldbus device functional class” on page 171
- “Checking live list and commissioning an uncommissioned device” on page 173
- “Viewing and optimizing link schedule configuration” on page 174
- “Initiating synchronization command” on page 178
- “Initiating switchover command” on page 179
- “Using fieldbus methods manager” on page 180
- “Using controller menu functions” on page 184
- “Using station detail displays” on page 185
- “Foundation fieldbus detail displays/faceplates” on page 186

“Using Station event summary display” on page 191

<https://maxautoland.com/>
manski@cambodia.ch +86 18030205725

12.1 Series C FIM4/FIM8 startup

The following table summarizes the stages the Series C FIM4/FIM8 goes through after power is applied to its IOTA during startup. The Series C FIM4/FIM8 repeats these stages every time power is cycled Off/On.

Stage	Description
1	Power Light Emitting Diode (LED) Lights
2	Executes firmware installed in FLASH memory. The initial firmware boot code is installed at the factory.
3	The Status LED briefly displays all of its colors: RED, GREEN, AMBER. Then, remains solid RED until the power-on self test (POST) completes.
4	Initiates a series of horizontal and vertical bars, as well as several brightness levels for evaluating the condition of the 4-character, alphanumeric display. At the end, the Link Status LEDs are blinked in turn.
5	Executes power-on self test to verify that all subsystems are working as intended. Cycles test number codes in the 4-character display to show progress of the test. (Initialization will halt on the first test that finds an invalid or faulty piece of hardware. The Series C FIM4//FIM8 will display the test number code associated with the detected device failure until it is reset.)
6	Upon successful completion of the power-on self test, displays information about the application image currently stored through its 4-character display. The status LED should now reflect the true state of its associated hardware.
7	The 4-character display shows -bp- ((BOOTP) until it obtains its IP Address. The display then shows -ts- (Time Server) until time has been obtained from the NTP Server. Once its IP Address is known, it negotiates its redundancy role, either Primary or Secondary, with its partner module, if present. Verifies that the correct Device Index is displayed (#nnn) and that no addressing errors are detected. The primary module will have the odd IP address while the secondary module will have the odd + 1 IP address. The odd IP address will follow the primary module during a switchover. The Device Index does not change during a switchover or any other role change. Once a device has obtained its IP Address and NTP Server IP Address(es), it retains them until its Device Index is changed or firmware is reloaded. (The Series C FIM4/FIM8 will determine if any other module is using the same IP address. If it does find another module with the same Device Index, it will not join the network but instead transitions to <i>no address</i> state waiting for new address assignment. If it finds another node with the same IP Address, it will not join the network but instead transitions to <i>dup address</i> state; it must be reset to recover.)
8	The 4-character display cycles this information: Device Index setting, Link status, followed by Redundancy status. See the <i>Display and LED Descriptions</i> section for more information about the display and LED indications.

https://mcauto.com/3025175
manski@com... +361403025175

12.2 Initiating Series C FIM4/FIM8 shutdown

Use the following procedure to initiate a shutdown command to the Series C FIM4/FIM8, which results in the Series C FIM4/FIM8 rebooting to its RDY state or boot firmware.

! Attention

- Shutting down the Series C FIM4/FIM8, interrupts the transfer of data to the Experion system. Be sure your system can tolerate the lost of live data, while the Series C FIM4/FIM8 is in its RDY state.


-
- 1 On the **Monitoring** tab, double-click the FIM4/FIM8 icon to open the **FIM4/FIM8 Block** configuration form.
 - 2 On the **Main** tab, click **Controller Command** box and select **Shutdown** from the list.
 - 3 Click **Yes** to confirm the action.
 - 4 Wait for the FIM4/FIM8 to reboot to its RDY state.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

12.3 Series C FIM4/FIM8 IOTA display and LED descriptions

The following illustration and table identify and describe the display and LED indications associated with the 4-character alphanumeric display on the Series C FIM4/FIM8 and LEDs on the Series C FIM4/FIM8 and IOTA.

Table 5: Display and LEDs on Series C FIM4 and IOTA.



If ...	Is ...	Then, it means that
<i>H1 Activity LED (FIM4/FIM8)</i>	Off	There is no activity on the link.
	Blinking Green	There is transmission activity on the link
<i>Series C FIM Power LED (FIM4/FIM8)</i>	Off	Series C FIM4/FIM8 is not receiving power.
	Green	Series C FIM4/FIM8 is powered.
<i>Series C FIM Status LED (FIM4/FIM8)</i>	Off (Blanked or Frozen Display)	There is a Series C FIM4/FIM8 fault, no cause specified; or hardware failure.
	Green	Non-redundant or primary Series C FIM4/FIM8 is loaded and operation is okay. For redundant operation, does not imply if the module is synchronized or not.
	Blinking Green	Non-redundant or primary FIM4/FIM8 is okay, not loaded or there is a soft failure. This may occur if no database is loaded to the module or a soft failure condition exists.

If . . .	Is . . .	Then, it means that
	Amber	Secondary Series C FIM4/FIM8 is in the backup or secondary state and the module is synchronized.
	Blinking Amber	Secondary Series C FIM4/FIM8 is in the backup or secondary state and is not synchronized or has a soft failure.
	Red	Module is running power on self test, or power on self test has failed.
	Blinking Red	<ul style="list-style-type: none"> Series C FIM4/FIM8 has no IP Address, no role. This should be a transient condition after power up unless BOOTP server is not running. Display will indicate module is not faulted. The module is not on control. Series C FIM4/FIM8 is in Alive (ALIV) or Ready (RDY) state and can accept a firmware download. Application image is not executing. The module is not on control. Series C FIM4/FIM8 is in LOAD state and accepting a firmware download. Application image is not executing. The module is not on control. Series C FIM4/FIM8 is in the FAIL state. An unrecoverable error has been logged and the module has gone off control.
<i>FTE A and/or FTE B LED (FIM4/FIM8)</i>	Off	Link integrity signal is present, but no activity. This is unlikely because every node will normally show some activity over several seconds.
	Blinking Green	Link integrity signal is present, along with some activity. Frequency of green LED pulse indicates the amount of transmit traffic on the FTE link.
	Red	Link is not connected. No link integrity signal.
<i>4-Character Alphanumeric Display (FIM/FIM8)</i>	#nnn	It is the Series C FIM's FTE device index, where nnn can be 001 to 255. This does not change with redundancy role.
	X-CE	Error during link communications Initialization. Where X equals 1, 2, 3, or 4 for FIM4 and 1 through 8 for FIM8 links.
	X-DE	Error during link database initialization. Where X equals 1, 2, 3, or 4 for FIM4 and 1 through 8 for FIM8 links.
	X-CI	Link is undergoing communications initialization. Where X equals 1, 2, 3, or 4 for FIM4 and 1 through 8 for FIM8 links.
	X-DI	Link is undergoing database initialization. Where X equals 1, 2, 3, or 4 for FIM4 and 1 through 8 for FIM8 links.
	X-nn	Link is currently online with connected devices. Where X equals 1, 2, 3, or 4 for FIM4 and 1 through 8 for FIM8 links. In addition, nn equals number of devices on the link from 01 to 16.
	BKUP	Series C FIM is currently in the Secondary role.
	-np-	Primary or Secondary Series C FIM is configured for redundant operation, but a partner module is not physically present.
	nrdn	Series C FIM is explicitly configured to be non-redundant.
	!syn	Redundant Series C FIM pair is not synchronized. Primary or secondary Series C FIM is configured for redundant operation and a partner module is physically present. Initial synchronization has not occurred.
	sync	Redundant Series C FIM pair is synchronized.

If ...	Is ...	Then, it means that
	XXX%	Initial synchronization is in progress. Where XXX can be 000 to 100 to indicate percentage complete.
	PRI	Series C Series C FIM is operating as primary in redundant Series C FIM pair.
	SEC	Series C Series C FIM is operating as secondary in redundant Series C FIM pair.
	TXXX	Series C FIM is in test mode. Where XXX equals some self test code.
	BOOT	Series C FIM is starting up.
	ALIV	Series C FIM is executing boot firmware. A valid application image has not been loaded.
	LOAD	Series C FIM is executing boot firmware. A new boot or application image is being loaded.
	RDY	Series C FIM is executing boot firmware. A valid application image has been loaded.
	FAIL	Series C FIM has detected a software failure.

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

12.4 Control Builder Block icon descriptions

! Attention

Communication to the FF link is unavailable due to physical layer disturbances. Hence, you must correct the physical layer disturbances and then perform a shutdown and startup of the FF link.

Related topics

“FIM4/FIM8 block icons” on page 164

















“FIM4/FIM8 link icons” on page 165






“Fieldbus Device icons” on page 165

“Fieldbus block icons” on page 166

12.4.1 FIM4/FIM8 block icons









The following table summarizes the various appearances that a FIM4/FIM8 block icon can assume based on configuration, view, and current Series C FIM operating state and status.

If icon is . . .	Then, it represents . . .	And, Module State Is. . .
Project Tab		
 (gray)	FIM4/FIM8 configured for non-redundant operation.	N/A
 (gray/white)	FIM4/FIM8 primary configured for redundant operation.	N/A
 (white/gray)	FIM4/FIM8 secondary configured for redundant operation.	N/A
Monitoring Tab		
 (blue)	FIM4/FIM8 is non-redundant.	Idle
 (blue/white)	Primary FIM4/FIM8 is synchronized	Idle
 (blue/yellow)	Primary FIM4/FIM8 is not synchronized and partner FIM4/FIM8 is visible.	Idle
 (yellow/blue)	Secondary FIM4/FIM8 is not synchronized and partner FIM4/FIM8 is visible.	Backup
 (blue/shadow)	Primary FIM4/FIM8 is not synchronized and partner FIM4/FIM8 is absent or incompatible.	Idle
 (green)	FIM4/FIM8 is non-redundant	Run
 (green/white)	Primary FIM4/FIM8 is synchronized	Run
 (white/green)	Secondary FIM4/FIM8 is synchronized	Backup
 (green/yellow)	Primary FIM4/FIM8 is not synchronized and partner FIM4 is visible	Run
 (green/shadow)	Primary FIM4/FIM8 is not synchronized and partner FIM4 is absent or incompatible	Run
 (yellow)	FIM4/FIM8 is non-redundant	No Database
 (yellow/white)	Primary FIM4/FIM8 is synchronized	No Database
 (yellow/yellow)	Primary FIM4/FIM8 is not synchronized and partner FIM4 is visible	No Database

If Icon is . . .	Then, it represents . . .	And, Module State Is . . .
 (yellow/shadow)	Primary FIM4/FIM8 is not synchronized and partner FIM4 is absent or incompatible	No Database
 (shadow/yellow)	Secondary FIM4/FIM8 is not synchronized and partner FIM4 is absent or incompatible	Backup
 (red)	FIM4/FIM8 is non-redundant and not communicating	Offnet
 (red/white)	Primary FIM4/FIM8 is not communicating.	Offnet
 (white/red)	Secondary FIM4/FIM8 is not communicating.	Offnet





12.4.2 FIM4/FIM8 link icons






The following table summarizes the various appearances that a FIM4/FIM8 Link block icon can assume based on view and current FFLink state. FFLink blocks apply only to the primary or non-redundant FIM4/FIM8 block, and do not have matching blocks for secondary FIM4/FIM8.

If Icon is . . .	Then, it represents . . .
Project Tab	
 (gray)	FFLink associated with configured non-redundant or primary FIM4/FIM8.
Monitoring Tab	
 (gray/arrow)	Control Builder / Control Data Access (CDA) server is currently establishing communication to the FFLink.
 (blue)	FFLink is inactive.
 (yellow)	FFLink is initializing.
 (green)	FFLink is active.
 (green/asterisks)	FFLink is active and uncommissioned devices exist on the H1 network.
 (red/black exclamation)	Communication to the FFLink is unavailable
 (red/white exclamation)	Communication to the FFLink is available, but the FFLink is in a failed state.

12.4.3 Fieldbus Device icons






The following table summarizes the various appearances that a Fieldbus device block icon can assume based on view and current device state. FFLink blocks apply only to the primary or non-redundant FIM4/FIM8 block, and do not have matching blocks for secondary FIM4/FIM8.

If Icon is . . .	Then, it represents . . .
Project Tab	
 (gray)	Device added to Project.
Monitoring Tab	
 (gray/arrow)	Control Builder / Control Data Access (CDA) server is currently establishing communication to the device.
 (green/question mark)	Uncommissioned device.
 (green)	Device is online and is configured as a Basic device.

If Icon is . . .	Then, it represents . . .
 (green/green clock)	Device is online and is configured as a Link Master device. Green clock means that the backup LAS in the field device is the same version and is in sync with FIM4/FIM8 Link. It is important to operate with a green clock, so the Link Master device has valid backup LAS in case of a FIM4/FIM8 failure.
	Device is online and is configured as a Link Master device. A bad link schedule exists in the device. A Red Clock indicates that either the field device never received a backup LAS or is not at the same version and is out of sync with FIM4/FIM8 Link. Such a condition can occur if the backup LAS cannot fit in the field device (For example, EXPKS_E_CL_SCHED_TOOBIG error seen during configuration download) or configuration download to the field device was aborted because of other failures.
 (red/black exclamation)	Device is offnet. Communications with the device is unavailable.
 (red/red exclamation)	Communications with the device is available, but the device is in a failed state. The device is a Basic device.
 (red/red exclamation/red clock)	Communications with the device is available, but the device is in a failed state. The device is a Link Master device.

12.4.4 Fieldbus block icons

The following table summarizes the various appearances that a Fieldbus block icon associated with a Fieldbus device can assume based on view and current block state. The faceplate of the block will vary to reflect the block type such as Resource, Transducer, Analog Input, and so on.

If Icon is . . .	Then, it represents . . .
Project Tab	
 (gray)	Block added to Project.
Monitoring Tab	
 (gray/arrow)	Control Builder / Control Data Access (CDA) server is currently establishing communication to the block.
 (green)	Block is active
 (blue)	Block is inactive
 (red/exclamation)	Block is offnet. Communications with the block is unavailable.

12.5 Activating or inactivating FIM4/FIM8 link

Use the following procedure to change the state of a FIM4/FIM8 H1 Link through the **Monitoring** tab in Control Builder.


Following are the considerations for activating or inactivating FIM4/FIM8 link

- Inactivating a FIM4/FIM8 Link essentially shuts down the H1 Link and the Series C FIM, if all Links are inactivated, and interrupts the transfer of data to the Experion system. Be sure your system can tolerate the lost of live data, while the FFLink is inactive.
- All Fieldbus device blocks associated with the inactivated FFLink are also shutdown, including those contained in Control Modules
- You can also initiate this same function through the corresponding Detail display in Station.

Prerequisites

- You can view FIM4/FIM8 and its Links through the **Monitoring** tab of Control Builder.

To change FIM4/FIM8 Link state

- 1 In **Monitoring** tab, click desired **FFLink** icon.
- 2 Click the **Toggle State** button  in the toolbar.
- 3 In the **Change State** dialog, click **Yes** to initiate the state change.
- 4 Check that the **FFLink** icon changes from green to blue, when it is inactivated; or from blue to green when its activated.
- 5 Repeat this procedure to inactivate or activate a given FFLink as applicable.
- 6 To inactivate the FIM4/FIM8, use this procedure to inactivate all 4 FFLinks or 8 FF links respectively.

<https://maxautolam.com/>
 manski@cambid.com.cn +86 18930205725

12.6 Initiating Series C FIM4/FIM8 link segment commands

The FIM4/FIM8 stores configuration data in non-volatile storage (NVS) for retention in case of loss of power, module restarts and module shutdowns. Each H1 Link block has its own independent NVS log, where changes in the configuration data are stored. The NVS usage increases as the configuration data changes. The current NVS usage for each H1 Link is provided as a percentage by the NVSUSED parameter. The H1 Links' NVS logs can be individually purged and compacted using the SEG Command parameter.

Use the following procedure to issue a startup, shutdown, or purge NVS (non-volatile storage), or Compact NVS command to a Series C FIM4/FIM8 H1 Link through the **Monitoring** tab in Control Builder.

Following are the considerations for Initiating Series C FIM4/FIM8 link segment commands

- Shutting down a Series C FIM4/FIM8 Link essentially shuts down the H1 Link and interrupts the transfer of data to the Experion system. Be sure your system can tolerate the lost of live data, while the FFLink is shutdown.
- All Fieldbus device blocks associated with the shutdown FFLink are also shutdown, including those contained in Control Modules
- You can also initiate this same function through the corresponding Detail display in Station.
- You must shutdown the Series C link before issuing the Purge NVS command.

Prerequisites

- You can view FIM4/FIM8 and its Links through the Monitoring tab of Control Builder.

To use segment commands

- 1 In **Monitoring** tab, click plus sign + for **FIM4/FIM8** icon to expose its associated Links in tree hierarchy.
- 2 Right-click desired **FFLink** icon and select **Module Properties** from the list to call up the **FFLink Block Parameters** form.
- 3 Click the **SEG Command** box and select **STARTUP, SHUTDOWN, PURGENVS, or COMPACTNVS** from the list to initiate desired FFLink/segment action. Click **Yes** to confirm the action.
- 4 Check that the **SEG State** read-only parameter changes to reflect the current state of the FFLink.
- 5 Click **OK**.
- 6 Repeat this procedure to use segment commands on another FFLink or issue another command on the selected FFLink, as applicable.

12.6.1 Initiating a PurgeNVS SEG command

The result of a PurgeNVS operation is an NVS log that contains only the H1 Link block settings including the Publication Method, Schedule Optimization enabled option, and Network Management bus parameters. The Link Schedule, Agents, VCRs, and other FIM resident device configuration will be removed from the NVS log. When the FIM4/FIM8 is restarted, the H1 Link block will retain its settings upon startup, but all Fieldbus devices on the H1 Link will be uncommissioned. To resume schedule execution and control with that link, all devices and CMs containing function blocks from that link must be reloaded from the Project view. The H1 Link must be DOWN to initiate a PurgeNVS operation.

Note: If a switchover is performed after the PurgeNVS SEG command is initiated but before the Primary FIM4/FIM8 is restarted, the NVS logs will contain all configuration data such as;

- Link Schedule
- Agents
- VCRs
- FIM resident device configuration

To initiate a PurgeNVS SEG Command.

- 1 In the Monitoring view, double-click the H1 Link function block.
The configuration form appears.
- 2 If the **SEG State** parameter value of the H1 Link is ONLINE, select **SHUTDOWN** from the **SEG Command** list to shutdown the H1 Link.
- 3 If the **SEG State** parameter value of the H1 Link is DOWN, select **PURGENVS** from the **SEG Command** list to initiate a PurgeNVS operation.
- 4 Click **OK**.

12.6.2 Initiating a CompactNVS SEG Command

As the NVS usage increases, it may become necessary to compact the NVS log. The result of a CompactNVS operation is an NVS log that contains all configuration data, using the minimum amount of space in the NVS log. When the FIM4/FIM8 is restarted, the H1 Link will retain its configuration upon startup, and all Fieldbus devices on the H1 Link that were previously commissioned will be commissioned upon startup. The CompactNVS operation may be performed while the H1 Link is ONLINE.

To initiate a CompactNVS SEG Command.

- 1 In the Monitoring view, double-click the H1 Link function block.
The configuration form appears.
- 2 In the **SEG Command** list, select **COMPACTNVS** to initiate a Compact NVS operation.
- 3 Click **OK**.

12.6.3 Automated NVS compaction

A secondary FIM4/FIM8 in a redundant configuration will automatically compact its NVS logs in the following circumstances.

- On startup of the secondary FIM4/FIM8, if the NVS usage of a NVS log is greater than 70%, that NVS log will be compacted.
- On a Drop-Sync, if the NVS usage of a NVS log on the secondary is greater than 70%, that NVS log will be compacted.

Automated NVS compaction does not occur on primary/non-redundant FIM4/FIM8 modules.

12.7 Activating or inactivating fieldbus block

Following are the considerations for activating or inactivating fieldbus block

- Inactivating a Fieldbus device block interrupts the transfer of data to the Experion system. Be sure your system can tolerate the lost of live data, while the block is inactive.

Prerequisites

- You can view FIM4/FIM8, its Links, and assigned Fieldbus devices through the **Monitoring** tab of Control Builder.

To activate or deactivate a block

- 1 In **Monitoring** tab, click plus signs + for **FIM4/FIM8**, **FFLink**, and **Device** icons to expose Fieldbus blocks in tree hierarchy.
- 2 Right-click desired **Fieldbus block** icon and select **Activate**> or **Inactivate**>**Selected Item(s)** from the list.
- 3 Check that the **block** icon changes from green to blue, when it is inactivated, or from blue to green when it is activated.
- 4 Repeat this procedure to inactivate or activate a given Fieldbus block, as applicable.

<https://maxautol.com/>
+86 18030205725
manski@cambid.com

12.8 Checking/changing fieldbus device functional class

Following are the considerations for Checking/changing fieldbus device functional class

- The Series C FIM is the primary **Link Master** for all Links. If you designate a device as a *backup Link Master*, be sure it has the capacity to handle the Link Schedule. Otherwise, you may have to reset the device as a **Basic** type and restart it to restore operation, if the Link Schedule is too large for it to handle.
- You can confirm the change by calling up the device's **Parameters** form and checking that **BASIC** appears as the value for the DL Operational Functional Class parameter on the **Network Management (Basic)** tab.
- If you change the functional class for a device in the **Project** tab, be sure you restart the device after it is loaded from **Project** for the change to be made in the device.
- You can manually cycle power to the Fieldbus device to restart it.

Prerequisites

- You can view FIM4/FIM8, its Links, and assigned Fieldbus devices through the **Monitoring** tab of Control Builder.
- You have logged on with a security level that allows you to make changes in a control strategy.

To change device functional class

- 1 In **Monitoring** tab, double-click device icon to open its configuration **Parameters** form.
- 2 Click **Network Management (LM)** tab to open it.
- 3 Click the arrow button in **Boot Operational Function Class** box and select **BASIC** or **LINKMASTER** from the list, as applicable.
- 4 Follow the online Wizard prompts to initiate the change. Click **Finish** to complete the change.
- 5 After Fieldbus device restarts, its functional class is changed to **BASIC** or **LINKMASTER** as commanded.
- 6 Be sure the **Boot Operational Function Class** change is also reflected in configuration form for the **Project** version of the device.
- 7 Click **OK** to close the form.



Attention

With R400, you can enable/disable the alarm conditions status and configure the non-cache parameters through the **Device Diagnostics** tab.

FISHER-CONTROLS:DVC6000F_0106 Block, DVC6000F_010_158 - Parameters [Project]

Server Displays | Control Confirmation | QVCS | Identification
Main | System Management | Network Management (Basic) | Device Diagnostics | Server History

Alarm Conditions Status

SI.No.	Condition Name	Enable
1	A1	<input type="checkbox"/>
2	A2	<input checked="" type="checkbox"/>
3	A3	<input type="checkbox"/>

Non-Cache Parameters

SI.No.	Parameter Name	Parameter Description
1	DVC6000F_010_158.TRANSDUCER.ADVISE_ALM.VALUE	Value
2	DVC6000F_010_158.TRANSDUCER.ACT_MODEL_NUM	Actuator Model Number
3	DVC6000F_010_158.TRANSDUCER.ACT_SN	Actuator Serial Number
4	DVC6000F_010_158.TRANSDUCER.ACT_MAN_ID	<input type="checkbox"/> Actuator Mfr Identifier

Show Parameter Names

OK Cancel Help

To configure the non-cache parameters, perform the following steps.

- In the **Non-Cache Parameters**, click that appears in the text box.
- The **Point Picker** dialog box appears.
- Select the required blocks and the related parameters that appear in the dialog box.
- Click **OK**.
- The selected parameter description appears in the corresponding **Parameter Description** column.

12.9 Checking live list and commissioning an uncommissioned device

Use the following procedure to check the link for devices that are added to the Live List as uncommissioned.

Following are the considerations for checking live list and commissioning an uncommissioned device

- If you add an unconfigured Fieldbus device to a live/operating link, it will appear as an **uncommissioned** device in the FFLink block hierarchy in the **Monitoring** tab in Control Builder.
- If you add a device with an address that is below 20 (decimal)/14 (hexadecimal) to the H1 Link, the Series C FIM4/FIM8 clears the device's address so it can join the Link at a temporary address that can be reassigned as required.
- If you add an uncommissioned device with a functional class of **LINKMASTER** to the H1 Link, the Series C FIM4/FIM8 initiates the following actions to guard the network against incorrect link schedules.

Clears the Link Schedule,

Clears the Primary Link Master Flag Variable,

Sets the configured link settings,

Sets the device functional class to **BASIC**, and.




Restarts the device.

- It is possible that the uncommissioned device will have an earlier version of the vendor's software (Device Rev). In this case, the device would appear to have no matching block type even if one exists for the same device but it is for a different software version. If the vendor supports flash upgrade of its device's firmware, you can upgrade the device's firmware through the **Uncommissioned Devices** tab on the Device's **Parameters** form in Control Builder. Please see "Upgrading firmware in uncommissioned device" on page 225 in the next Section Series C FIM4/FIM8 Maintenance for more information.
- A new Link Schedule must be loaded to the Series C FIM4/FIM8 and other Link Master devices anytime there is a change that invalidates the current Link Schedule, such as adding a device, removing a device, or making a configuration change.
- A block type must exist before a device can be integrated/commissioned with the system.

Prerequisites

- You can view FIM4/FIM8, its Links, and assigned Fieldbus devices through the **Monitoring** tab of Control Builder.

To change uncommissioned device to commissioned one

- 1 In **Monitoring** tab, click plus sign + for **FIM4/FIM8** icon to expose its associated Links in tree hierarchy.
- 2 Click the plus sign  for the **FFLink** icon with an asterisks  to expose the uncommissioned device icon .
- 3 Double-click the uncommissioned device icon to open the FFLink **Parameters** form with the **Uncommissioned Devices** tab open.
- 4 Click **Create Project Database Instance for this Device** to launch a commissioning wizard that automatically steps through the process to commission a device. The process includes creating device Type, changing tag and/or address, creating Project instance, matching Project to device, and loading device, as required.
- 5 Click **OK** to close the **Parameters** form.
- 6 Repeat this procedure for other uncommissioned devices as needed.

12.10 Viewing and optimizing link schedule configuration

The following table summarizes how to call up a Link schedule configuration for viewing in the control chart area of the Control Builder application. You can also interact with the natural schedule to optimize it using the considerations listed below. Or, you can configure the FFLink for the system to provide automatic schedule optimization as noted in the following procedure.

Following are the considerations to configure link schedule optimization

- The key to optimizing the Link schedule is logically configuring the ORDERINCM parameter for each block to:
 - Sequence blocks in a logical order from inputs to outputs and,
 - Execute non-control blocks after control blocks.
 - The following are some general latency related considerations to use as reference for determining the most logical overall sequencing for your Control Strategy.
 - Assume that faster loops are more critical and have a higher priority than slower ones on the same link.
 - Primary or innermost loops are always more critical than secondary or outer loops. The same is true for lower level loops in multi-level cascades, since the timing requirements for each level become less critical.
 - Configurations that do not contain an output type block have a much lower priority than any configuration that does, since these configurations are most likely intended for monitoring only.
 - Back-Calculation publications have the lowest priority, since they only have to be published before they are needed in the next execution sequence.
 - Delay execution of non-control loop auxiliary blocks like integrators through the ORDERINCM parameter sequencing. If they are created last, delay will occur naturally through the default ORDERINCM parameter sequencing.
-
- ! Attention**
- Loading the LINK with or without contents for the first time will not load the link schedule. However, it loads the FFLINK Optimization parameters and will not modify the monitor view LINK schedule. LINK schedule gets loaded only by loading a new FFCM or reloading the existing CM
-
- See the following procedure to configure the FFLink for automatic schedule optimization.

12.10.1 Calling up Link Schedule

If You Are in the . . .	Then, you can	And, the Link Schedule Configuration shows. . .
Project Tab	Right-click the FFLink icon and select Open Chart from the list. Or, Double-click the FFLink icon.	The block execution and data publications for all Control Modules that are configured in Project and assigned to the FFLINK or CEE. And, they contain Fieldbus function blocks that are associated with a device assigned to the given FFLink, and/or Experion blocks that participate in Link publications. See the Sample Link Schedule configuration display in Project Figure that follows this table for reference.
Monitoring Tab	Same as above.	The block execution and data publications for all applicable Control Modules configured and assigned in Project and loaded to the FFLINK or CEE. See the Sample Link Schedule configuration display in Monitoring Figure that follows this table for reference.




Figure 22: Sample Link Schedule configuration display in Project.

<https://maxautoland.com>
 manski@cambid.com +86 18930205112




Figure 23: Sample Link Schedule configuration display in Monitoring.

12.10.2 Additional Link Schedule terms reference

The following table lists additional terms that appear at the bottom of the link schedule (not shown in figures above) along with their descriptions.

Term	Description
Macrocycle Usage Gain (MUG)	Measures percent reduction in used portion of macrocycle, start to end of last element. $MUG = \left(1 - \left(\frac{\text{optimized used portion length}}{\text{natural used portion length}} \right) \right) \times 100\%$
Latency Improvement Factor (LIF) (reduction factor)	Measures percent reduction in latency from start of input to end of output $LIF = \left(1 - \left(\frac{\text{optimized loop length}}{\text{natural loop length}} \right) \right) \times 100\%$

Term	Description
Publication Gap Availability Improvement (PGAI)	Index based on square of gap sizes greater than 18 milliseconds. $PGAI = \left(1 - \frac{\left(\text{sum of squares of lengths of natural qualifying pub gaps} \right)}{\left(\text{sum of squares of lengths of optimized qualifying pub gaps} \right)} \right) \times 100\%$

12.10.3 Configuring link schedule optimization

Prerequisites

You have completed your control strategy configuration that includes Fieldbus blocks integrated with control modules in Control Builder.

To configure link schedule optimization

- 1 In the **Project** tab, click the plus sign for the FIM4/FIM8 icon to expose its PFLinks in the tree.
- 2 Right-click the first FFLink icon and select **Module Properties** to open the **FFLINK Block Parameters** form.
- 3 On the **Main** tab, click the down-arrow button in the **Link Schedule Optimization** box and select **OPT** or **OPT_NOFORCE** for automatic link schedule optimization. Otherwise, select **NO_OPT** to disable link schedule optimization.
Refer to *FFLink Configuration Parameters Reference* for more information about the selections.
- 4 Click the down arrow button in the **Sample Skew** box and select **SKEW** or **NOSKEW** for desired block execution action.
Refer to *FFLink Configuration Parameters Reference* for more information about the selections.
- 5 Repeat Steps 2 to 4 for other FFLinks, as applicable.
- 6 Click **OK** to close the form and save the settings.

<https://maxoutolam.com/+661813025725>
 manski@cambodia.com

12.11 Initiating synchronization command

Use the following procedure to initiate a synchronization command manually to a redundant Series C FIM4/FIM8 pair.

Prerequisites

You can view active redundant FIM4/FIM8 pair on **Monitoring** tab in Control Builder.

To command synchronization

- 1 In the **Monitoring** tab, double-click the primary **FIM4/FIM8** icon to call up its **Parameters** configuration form.
- 2 Click the **Redundancy** tab to display it.
- 3 Click **Enable Synchronization**.
- 4 Click **Yes** to confirm the action and issue the synchronize command.
- 5 Check the **Redundancy Status** data on the **Parameters** form and confirm that **sync** cycles in the primary Series C FIM's 4-character display.
- 6 Click **OK** to close the **Parameters** form.

<https://maxautoland.com/>
manski@cambid.com +86 18030205725

12.12 Initiating switchover command

You can use the following procedure to initiate a switchover command manually to a redundant Series C FIM4/FIM8 pair.

Prerequisites

You can view active redundant FIM4/FIM8 pair on **Monitoring** tab in Control Builder.

The primary and secondary Series C FIM4/FIM8s are synchronized.

To command a switchover

- 1 In the **Monitoring** tab, double-click the primary **FIM4/FIM8** icon to call up its **Parameters** configuration form.
- 2 Click the **Redundancy** tab to display it.
- 3 Click **Initiate Switchover**.
- 4 Click **Yes** to confirm the action and issue the switchover command.
- 5 Confirm that the Secondary Series C FIM4/FIM8 assumes the Primary role.
- 6 Click **OK** to close the **Parameters** form.

<https://maxautoland.com/>
+86 18030205725
manski@cambid.com.cn

12.13 Using fieldbus methods manager

Prerequisites

Before you can launch Methods Manager you must:

- Create the block type for a device from its manufacturer's DD files that include methods data using the **Type** command in Control Builder.
- Instantiate (create) and load the device block through Control Builder.
- Access the active device block through the **Monitoring** tab in Control Builder.

To launch Methods Manager

- You can use one of the following action to launch Methods Manager through Control Builder, assuming the prerequisites have been met.

If You Select . . .	Then, . . .	And,
Device in Monitoring tab	Click Field Devices-> Methods Manager...	Methods Manager dialog provides a selection list that includes all the blocks associated with the device and their available methods with the method description.

To interact with Methods Manager



- The Methods Manager application executes the device's method and prompts users for needed interaction based on the selected method. The following table lists some possible user prompted actions for reference. The actual interaction is determined by the selected method.






Tip



- When active, press the **Summary** button on the Methods Manager dialog to call up a report that shows all the steps executed during the execution of the selected method up to that point in time.
- When active, press the **Show Methods List** button to see the list of methods and their descriptions for the selected device.

Note that some methods in the Methods List, which are derived from newer EDDs, may *not* be supported in the current Experion release. These methods will be grayed out and unavailable for execution.

If Methods Manager Dialog . . .	Then, You Are Prompted to . . .
<p>Includes list of available Methods.</p> 	<p>Select the method to be invoked and follow the instructions in the Methods Manager dialog.</p>
<ul style="list-style-type: none"> • While using the Fieldbus Methods Manager to execute a method, do not use Experion applications like Control Builder or Station to change the device/block parameters for the device on which the methods is running. • While using the Fieldbus Methods Manager to execute a method, some methods may display messages that are very specific to a vendor. In this case, please consult the vendor's user/maintenance manual to verify/validate it. 	
<p>Shows action in progress.</p> 	<p>Wait for action to complete before continuing.</p>

<https://maxautoland.com/>
 +86 180 3203725
 manski@cambia.cn

If Methods Manager Dialog . . .	Then, You Are Prompted to . . .
<p>Shows selection from a list.</p>  <p>The screenshot shows the 'Fieldbus Methods Manager' window. At the top, it lists: Device - DVC5000F_A_09_42, Block - ADV_POS_BASIC, and Method - Auto Travel Calibration. A warning box contains the text: 'WARNING - This procedure may result in a sudden change in the valve position, and loss of process control. DO NOT continue until the instrument and the associated valve are isolated from the process.' Below the warning is a dropdown menu labeled 'Do you wish to continue?' with 'Yes' selected. At the bottom, there are buttons for 'Next >>', 'Summary', and 'Cancel'.</p>	<p>Select desired action by selecting an option and follow the instruction given in the Methods Manager dialog.</p>
<p>Requests user acknowledgement.</p>  <p>The screenshot shows the 'Fieldbus Methods Manager' window. It lists: Device - EH1, Block - EH_RADARLEVEL_0, and Method - system parameters. The main area displays 'protocol+sw-no.: V01.01.02 (FF)'. At the bottom, there are buttons for 'Next >>', 'Summary', and 'Cancel'.</p>	<p>Follow the instruction given in the Methods Manager dialog.</p>
<p>Requests user action.</p>  <p>The screenshot shows the 'Fieldbus Methods Manager' window. It lists: Device - EH1, Block - EH_RADARLEVEL_0, and Method - diagnostics. The main area displays 'unlock parameter 2457' with a text input field containing '2457'. At the bottom, there are buttons for 'Next >>', 'Summary', and 'Cancel'.</p>	<p>Follow the instruction given in the Methods Manager dialog.</p>

If Methods Manager Dialog . . .	Then, You Are Prompted to . . .
<p>Displays error message or code</p> 	<p>Note error and follow the instruction given in the Methods Manager dialog.</p>
<p>Shows an abort message</p> 	<p>Wait until the abort sequence is completed.</p>

*https://maxautol.com/
manski@cambria.cn +86 18030205725*

12.14 Using controller menu functions

Many of the Control Builder **Controller** menu functions designed for use with the Controller and CEE components also apply for the FIM4/FIM8 and Links components. These include **Upload**, **Update**, and **Checkpoint** functions. These functions are useful for correcting mismatches that may occur between the components and the database. Please refer to the *Control Building User's Guide* for details about a given menu function.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

12.15 Using station detail displays

The Experion server Station application includes pre-configured Detail displays for the Series C FIM, Link, device and Fieldbus function blocks. These displays are the default entries for the Point Detail Page parameter on the **Server Parameters** tab of the configuration form. Once you establish communications with a Fieldbus H1 link you can begin monitoring the status of any component that has been loaded as part of a Control Strategy to a Series C FIM with points registered in the Experion server. The Detail displays let you quickly view the component's current state, fault status, and pertinent configuration data.

Please refer to the Operator's Guide for detailed information about calling up, navigating, and viewing Station displays.

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

12.16 Foundation fieldbus detail displays/faceplates

A new set of Detail Displays and faceplates are created for the Foundation Fieldbus control points. The FF Detail Displays and faceplates are designed to display only the standard FF parameters.

This feature is applicable to the following Foundation Fieldbus control points.

- PID (Proportional Integral Derivative)
- AI (Analog Input)
- DO (Digital Output)
- DI (Digital Input)
- AO (Analog Output)
- MAI (Multiple Analog Input)

Note that the FF Detail Displays and faceplates are not applicable for mixed modes (FF AI -> CEE PID -> FF AO).

Refer to the following documents for more information:

- *HMIWeb Display Building Guide* for more information on creating displays.
- *Server and Client Configuration Guide* for more information on configuring faceplates.

12.16.1 Naming conventions for Detail Displays

You need to follow the conventions such as block name, Point Detail Display, and Group Detail Display to view the FF Detail Displays.

The following table lists the conventions to be followed to view the FF Detail Displays.

Block name	Point detail display	Group detail display
AI	sysdtlffaia	sysdtlffai_fp
AO	sysdtlffaoa	sysdtlffao_fp
DI	sysdtlffdia	sysdtlffdi_fp
DO	sysdtlffdoa	sysdtlffdo_fp
PID	sysdtlffpida	sysdtlffpid_fp
MAI	sysdtlffmaia	sysdtlffmai_fp

12.16.2 Detail Displays contents based on FF control points loading

The FF control points can be loaded to FFLINK environment or CEE (C300 or C200) environment. However, the contents in the Main tab display vary based on whether the point is loaded to the CEE environment or to the FFLINK.

12.16.3 Tabs of FF Detail Displays

Refer to the *Operator's Guide* for additional details on using the Station and calling up the displays.

The following table lists the different tabs that appear in FF Detail Displays and a short description of each tab.

Detail Displays tab name	Description
Main Tab Display	<p>This page displays the Control Module-related information based on the following:</p> <ul style="list-style-type: none"> Point is loaded to CEE environment. Point is loaded to FFLINK. <p>Depending on how the point is loaded, some of the group headings and their related parameters appear on the page accordingly.</p> <p>For example when the point is loaded in CEE environment, the following headings appear on the page:</p> <ul style="list-style-type: none"> Execution & Control Alarm Enable & Summary Assigned Controller <p>Similarly, when the point is loaded to FFLINK, the following headings appear on the page:</p> <ul style="list-style-type: none"> Device & Simulation State Alarm Summary Assigned Module
IO/Status Options Tab Display	This page contains the options that you can select for altering the Input and output block processing and the block processing status.
Alarms Tab Display	This page can be used for configuring alarms, trip points and priority/severity. You can enter a value between 0 - 15 as alarm priority which is the standard for FF. Based on the priority, the associated alarm is logged in the Alarm Summary.
Connection Tab Display	This page displays the names of the Point Detail Display, Group Detail Display, and associated display that are associated with the specific block.
Chart Tab Display	This page displays the chart display of the loaded block.
Tuning Tab Display	This page displays the Out value and Readback values that are plotted with Y-axis units as %. This page also provides various configurable options for plotting the trend.
Loop Tune Tab Display	This page displays the Out value, SP value, PV value, Readback value that is plotted with Y-axis units as %. Integral tuning time units are displayed both in minutes and seconds. The master value is edited in minutes and seconds and displayed as read-only parameter value and they support upto 2 decimal points. This page also provides various configurable options for loop tuning.
Set Point	This page displays the set point input ranges and set point ramping values. This page provides various configurable options for status and control.
PV & OP Tab Display	This page displays the process variable ranges and its status. This page also provides various configurable options for control, output ranges, clamping/ filtering values, and track scale.

12.16.4 Detail Displays tabs of the different Foundation Fieldbus blocks

Not all tabs appear for all FF blocks. Use the following table to determine the tabs that appear for each FF blocks.

FF Blocks Versus Tabs	PID	AI	AO	DI	DO	MAI
Main	X	X	X	X	X	X
Tuning	-	-	X	-	-	-

Loop Tune	X	-	-	-	-	-
Alarms	X	X	-	-	-	-
Connection	X	X	X	X	X	X
Chart	X	X	X	X	X	-
I/O status Option	-	-	X	X	X	X
Set Point	X	-	-	-	-	-
PV & OP	X	-	-	-	-	-

The following figure displays a sample FF PID Main tab detail display when the point is loaded in CEE environment.




Figure 24: FF PID Main Tab Detail Display when loaded in CEE Environment.

The following figure displays a sample FF PID Main tab Detail Display when the point is loaded to FFLINK.




Figure 25: FF PID/Main Tab Detail Display when loaded to FFLINK.

12.16.5 Common functionalities of faceplates

There are a few common functionalities that are applicable to one or more FF point faceplates. Refer to the *Server and Client Configuration Guide* for more information on configuring faceplates. The following table lists the common functionalities and the applicable FF point faceplates.

Functionality	Applicable faceplate
Mode Attribute Interpretation	<ul style="list-style-type: none"> sysdtlffai_fp.htm systdlffao_fp.htm sysdtlffpid_fp.htm sysdtlffdi_fp.htm sysdtlffdo_fp.htm sysdtlffmai_fp.htm
Intermediate EU values	<ul style="list-style-type: none"> sysdtlffai_fp.htm systdlffao_fp.htm sysdtlffpid_fp.htm

Functionality	Applicable faceplate
Off Normal Mode Indication on faceplates	<ul style="list-style-type: none"> • sysdtlffai_fp.htm • sysdtlffao_fp.htm • sysdtlffpid_fp.htm • sysdtlffdi_fp.htm • sysdtlffdo_fp.htm • sysdtlmai_fp.htm
PV Alarm Limits 13.16.6	<ul style="list-style-type: none"> • sysdtlffai_fp.htm • sysdtlffpid_fp.htm
READBACK Value	<ul style="list-style-type: none"> • sysdtlffpid_fp.htm • sysdtlffao_fp.htm
Auto selection 13.16.7	<ul style="list-style-type: none"> • sysdtlffpid_fp.htm • sysdtlffao_fp.htm • sysdtlffai_fp.htm • sysdtlffmai_fp.htm • sysdtlffdi_fp.htm • sysdtlffdo_fp.htm

12.16.6 FF Detail Displays example templates for Control Builder

FF Detail Displays example templates for Control Builder are installed as part of Experion installation. These templates can be found in the following location: *C:\Program Files\Honeywell\Experion PKS\Engineering Tools\Examples\FF Blocks*.

These example templates are not supported for MAI block as it is not supported as a standard block in the Control Builder.

Importing FF Detail Displays example templates into Control Builder

You can import FF Detail Displays example templates into Control Builder from the following location: *C:\Program Files\Honeywell\Experion PKS\Engineering Tools\Examples\FF Blocks*.

<https://mansi@cam.ac.uk/> and <mailto:manski@cam.ac.uk> +86 18030205725

12.17 Using Station event summary display

Like the Detail displays, the Station Alarm and Event Summary displays support the integration of Fieldbus generated notifications and events. It is integrated with Experion component data and is for the most part self-explanatory. Use the Event Summary display to get a quick review of recent actions that have been initiated within the system.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

<https://maxautoland.com/>
manski@cambodia.cn +86 18030205725

13 Experion PKS Host Registration with Foundation Fieldbus

Foundation Fieldbus is non-profitable organization consisting of leading process end users and automation companies. Within the Fieldbus Foundation, end users, manufacturers, universities and research organizations work together to develop an automation infrastructure that provides process integrity.

Experion is a registered host with Foundation Fieldbus organization (www.Fieldbus.org). The registration of Experion Host with Foundation Fieldbus provides Experion users the benefits of the following additional features.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205715

13.1 New features

The following new features are supported.

- Conditional evaluation support for Fieldbus function blocks in Control Builder.
- Support for EDDL (Electronic Device Description Language) and visualization constructs.
- Support for Persistent Data Handling.
- Support for EDDL and visualization constructs for FF devices.
- Support for FF devices with Multi-capability feature.
- Advanced diagnostic support for FF devices.

As part of the Experion Host registration with FF, following is a complete list of features supported by Experion.

Feature	Description
<i>Foundation H1 Device Support</i>	
H1 Device Address Assignment	The capability of setting or clearing the H1 link address of an FF device. Devices with cleared addresses appear at available temporary addresses. They are not actually set to those addresses.
Configuration of Link Master Devices	The capability to prepare and write (Network Management Information Bus) NMIB and (System Management Information Bus) SMIB parameters associated with link mastership.
H1 Physical Device Tag Assignment	The capability to set or clear the physical device tag of an FF device.
Convert Link Master to Basic Device	The capability to change FF devices from Link Master to Basic class.
H1 Software Download	The capability to download device software or firmware code via the H1 link.
<i>Distributed Application Support</i>	
Block Tag Configuration	The capability to change, write, or clear tags of resource block, transducer blocks, and function blocks within an FF device.
Block Instantiation	The capability to add blocks to and delete blocks from FF devices on the link using the FB_Action service.
Resource and Transducer Blocks	The capability to read and write (if writeable) all parameters in standard and enhanced resource blocks and all parameters in standard, enhanced, or custom transducer blocks.
Standard Function Blocks	The capability to read and write (if writeable) all standard parameters in standard and enhanced function blocks.
Enhanced Function Blocks	The capability to read and write (if writeable) all manufacturer-specific parameters of enhanced function blocks.
Custom Function Blocks	The capability to read and write (if writeable) all parameters, including manufacturer-specific parameters, in custom function blocks.
Configuration of scheduled Control function blocks	The capability to configure a distributed application including PID closed loop control across multiple field devices without host-based function blocks.
Function Block Linking and Publication Scheduling	The capability to interconnect output parameters with input parameters between any supported function blocks.
Function Block Execution Scheduling	The capability to schedule function blocks.
<i>Foundation Alert Configuration and Handling</i>	
Process Alert Configuration and Handling	The capability to configure the report VCR for process alert notifications and display or record the process alert notifications.
Process Alert Management Configuration	The capability to configure the report VCR for process alert notifications.

Feature	Description
Process Alert Handling and Confirmation	The capability to confirm and display or record the process alert notifications.
Device Alert Management Configuration	The capability to configure the report VCR for device alert notifications.
Device Alert Handling and Confirmation	The capability to confirm and display or record the device alert notifications.
Multi-bit Alert Support	The capability to utilize the multi-bit alarm capability.
<i>Device Description Support</i>	
DD Blocks and Parameters	<ul style="list-style-type: none"> • The capability to accept and utilize the definitions of blocks and their parameters from Version 4 DD files. • The requirement to support conditionals as restricted by the FF-901 specification. • The requirement to support devices with multi-capability feature.
DD v4 Methods execution	The capability to select and execute any DD method against its associated block.
DD v4 Menus	The capability to display and navigate through menus as defined in a DD.
DD v5 Visualizations, Methods	<p>The capability to display and navigate through enhanced menus that contain charts, graphs, images, grids, and so on as defined in a DD. The capability to select and execute any DD method against its associated block.</p> <p>The capability to display and navigate through the menus as defined in a DD is also available at the field device level.</p>
DD v5 Persistent data	The capability to persist data as utilized by version 5 DDs.
Capability File Support	The capability to import a Capability File for offline configuration.

<https://maxautoland.com/>
 manski@cambid.com.cn +86 150 200 51713

13.2 Conditional support for FF devices

Conditionals are a set of rules that define or affect the parameter attributes like display format, validity, handling, minimum value, maximum value and so on. When you modify the default value of a parameter, the other parameter's attribute, which are conditionally affected by this parameter, also changes.

To support Conditional evaluation, the Parameter Definition Editor (PDE) is enhanced in Control Builder.

For more information, see Parameter Definition Editor Reference.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

13.3 About EDDL

Electronic device Description Language (EDDL) technology is used by major manufacturers to describe the information that is accessible in devices and it helps to define universal visualization information for the devices. The EDDL technology for FF Devices in Control Builder appears in the **DD View** tab. The DD View of the device and device function blocks are based on the visualization data present in the DD files.

DD View is available in configuration form of Project view, Monitoring view, and in PDE.

For more information, refer to the Parameter Definition Editor Reference.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

13.4 About DD View tab

The **DD View** tab is a new tab that appears in the configuration form of the FF blocks and FF devices. In this tab, you can view parameter values, configure parameter values, visualize graph, charts, and images and execute methods in monitoring mode only. Hence, you can visualize the complete layout of the EDDL for the selected FF block and FF devices. This tab appears only for those blocks/FF devices that support EDDL technology.




Figure 26: PDE view

For more information, see Parameter Definition Editor Reference.

On the FF block/FF devices configuration form, **DD View** tab appears only if the imported DD files have the EDDL and visualization constructs like menus, charts and so on. On the **DD View** tab, parameters and its values appear.




Figure 27: DD View tab of FF blocks




Figure 28: DD View tab of FF devices


Attention










- The **DD View** tab of an FF device contains parameters/methods of its FF blocks.
- On the Monitoring view, the DD-View tab reflects the field values.
- Conditionals cannot be evaluated on the Project and Monitoring views.

Following are some of the considerations for FF blocks and FF devices with DD View.

- The **DD View** tab appears as the first tab for all the FF blocks and FF devices, which support EDDL technology.
- The **DD View** tab consists of two panes, left pane and right pane. The left pane consists of menus to navigate to the appropriate page and the right pane consists of items like image, charts, graphs, methods, parameters and so on that appear as page.
- The left pane has an autohide feature so that you can view the contents completely in the right pane. However, when you hover the cursor on the pane, the hidden pane appears.
- Tool tip appears for all controls and methods that are available in the EDDL features such as menus, charts, graphs, and so on.
- Tool tip consists of information on parameter name, parameter description and unit if available.

The following table consists of toolbars and its descriptions.

Toolbar	Description
	To automatically hide the left pane. When you hover the mouse on the left pane, the hidden pane appears.

Toolbar	Description
	To navigate towards left of the tabs.
	To navigate towards right of the tabs.
	To identify button, which consists of methods.
	To zoom out
	To zoom in
	To zoom and view at a fixed point
	To copy to clipboard
	To save the changes
	To print the page

<https://maxautol.com/>
 manski@cambid.com +86 180 30205725
 manski@cambid.com

13.5 Multi-capability support for FF devices

You can configure a capability level for those FF device templates that support multi-capability levels. The configured capability level of a device is contained in the DD file and the level is suffixed in the device template name.

Note: A template represents a single device capability level. However, if you want to import a device with different capability level, then you have to create one template for each of the capability level.

While importing an FF device DD file, the details of capability levels supported by the device are displayed.

For example, consider to import the device “EJX_0303,” which supports 3 levels of capability. If you import this device by selecting the capability level as “2,” then it indicates that this device is imported with capability level “2” and the device appears as “EJX_0303_2.”

Note: The capability level of a device is also displayed in the Capability Level column under the Device Match dialog tab, only if the device supports Capability Level parameter, while matching an uncommissioned device to a Project device.

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

13.6 About Field Diagnostic support

The Field Diagnostic support for FF devices provides the ability to monitor the device status using the standard diagnostic parameters.

You can generate alarms, based on the conditions that are configured. These conditions are vendor-defined aggregations of device diagnostics that are individually generated in a device and displayed in Experion.

Following are the different types of Field Diagnostic parameters.

- MAP: Parameter for enabling alarm detection
- ACTIVE: Parameter for indicating alarms.
- ALM: Parameter for maintaining alarm broadcast record.
- MASK: Parameter for enabling alarm broadcast.
- PRIORITY: Parameter for setting priority for each alarm category.

Following are the Field Diagnostics alarm categories that are available.

- Failure: Output signal is invalid because of a malfunction in the field device or its peripherals.
- Off-Specification: The device operates outside the specified range or an internal diagnostic indicates deviations from measured values due to internal problems in the device or process characteristics. For example, bubble formation in flow metering or valve sticking.
- Maintenance: Although the output signal is valid, the wear reserve exhausts or a function is restricted due to operational conditions. For example, built-up of deposits.
- Check function: Output signal is temporarily invalid due to on-going work on the device.




Figure 29: Field Diagnostics tab with alarm parameters




Figure 30: Field Diagnostics tab with Active parameters




Figure 31: Field Diagnostics tab with Mask parameters

https://maxautol.com/1899205725
manski@cambia.cn




Figure 32: Field Diagnostics tab with Map parameters

13.7 Parameter definitions

Following are the various parameters that are available at the device level. These parameter definitions are similar to all Field Diagnostic categories.

- **MAP** parameter: This parameter maps conditions to be detected as active for the alarm category. If the alarm condition occurs, then the alarm record will not be updated unless we have not masked the parameter.
- **ACTIVE** parameter: This parameter displays the error conditions that are currently indicated as active. The ACTIVE parameter would indicate issues only if the corresponding MAP bits are ON.

Consider an alarm condition “Network failure.” If you map this parameter, then when the network failure is detected, the alarm condition will be displayed in the alarm record and the parameter is broadcasted as active.

- **MASK** parameter: This parameter allows you to broadcast single or multiple conditions that are active. Therefore, when you mask an alarm condition, the condition is not broadcasted through the alarm.
- **PRIORITY** parameter: This parameter allows you to specify the priority of the alarm category. Based on the priority set, the mapped alarm condition will be broadcasted in Station as an event or alarm.

Field diagnostics alarm priority is similar to Experion Alarm Priority. For more information, see “Fieldbus versus Experion Alarm Priorities” on page 312

- **ALM** parameter: This parameter is used primarily to broadcast a change in the associated active conditions, which are not masked for this alarm category. When a particular alarm condition occurs, then the alarm details such as, timestamp, subcode and value is displayed in the alarm record.

Considerations

Following are the considerations for configuring diagnostic parameters.

- Using FD_XXX_PRI parameter, you can set the priority of Field Diagnostic alarms of corresponding category.
- Each condition is evaluated at the device level to generate alarms.
- Each condition can be mapped or not mapped for each category using FD_XXX_MAP parameter.
- If the condition in the ACTIVE parameter is not masked by the corresponding bit in the MASK parameter, then the condition will be queued for broadcast using the ALM parameter.
- You can view the alarm information such as, alarm status, and the time of alarm generation, values, and sub code using alarm parameter.
- Each of the categories, share 32 conditions that can be defined by the device.
- An alarm condition is displayed as active, if a particular condition is mapped and the alarm for that condition is generated in the device.

13.8 Persistent data handling

For some devices, the condition and performance cannot be determined empirically. For such devices, the relative performance is the indicator of the device condition and the file constructs of the device blocks helps to resolve this.

! Attention

- When creating a device template under the FIM link, a message appears displaying the information that the file information is lost if the template details are replaced.
-

The file operations are supported per instance of the device and it is applicable to both Project mode and Monitoring mode.

For example: If a device block refers to a File_TC_001 then this same file is referred in the Project and Monitoring modes with the latest values available.

<https://maxautoland.com/>
manski@cambid.com +86 18030205725

14 Series C FIM4/FIM8 maintenance

This section provides information about maintaining the Series C FIM. The following table lists the topics included in this section. If you are viewing this information online, just click the topic title to jump to the information location.

Topic
“Periodic checks” on page 211
“Recommended spare parts” on page 212
“Series C FIM4/FIM8 removal and installation under power” on page 213
“Replacing device template with a different one” on page 214
“Replacing failed Series C FIM4 CC- or CU-PFB401” on page 221
“Replacing IOTA DC-TFB402 or DC-TFB412, CC-or CU-TFB401, CC-or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412” on page 222
“Relocating Series C FIM4/FIM8 or reassigning IP address” on page 224
“Upgrading firmware in uncommissioned device” on page 225
“Replacing a failed device with a like device having the same model name and device revision” on page 226
“Replacing a failed device with a different device using a different block type” on page 227
“Unlike device replacement report” on page 229
“Preparing Fieldbus device for a move or software migration” on page 232
“Using fieldbus device simulate function” on page 234
“Checking fieldbus device calibration” on page 236

Related topics

- “Periodic checks” on page 211
- “Recommended spare parts” on page 212
- “Series C FIM4/FIM8 removal and installation under power” on page 213
- “Replacing device template with a different one” on page 214
- “Correcting some common UTR errors” on page 220
- “Replacing failed Series C FIM4 CC- or CU-PFB401” on page 221
- “Replacing IOTA DC-TFB402 or DC-TFB412, CC-or CU-TFB401, CC-or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412” on page 222
- “Relocating Series C FIM4/FIM8 or reassigning IP address” on page 224
- “Upgrading firmware in uncommissioned device” on page 225
- “Replacing a failed device with a like device having the same model name and device revision” on page 226
- “Replacing a failed device with a different device using a different block type” on page 227
- “Unlike device replacement report” on page 229
- “Changing or clearing tag and/or address of uncommissioned device” on page 231
- “Preparing Fieldbus device for a move or software migration” on page 232

“Using fieldbus device simulate function” on page 234

“Checking fieldbus device calibration” on page 236

<https://maxautoland.com/>
manski@cambiala.cn +86 18030205725

14.1 Periodic checks

The following table identifies checks that you should make periodically (every 3 to 6 months) to keep the Series C FIM4/FIM8 in good working condition.

Check . . .	Possible Corrective Action . . .
That all segments of the 4-character display and the light emitting diodes (LED) on Series C FIM4/FIM8 and IOTA are working.	If segment or LED is not lit or has dimmed, you must replace the Series C FIM4/FIM8 or IOTA, since front-panel indicators and LEDs are not field replaceable.
That all connections are secure.	Secure connections, as needed.
That cable insulation is not worn or cracked.	Replace cables, as required.
That IOTA is secure.	Tighten mounting screws.

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

14.2 Recommended spare parts

The following table provides a list of parts that you may want to keep on hand for backup.

Part Name	Part Number	Description	Quantity per 10/100
Series C FIM4	CC- or CU-PFB401	Series C Fieldbus Interface Module	1/5
Series C FIM8	CC-PFB801	Series C Fieldbus Interface Module	
Non-Red. IOTA (FIM4)	CC- or CU-TFB401	Non-Redundant Input Output Terminal Assembly	1/2
Non-Red. IOTA (FIM4)	CC- or CU-TFB402	Non-Redundant Input Output Terminal Assembly - Supersedes CC/CU-TFB401 in row above.	1/2
Red. IOTA (FIM4)	CC- or CU-TFB411	Redundant Input Output Terminal Assembly	1/2
Red. IOTA (FIM4)	CC- or CU-TFB412	Redundant Input Output Terminal Assembly- Supersedes CC/CU-TFB411 in row above.	1/2
Red. IOTA (FIM8)	CC-TFB811	Redundant Input Output Terminal Assembly	
Fuse (FIM4/FIM8)	51506348-341	800 mA, quick-acting fuse on Input Output Terminal Assembly	4/25
Fuse Holder (FIM4/FIM8)	51506443-100	Fuse holder on Input Output Terminal Assembly	2/10
Connector (FIM4/FIM8)	51506471-202	Plug-in connector for H1 link field wiring	4/15
Pwr Conditioner IOTA (FIM4/FIM8)	F660A, or F860	Redundant Power Conditioner Input Output Terminal Assembly (Optional - order from vendor MD-Relcom)	1/2

<https://maxautoland.com/>
 manski@cambiala.cn +8618930205125

14.3 Series C FIM4/FIM8 removal and installation under power

The Series C FIM4/FIM8 has been designed to permit removal and installation under power (RIUP) without damaging the module or interrupting IOTA communications.

Please review the Removal and Insertion Under Power (RIUP) Function Guidelines in the *Control Hardware Installation Guide* before you RIUP any module.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

14.4 Replacing device template with a different one

Use the following procedure to replace one or more instances of the same Fieldbus device type with a different device type.

Following are the considerations for replacing device template with a different one

- You have created a replacement/different Fieldbus device type in the **Library** tab of Control Builder.
- The Unlike Template Replacement wizard will guide you through the following replacement operations.

Select device instances to replace,

Select the replacement device type,

Initiate validation of the replacement for each device instance selected,

Initiate replacement of the selected instances, and

Display errors and warnings as appropriate.

- The wizard validates whether the replacement of a certain device instance with the selected device type is acceptable. Errors and/or warnings may be generated during this operation.
- The wizard performs the replacement of each selected instance with the selected device type. Errors and/or warnings may be generated during this operation.
- If you are using the Qualification and Version Control System, the wizard automates all required QVCS operations. In general, the operational requirements of QVCS must be followed, regardless of whether the user is making changes to the configuration or whether the system makes changes automatically.
- The contents of the original device's resource block are retained when the replacement is completed. Any transducer blocks in the original device that match those in the replacement device have their contents retained.
- Fixed function blocks can match with instantiable blocks of the same basic type, and vice-versa. When a replacement device contains both fixed and instantiable blocks, for the same basic block preference is given to the fixed block(s) first, and then followed by the instantiable blocks. This allows fixed blocks to be allocated in the replacement device before instantiable blocks need to be created.

Prerequisites

- You have logged onto Control Builder with sufficient security level to make control strategy changes.
- You have created Fieldbus device types.


To use Unlike Template Replacement wizard to make device replacements

- 1 All the illustrations used in the following procedure are for example purposes only.
- 2 In the **Project** tab, select the Fieldbus device you want to replace. Use CTRL +click to select multiple devices.


OR

In the **Library** tab, select the device type to be replaced.


- 3 In the **Device** menu, click **Unlike Template Replacement** to launch the wizard.
(You can also right-click on device and select **Unlike Template Replacement** from the list.)



- 4 Check that all selected devices or instances of selected device type are listed in the **Available Controls** column. Select device(s) in the column and click **Select** to move selected devices to the **Selected Controls** column. Or, just click **Select All** to move all the listed devices to the **Selected Controls** column.
(Use **Remove** or **Remove All** to remove one selected or all devices from the **Selected Controls** column, as needed.)
- 5 On the right side of the dialog, select the **Show only Same Device Models** or **Show all FF Device Types** to tailor what devices are shown in the **Tree View** and **List View** tabs below.
- 6 In the **Tree View** or **List View** tab, select the replacement device.




7 Click **Next** to call the **Validation** page.



8 Click **Validate** to initiate the validation function.

- 9 Wait for the validation process to be completed one device at a time. Note any errors or warnings that may be displayed. Only devices with no errors will be enabled for replacement.
(Click **Cancel** to exit the operation and start over after making any necessary corrections.)
- 10 Check the check box in the **Select** column to select the device for replacement. All devices that passed validation are automatically selected, and those that failed cannot be selected.



- 11 If error or warning messages appear in the Validation Results list box, click **View Replacement Log** to call up the FF_UTR_Log to review validation results.
- 12 Click **Next** to call up the **Replace Device** page.

https://mohautoland.com/8030205725
manski@campus.cn +86

Old Device Template: HONEYWELL-ST3000FF_0801

New Device Template: YOKOGAWA-ELECTRIC:EJA100A_0201

Index	Selected Control	Status
1	ST3000FF_080_181	Not Replaced
2	ST3000FF_080_240	Not Replaced
3	ST3000FF_080_245	Not Replaced
4	ST3000FF_080_250	Not Replaced

Status: Click on Replace Device to start Replace Device Operation

Unlike Template Replacement Results (Select grid entry to view UTR results)

View Replacement Log

< Back Replace Device Cancel

- 13 Confirm that the devices to be replaced are listed in the **Summary** list box.
- 14 Click **Replace Device** to initiate the replacement function.
- 15 Wait for the replacement process to be completed sequentially one device at a time. Note any errors or warnings that may be displayed. Only devices with no errors will be replaced.
(Click **Cancel** to exit the operation and start over after making any necessary corrections.)
- 16 Check that the Status for each selected control turns to Replaced, when the function is completed.

Replace Device

Old Device Template: HONEYWELL:ST3000FF_0801

New Device Template: YOKOGAWA:ELECTRIC:EJA100A_0201

Index	Selected Control	Status
1	ST3000FF_080_181	Failed
2	ST3000FF_080_240	Failed
3	ST3000FF_080_245	Failed
4	ST3000FF_080_250	Failed

Status: Replacement Complete

Unlike Template Replacement Results (Select grid entry to view UTR results)

Block: is in an invalid lifecycle state [EXPKS_E_CL_INVLCYCST (4L.101.10110)]

View Replacement Log

< Back DONE Cancel

- 17 If error or warning messages appear in the Unlike Template Replacement Results list box, click **View Replacement Log** to call up the FF_UTR_Log to review replacement results. If the message includes an error code reference, refer to the *Control Builder Error Code Reference* document for more information. For example, if the message includes a reference like, [EXPKS_E_CL_INVLCYCST (4L.101.10110)], the last five digits (10110) represent the error code.
- 18 Click **DONE** to close the wizard. If applicable, correct any errors and repeat the procedure.

<https://maxautomation.com/>
 manski@cambria.com +855 78030205725

14.5 Correcting some common UTR errors


The following table identifies some common errors that may occur during an UTR operation and offers some suggested corrective action.

If You Encounter This Problem . . .	Then, Take This Corrective Action . . .
Device is loaded to Monitoring side of Control Builder	Delete the device from Monitoring side. Use the Force Delete function, if necessary. This may also require the device's blocks to be deleted from the Control Module on the Monitoring side.
Device is locked	Locate the source of the lock.
Block loss with control connections	<ul style="list-style-type: none"> • Select another Fieldbus device type for replacement, which can support all blocks that have connections. • Change the control strategy to eliminate the control connection(s) to the block that does not match.
Insufficient VCR's	<ul style="list-style-type: none"> • Select another Fieldbus device type that has a sufficient number of resources. • Alternatively (although not recommended since the intended results may be difficult to obtain), the user may also modify the control strategy to reduce the number of resources required. This may work, although the user may have to go through several rounds of trial and error before eliminating the error.
Insufficient FB Start Entries	
Insufficient Link Objects.	

<https://maxautol.com/>
 manski@cambid.com
 +86 1803451725


14.6 Replacing failed Series C FIM4 CC- or CU-PFB401

Use the following procedure as a guide for replacing a failed Series C FIM4/FIM8.

 CAUTION	<p>We recommend that you proceed with extreme caution whenever replacing any component in a control system. Be sure the system is offline or in a safe operating mode.</p> <p>Component replacements may also require corresponding changes in the control strategy configuration through Control Builder, as well as downloading appropriate data to the replaced component.</p>
--------------------------------------------------------------------------------------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Following are the considerations for replacing failed Series C FIM CC- or CU-PFB401

- You can remove and install the Series C FIM4/FIM8 under power.
- Be sure you take ESD hazard precautions when handling the Series C FIM4/FIM8 and IOTA. See the “Installation declarations” on page 32 section for more information.

 CAUTION	<p>Only use a #2 Phillips screw driver to carefully loosen or tighten the long gray plastic screw on the Module's face. Do not use either a #1 Phillips screw driver or a battery powered screw driver to remove or install the plastic screw as this can damage the screw head.</p>
--------------------------------------------------------------------------------------------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Prerequisites

You have logged onto Control Builder with sufficient security level to make control strategy changes.

To replace failed Series C FIM CC- or CU-PFB401

- 1 Loosen the screws that hold the Series C FIM4/FIM8 to the IOTA and remove the Series C FIM from its connector on the IOTA.
(It is not necessary to completely remove the long gray plastic screw located on the module's face.)
- 2 Install the new Series C FIM4/FIM8 on its connector on the IOTA and tighten the screws.
- 3 Monitor the front-panel 4-character display to confirm that the Series C FIM receives its IP address and starts running. If this is a redundant configuration, the Series C FIM starts in a secondary role. See Series C FIM4/FIM8 Startup for more information.
- 4 Use the **CTool** utility to check that the firmware revision of the new Series C FIM4/FIM8 is the correct one for your application.
 - If firmware revision is correct, go to Step 6, if the Series C FIM is non-redundant; or go to Step 5, if it is redundant.
 - If firmware revision is not correct, go to the “Upgrading Series C FIM4/FIM8 firmware” on page 56 section and then return to Step 5, if Series C FIM is redundant; or Step 6, if it is non-redundant.
- 5 Command the primary Series C FIM to synchronize the secondary Series C FIM through the FIM4 block parameters form in the **Monitoring** tab of Control Builder.
- 6 Load the block from **Project** tab.

14.7 Replacing IOTA DC-TFB402 or DC-TFB412, CC-or CU-TFB401, CC-or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412

Use the following procedure as a guide to replace a non-redundant or redundant IOTA.

Following are the considerations for replacing IOTA CC-or CU-TFB401, CC-or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412

- You can replace a non-redundant IOTA with a redundant one, providing that mounting space is available and the Series C FIM has an odd Device Index number assignment.
- Be sure you take ESD hazard precautions when handling the Series C FIM and IOTA. See the “Installation declarations” on page 32 section for more information.



CAUTION

This caution is not applicable for Series C Mark II.

- The screws in the **24V +** and **COM** terminals can bind during installation or removal, if the IOTA mounting screws are fully secured before the 24V/COM screws are secured/removed.
- Only use a #2 Phillips screw driver to carefully loosen or tighten the long gray plastic screw on the Module's face. **Do not use** either a #1 Phillips screw driver or a battery powered screw driver to remove or install the plastic screw as this can damage the screw head.

Prerequisites

- You have reviewed the previous CAUTION note.
- You have logged onto Control Builder with sufficient security level to activate/inactivate components.

To replace replacing IOTA CC-or CU-TFB401, CC-or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412

- 1 You may want to inactivate the associated FFLinks through the **Monitoring** tab in Control Builder first, since view of the process will be lost while the IOTA is being replaced
- 2 Record the Device Index number set on the binary coded decimal (BCD) switches on the IOTA.
- 3 Tag and remove the H1 link connections from connectors on the IOTA.
- 4 Remove the FTE cables from IOTA connectors.
- 5 Loosen the screws holding the non-redundant or Primary Series C FIM to the IOTA. Remove the Series C FIM4/FIM8.
(It is not necessary to completely remove the long gray plastic screw located on the module's face.)
- 6 If you are replacing a redundant IOTA, loosen the screws holding the Secondary Series C FIM4/FIM8 to the IOTA. Remove the Series C FIM4/FIM8 and be sure you can identify it as the Secondary Series C FIM4/FIM8. Otherwise, go to the next Step.
- 7 Loosen the IOTA mounting screws **half way**.
- 8 Remove the screws from the **24V** and **COM** terminals to disconnect the IOTA from the power bus bars.
- 9 Remove mounting screws, spacers, washers, and remove the IOTA.
 - Be sure component side of replacement IOTA is facing up. Secure IOTA to carrier using screws, washers and spacers provided.
 - Insert spacers and washers between bottom of IOTA and top of carrier.
 - Only tighten mounting screws half way.
- 10 Tighten screws in **24V** and **COM** terminals to connect the IOTA to the power bus bars.
- 11 **Fully** tighten the mounting screws.
- 12 Set the BCD switches to the value noted in Step 2.
- 13 Connect H1 link connections to connectors on IOTA as noted in Step 3.

- 14 Connect FTE Cables to appropriate connectors on the IOTA.
- 15 Install non-redundant Series C FIM or Primary Series C FIM on top connector on a redundant IOTA. Tighten screws to hold Series C FIM to IOTA.
- 16 If you are replacing a redundant IOTA, install Secondary Series C FIM on lower connector on IOTA. Tighten screws to hold Series C FIM to IOTA.
- 17 Check front-panel display to confirm operational state of the Series C FIM.
- 18 If necessary, load FIM4 block from **Project** and activate FFLinks in **Monitoring** mode.

To replace replacing IOTA DC-TFB402 or DC-TFB412

- 1 You may want to inactivate the associated FFLinks through the **Monitoring** tab in Control Builder first, since view of the process will be lost while the IOTA is being replaced
- 2 Record the Device Index number set on the binary coded decimal (BCD) switches on the IOTA.
- 3 Tag and remove the H1 link connections from connectors on the IOTA.
- 4 Remove the FTE cables from IOTA connectors.
- 5 Loosen the screws holding the non-redundant or Primary Series C FIM to the IOTA. Remove the Series C FIM4/FIM8.
(It is not necessary to completely remove the long gray plastic screw located on the module's face.)
- 6 If you are replacing a redundant IOTA, loosen the screws holding the Secondary Series C FIM4/FIM8 to the IOTA. Remove the Series C FIM4/FIM8 and be sure you can identify it as the Secondary Series C FIM4/FIM8. Otherwise, go to the next Step.
- 7 Remove the combo cable to disconnect the IOTA.
- 8 Loosen the IOTA mounting screws.
- 9 Remove mounting screws, spacers, washers, and remove the IOTA.
 - Be sure component side of replacement IOTA is facing up. Secure IOTA to carrier using screws, washers and spacers provided.
 - Insert spacers and washers between bottom of IOTA and top of carrier.
 - Only tighten mounting screws half way.
- 10 Connect the combo cable to the IOTA.
- 11 **Fully** tighten the mounting screws.
- 12 Set the BCD switches to the value noted in Step 2.
- 13 Connect H1 link connections to connectors on IOTA as noted in Step 3.
- 14 Connect FTE Cables to appropriate connectors on the IOTA.
- 15 Install non-redundant Series C FIM or Primary Series C FIM on top connector on a redundant IOTA. Tighten screws to hold Series C FIM to IOTA.
- 16 If you are replacing a redundant IOTA, install Secondary Series C FIM on lower connector on IOTA. Tighten screws to hold Series C FIM to IOTA.
- 17 Check front-panel display to confirm operational state of the Series C FIM.
- 18 If necessary, load FIM4 block from **Project** and activate FFLinks in **Monitoring** mode.

14.8 Relocating Series C FIM4/FIM8 or reassigning IP address

The following procedure outlines how to prepare a Series C FIM4/FIM8 for relocation to another network or assigning a new device index and IP address.

Following are the considerations for resetting device index and IP address

- You can remove and install the Series C FIM4/FIM8 under power. See the previous **Warning** before doing so.
- Be sure you take ESD hazard precautions when handling the Series C FIM4/FIM8 and IOTA. See the “Installation declarations” on page 32 section for more information.
- The Series C FIM4/FIM8 retains its assigned IP address in non-volatile storage, which means it must be erased before a new address can be assigned.
- If you are working with a redundant Series C FIM4/FIM8 pair, the device index and IP address will be reset in both the Primary and Secondary modules. The node number for a device is dynamically assigned. The primary device in a redundant pair always has an odd node number. The node number is actually the IP address minus the Base IP Address set through **System Preferences** in Control Builder. The Device Index number is set on the Binary Coded Decimal switches on the device's IOTA.
- For a redundant Series C FIM4/FIM8 application, be sure to set the Device Index to be an odd number. The odd number will be used for the primary Series C FIM and a one (1) will be added to the number to be used as a device index for the secondary Series C FIM. For example, if you set the Device Index to 17 for the primary Series C FIM, the Device Index for the secondary Series C FIM would be 18.
- We recommend setting the Device Index for a non-redundant Series C FIM application to an odd number also, so you can easily upgrade to a redundant Series C FIM application at a later date, if desired.
- After Device Index and IP address are reset, refer to the “Series C FIM4/FIM8 configuration” on page 61 and Loading FIM4/FIM8 Components Online sections in this book to configure and load the associated function blocks for the reassigned Series C FIM(s).

Prerequisites

- You have logged onto Control Builder with sufficient security level to make control strategy changes.
- Be sure the system is offline or in a safe operating mode.

To reset device index and IP address

- 1 Remove power from the IOTA containing the non-redundant Series C FIM pair to be reset.



Note

This is not applicable for redundant Series C FIM4/FIM8.

- 2 Locate the three binary-coded decimal rotary switches on the lower left side of the IOTA.
- 3 Use a small flat-bladed screwdriver or your thumbnail to set the left-hand switch (100) to zero (0), middle switch (10) to zero (0) and the right-hand (1) switch to zero (0).
- 4 Apply power to the IOTA. Wait for Series C FIM(s) to start up and confirm that 4-character display shows device index as **#000**.
- 5 Remove power from the IOTA.
- 6 Use a small flat-bladed screwdriver or your thumbnail to set the left-hand switch (100) to the desired most significant decimal number, middle switch (10) to the desired next most significant decimal number and the right-hand (1) switch to the desired least significant decimal number. The applicable setting range is 01 to 511.
- 7 Apply power to the IOTA. Wait for Series C FIM(s) to start up and confirm that 4-character display shows device index as **#nnn**. Where nnn equals the Device Index number set on the switches in Step 6. The IP address is assigned based on the new device index number.

14.9 Upgrading firmware in uncommissioned device

Use the following procedure to upgrade the firmware in an uncommissioned device through Control Builder.



CAUTION

Do **not** upgrade firmware in Honeywell model ST3000 or model STT35F, or Flowserve Logic 1400 devices on a running Fieldbus link. Be sure to take all devices on the link off control before upgrading firmware in a ST3000, STT35F, or LX1400 device.

Following are the considerations for initiating Firmware upgrade

If the **Load Firmware** button is inactive (grayed out) on the **Uncommissioned Devices** tab, try changing the device address to a lower number in the 30 to 40 range.

Prerequisites

- You have the vendor supplied upgrade file for the device.
- You are monitoring the FIM4/FIM8 /FFLINK through the **Monitoring** tab in Control Builder.

To initiate a firmware upgrade

- 1 Double-click the uncommissioned device icon to open the FFLINK Parameters form with the **Uncommissioned Devices** tab open.
- 2 Click **Load Firmware** to open the **Device Firmware Upgrade** dialog.
- 3 Click **Upgrade** to open the **Open** dialog.
 - Use the **Look In** box to navigate to the directory location that includes the vendor's upgrade file.
 - Select the file and click **Open** to initiate the firmware upgrade. This may take a few minutes to complete.
- 4 Once the firmware upgrade is completed, wait for the device to rejoin the network. This may take up to three minutes. Click the close button to close the dialog.
- 5 See the procedure to commission the device. Otherwise, click **OK** to close the form.

<https://maxautotrend.com/>
 manski@cambria.com +86-18030205725

14.10 Replacing a failed device with a like device having the same model name and device revision

Use the following procedure to replace a failed Fieldbus device with a like device having the same Model Name and Device Revision (DEV_REV).



Tip

A wizard will guide you through the device replacement process when you initiate the action through the device detail display in Station. In this case, you can ignore the following procedure.

Following are the considerations for replacing like device

- After the procedure, be sure you complete the device load before you return the system to normal operation.
- If you are replacing a device that includes **instantiated** blocks, you must re-load any Control Module and Sequential Control Module that include client/server connections to the blocks in the replacement device from the **Monitoring** tab before putting the device into operation. See “Replacing failed device that includes instantiable blocks with like device” on page 122 for more information.

Prerequisites

The system is offline or in a safe operating mode

To replace a like device

- 1 Disconnect the failed device from the Link. Fieldbus device icon turns red in **Monitoring** tab.
- 2 Right-click the failed device icon and select **Device Replacement** from the list to call up the **FFLINK Block Parameters** form with the failed device listed in the bottom half of the **Device Replacement Dialog**.
 - Connect the replacement Fieldbus device to the Link
 - Wait for the replacement device to appear as an Uncommissioned Device (UCD) listed in the top half of the **Device Replacement dialog**.
 - Click the check box to the left of the **Tag** column for the Replacement Device.
 - The **Replace the Failed Device with the Uncommissioned Replacement Device** button becomes active.
 - Click **Replace the Failed Device with Uncommissioned Replacement Device**.
 - Click **Continue** to acknowledge **Warning** prompt.
 - If another **Warning** prompt appears, the replacement device was previously matched to another device and the previous match will be undone, if you continue. Otherwise, go to the next Step.
 - **Progress** dialog appears to track the status of the replacement.
 - Wait for **Replacement Device Load Confirmation** dialog to appear. Click **Continue**. The **Load Dialog** for replacement device appears. It is normal for an error code (Err xxxx) to appear in the **Current State** column for the blocks.
- 3 Click the check boxes for the automatic state changes near the bottom of the dialog. Click **OK**. Load dialog appears to track progress of the load.
- 4 Once the load is completed, check the **Monitoring** tab to confirm that the device icon has turned green and function blocks are inactive (blue) or active (green) per the selected **Post Load State**.

14.11 Replacing a failed device with a different device using a different block type

Use the following procedure to replace a failed device with a different device using a different block type.



Attention

Starting with R400, you can generate an Unlike Device Replacement Report for an FF device. You can view the device-related information and the control Modules that would be affected by Unlike Device Replacement.

For more information on Unlike Device Replacement Report, see “Unlike device replacement report” on page 229.

Following are the considerations for replacing different device

- It is a good idea to record the Tag and Address assignments for the failed device before deleting it.
- It is a good idea to print out a parameters and connections report for a CM before you modify it. This will serve as a convenient configuration reference.
- You must unassign the given Fieldbus block from its associated device before you can delete the device from **Project**.
- If you unassign a Fieldbus block that has a RCAS_IN or ROUT_IN connection from a Experion block, be aware that the VCR that was formed when the connection was made is **not** removed when the block is unassigned. To remove this VCR, you must delete the block and then recreate it. The same is true, if you want to delete the RCAS_IN or ROUT_IN connection and re-wire it to the block's CAS_IN pin.
- Always initiate match from Project Device to UCD for replacement devices.

Prerequisites

- The system is offline or in a safe operating mode
- The template of the replacement device must be added using the device DD files.

To replace a different device

- 1 Optionally, inactivate any CMs that contain blocks associated with the failed device.
- 2 Disconnect the failed device from the Link. **Device** icon turns red in **Monitoring** tab.
- 3 In **Monitoring** tab, locate all Control Modules (CMs) containing Fieldbus blocks associated with the failed device. The associated Fieldbus block icons will be red.
- 4 Right-click the CM icon and select **Force Delete** from the list to open **Force Delete** dialog
- 5 Click **Delete Selected object(s)**. Deletion errors are displayed in the list box for the dialog. You can ignore these, since you know the failed device is off net.
- 6 Click **Close** to acknowledge any errors or skip this Step, if no errors are detected.
- 7 Repeat Steps 4 through 6 for other CMs, as required.
- 8 Right-click the failed device icon and select **Force Delete** from the list.
- 9 Click **Delete Selected object(s)**. Deletes Failed device from the **FFLink** folder in **Monitoring**.
- 10 In the Project tab, right-click on the selected device to select **Unlike Template Replacement (UTR)**. The Unlike Template Replacement Wizard appears.
- 11 Check for all the selected devices or instances of device type that are listed in **Available Controls**.
 - Select the device(s) in the column and click **Select** to move the selected devices to the **Selected Controls** column.

Or

- Click **Select All** to move all the listed devices to the **Selected Controls** column.





**Attention**

- Click **Remove** or **Remove All** to remove the selected devices or all the selected devices from the **Selected Controls** column.

- 12 On the right pane of the dialog box, click **Show only Same Device Models** or **Show all FF Device Types** to filter the devices in **Tree View** and **List View** tabs.
- 13 In the **Tree View** or **List View** tab, select the device template.
- 14 Click **Next**.
- 15 Click **Validate**.
The validation process starts for one device at a time.
Note: The selected devices must not have any errors to be enabled for replacement of the device.
- 16 Click **Next**.
The **Replace Device** dialog box appears with the list of devices to be replaced.
- 17 Click **Replace Device**.
The status of the selected devices changes to 'Replaced'.


**Attention**

- If an error/warning message appears in the **Unlike Device Replacement** dialog box then click **View Replacement Log** to open the FF_UTR_Log to review replacement results.

- 18 Click **Close**.
- 19 Switch back to the Monitoring tab, click the plus sign  for FIM4 icon to expose its associated links in tree hierarchy.
- 20 Click the plus sign  for the FFLink icon with an asterisks  to expose the uncommissioned device icon .
- 21 Double-click the uncommissioned device icon to open the FFLink Parameters form with the Uncommissioned Devices tab open.
- 22 Click **Match** to call up the Device Match dialog.
- 23 Click check box to left of **Tag** column for matching **Project Device**. Selects project device and activates the **Match** buttons.
- 24 Click **Match From Project Device to Uncommissioned Device**.
- 25 Click **Continue** to acknowledge Warning prompt about Tag/Address changes in UCD.
- 26 Wait for match to be completed and note that the UCD's Tag and Address now match the Project Device. Click **OK** to close the Match dialog.
- 27 In the Project tab, click FFLINK with new project device and click Controller->Load with Contents to call up the Load Dialog.
 - Ensure that the **Load** check boxes for components to be loaded are selected. Clear the check box to add/remove component as applicable.
 - Click **OK**.
- 28 Wait for load to complete and check that UCD changes to commissioned device, in Monitoring tab.
- 29 In Project tab, click CEE with reconfigured CM and click **Controller->Load With Contents** to call up **Load Dialog**.
 - Ensure that the **Load** check boxes for components to be loaded are selected. Clear the check box to add/remove component as applicable.
 - Click **OK**.
- 30 Wait for the load to complete and check that the CM is restored in **Monitoring** tab.

14.12 Unlike device replacement report

With R400, Unlike Device Replacement (UDR) Report can be generated to view information about the device to be replaced and the control modules that are affected due to replacement of the failed device.



You can view the following information from the Unlike Device Replacement Report.

- Report identification: The top-level information used to identify device tag, time, and date.
- Device information: The following are the device- related information that is available.

ITEM	SOURCE
Model Name	VFDMODNAME parameter of Resource block
Device Address	ADDR parameter of the device block
Device ID	DEV_ID Parameter of the device block
FIM name	'Parent' of FF link
Template Name	Device template name from the template library
Honeywell Name	VFDVENNAME parameter of Resource block
Device Revision	DEV_REV parameter of Resource block
DD Revision	DD_REV parameter of Resource block
FF Link Name	'Parent' of device

- General procedure for FF Unlike Device Replacement: This defines a high-level procedure of unlike device replacement, which consists of some of the pre-replacement and replacement steps.
- Directly affected modules: This section lists all CMs and SCMs that contain references to parent CMs of device function blocks, but do not directly contain device functions blocks. These modules are listed because all parent CMs that are deleted from the Monitoring side affect any CM or SCM that are connected.'

The following are the information that are available on the directly affected modules.

ITEM	COLUMN
CM Name	'Affected Control Module'
CM Description (DESC parameter)	'Description'
Assigned To	'Reference end point (Affected Module)'
Reference end point	'Reference end point (Affected Module)'
Reference source point	'Reference source point (To Be Deleted Module)'

- **Modules to be deleted:** This section consists of a list of Control modules that must be deleted during an Unlike Device Replacement because they contain function blocks from the device to be replaced.

The following are the information that are available on the modules to be deleted.

ITEM	COLUMN
CM Name	'Container Module Name'
CM Description (DESC parameter)	'Description'
Name of the device function block	'Device Function Block'
The controller name in which the CM is contained	'Controller Name'

- You can export the data in any of the formats such as, MS Word, Excel, Adobe PDF, and so on.
- You can view the first level and second level modules that are affected due to the device replacement.
- You can print the data, which is available in the report generated.

To view Unlike Device Replacement Report, perform the following steps.

1. Right-click on the failed device icon to select **Unlike Device Replacement Report**.

The report of the failed device that appears consists mainly of the directly affected modules, general procedure for FF Unlike Device Replacement, and the modules to be deleted.

2. In the **Directly Affected Modules** table, click **Affected Module**.

The detailed information about the selected Affected Module appears in a **Second Level Affected Modules** tab.



Attention


To view the Main Report, click **Main Report** tab.

1. In the **Modules to be Deleted** table, click **Container Module Name**.

The detailed information about the selected module name appears in a **First Level Affected Modules** tab.

14.13 Changing or clearing tag and/or address of uncommissioned device

Use the following general procedure to change the tag and/or address of a uncommissioned device. You can also use this procedure to clear the tag name and/or address from a device to re-initialize it.

- 1 In the **Monitoring** tab, double-click the uncommissioned device icon  to open the **FFLINK Parameters** form with the **Uncommissioned Devices** tab open.
 - To change the tag name, key in desired Tag (PD_TAG) name. Usually use the tag name that matches the one used for the **Project** device. Press the **Enter** key or click **OK**.
 - To clear the tag name, highlight it and press **DELETE**. Click **OK**.
- 2 Click **Continue** to acknowledge **Warning** prompt and initiate change.
- 3 Wait for change to complete. Press **TAB** to move cursor to Address box.
 - To change the address, key in desired address and press **ENTER**.
 - To clear the address, highlight it and press **DELETE**. Click **OK**.
- 4 Click **Continue** to acknowledge **Warning** prompt and initiate change.
- 5 Wait for change to complete. Click **OK** to close the form.
- 6 Confirm that the tag for the uncommissioned device icon in the **Monitoring** tab has changed or has been cleared (NoTag_248).

<https://maxautoland.com/>
manski@cambid.com +86 18030205725

14.14 Preparing Fieldbus device for a move or software migration

During migration to R400, EDDL constructs are ignored. Hence, you need to manually import the latest DD files after migrating to R400. For more information on importing of DD files, see “Creating a fieldbus device type from vendor DD”.

The process of importing the DD files enables interpreting the EDDL constructs along with Conditionals.

! Attention

- The DD files must have the latest EDDL constructs to make use of the additional features, which are supported by the Experion host.
- There is no limitation on the number of conditionals for the Experion host to support.
- Experion host supports version 1.9 of Device Capability File (.CCF) files.

Use the following procedure to prepare a device before migrating the system to a new software release or moving the device to another Link.

! Attention

- If you do **not** prepare a device as outlined in the following procedure, you may have problems loading a device after it is moved to another LINK or after the system software has been migrated to a new release.

- 1 In the **Monitoring** tab, click + plus sign for FIM4/FIM8, FFLINK, and Device icons to expand directories to block level.
- 2 Right-click the Fieldbus block icon and select **Inactivate** -> **Selected Item(s)** to call up the **Change State** dialog.
- 3 Click **Yes** to initiate the action. Check that the function block icon turns Blue.
- 4 Double-click the Fieldbus block icon to call up the **Block Parameters** configuration form.
- 5 On the **Process** tab, check that the **Actual Mode** has changed to **OOS** to confirm that the block is in Out-Of-Service (OOS) mode.
- 6 Click **OK** to close the form.
- 7 Repeat Steps 2 to 6 for other Fieldbus blocks (if applicable), Transducer, and Resource blocks in the device, in that order.
- 8 Device is now ready to be decommissioned and moved to another Link or migrated to a new system software release.

14.14.1 Migrating Fieldbus device type to a release supporting Enable Block Offnet Diagnostic Alarm

The database can be migrated to R400 release, which supports Block Offnet Diagnostic Alarm parameter. The Enable Block Offnet Diagnostic Alarm parameter is added to all the Fieldbus Block templates and is available in control strategies or on Station Detail Displays. However, you must edit the template for each block within the device for the parameter to appear on the Configuration form.

Perform the following steps to edit the template.

- 1 Right-click the Fieldbus block in the Library view.
- 2 Select **Edit Type**.
- 3 In the Font box, type OFFNETALM_ENABLED.
- 4 Select **OK**.

Perform this procedure for each Fieldbus block if you want the parameter to appear in the configuration form.

! Attention

You can also create the device type template by selecting device type from the device list. The OverWrite feature reconfigures the configuration forms to include the 'Enable Block Offnet Diagnostic Alarm' check box.

<https://maxautoland.com/>
manski@cambid.com +86 18030205725

14.15 Using fieldbus device simulate function

Some of the standard Fieldbus function blocks support a signal simulation function for testing purposes only. The following procedure shows the general steps involved in using the simulate function with an Analog Input block in a Honeywell ST3000 transmitter. You can easily adapt this procedure to any applicable Fieldbus device.



CAUTION

Only use the simulate function when the system is offline or in a safe operating mode for testing purposes.

Prerequisites

The Fieldbus device is capable of supporting a simulate function.

To use a fieldbus device simulate function

- 1 Refer to the vendor documentation supplied with the Fieldbus device to determine the location of the simulate activating jumper or switch on the device.
A switch or jumper is usually included in the device to inhibit accidental activation of the simulate feature.
- 2 Position the jumper or switch to its simulate enable position.
- 3 In the **Monitoring** tab, open the directory for the Fieldbus device icon and double click the Analog Input function block to call up the **Block Parameters** form.
- 4 Click the **Maintenance** tab.



Attention

You can disable or enable individual block errors in the Function blocks, Transducer blocks, and Resource blocks. You can enable/disable individual block errors only when block alarm is enabled in the **Alarms** tab.

Following are some of the considerations for disabling individual block errors.

- For the blocks such as AI block configured in Control Modules, when an inactive block error is disabled and if the block error turns active, the **Alarm Display** will not display the alarm and the **Event Summary** will not display the alarm event. For the devices only blocks such as, Resource or Transducer blocks, block error alarm appearance in the **System Status Display** is affected.
- Regardless of disabling, the individual block error status is displayed on the block's **Maintenance** tab.
- When an active block error is disabled, the **Alarm Display** or **System Status Display** alarm returns to normal, and **Event Summary** displays the alarm action as OK.
- In the **Alarm Display** or **System Status Display**, when you acknowledge block error alarms that have returned to normal, the alarms disappear and **Event Summary** displays the acknowledged alarms.
- When the disable is removed for an active block error, the **Alarm Display** or **System Status Display** displays the alarm as active and **Event Summary** receives the event for that particular alarm.


- 5 In the **Simulate En/Disable** box, click the arrow button and select **Simulation Active**.
- 6 Click **Yes** to confirm the action and initiate the simulate function.
- 7 Click the arrow button in the **Simulate Status** box. For this example, select **Good** from the list.
- 8 Click **Yes** to confirm the action and set the **Simulate Status** to Good.
- 9 Click in the **Simulate Value** box and key in **25** and press **ENTER**.
- 10 Click **Yes** to confirm the action and set the **Simulate Value** to 25.

 **Attention**

The parameter **Enable Block Offnet Diagnostic Alarm** appears on the **Maintenance** tab of Resource blocks, Transducer blocks, and other function blocks that support block errors. By default, this parameter is disabled, which means that the Block Offnet Alarm is not reported if a device that contains the block goes off the network.

Before configuring the Enable Block Offnet Diagnostic Alarm parameter, consider the following conditions:

- If you enable the Enable Block Offnet Diagnostic Alarm, the Block Offnet Alarm is reported while the device, which contains the block, goes offnet.
- If you disable the option while the alarm is active, the alarm returns to normal. Therefore, you can configure this alarm before loading and it can be changed at runtime while the device is offline. You can silence the alarm and prevent the report generation.

- 11 Click **OK** to close the form.
- 12 In the **Monitoring** tab, double-click the Control Module that includes the Analog Input block for the device with the simulated value to open it in the control chart.
- 13 Check that OUT VALUE for the Analog Input block is 25 to confirm that simulate value is active. Click the  close button to close the CM.
- 14 To disable the simulation, repeat Steps 3 to 6 and select **Simulation Disabled** instead of **Simulation Active** in Step 5.
- 15 Click **OK** to close the form.
- 16 Reverse the jumper position set in Step 2 to disable the simulate function in the device.

<https://maxautoland.com/>
 manski@cambodia.cn +86 18030205725

14.16 Checking fieldbus device calibration

Please refer to the manufacturer's documentation for the Fieldbus device to determine the recommended calibration schedules and procedures. The **Tune** and **Other** tabs on the **Parameters** form for a device's transducer block provide pertinent calibration information, when accessed through the **Monitoring** tab in Control Builder. The following illustrations show typical **Tune** and **Other** tabs for reference.




Figure 33: Typical Tune tab for Fieldbus device's Transducer block.




Figure 34: Typical Other tab for Fieldbus device's Transducer block.

<https://maxautoland.com/>
manski@cambodia.cn +86 18030205725

15 Series C FIM4/FIM8 troubleshooting

This section provides information about troubleshooting the Series C FIM4/FIM8. The following table lists the topics included in this section. If you are viewing this information online, just click the topic title to jump to the information location.

Topic
“Isolating problems” on page 240
“Fault classifications” on page 241
“Initial checks” on page 242
“Series C FIM4/FIM8 self-test diagnostic codes” on page 245
“Fixing common problems” on page 252
“Getting further assistance” on page 258

Related topics

- [“Isolating problems” on page 240](#)
- [“Fault classifications” on page 241](#)
- [“Initial checks” on page 242](#)
- [“Series C FIM4/FIM8 self-test diagnostic codes” on page 245](#)
- [“FIM link communication error” on page 251](#)
- [“Fixing common problems” on page 252](#)
- [“Getting further assistance” on page 258](#)

https://maxoutoland.com/
manski@cambridge.cn +86 18030205725

15.1 Isolating problems

This section offers some general data about fault classifications, initial checks, and Series C FIM self-test diagnostic codes that may help you isolate the cause of a problem.

If you have observed a specific symptom and/or identified an error code, go to the Fixing Common Problems section to see if you can find a matching topic.

<https://maxautoland.com/>
manski@cambodia.cn +86 18030205725

15.2 Fault classifications

The following table lists some possible ways for classifying faults along with some identifying characteristics.

Fault Classification	Characteristics
<i>Hard Failure</i>	Failure detected by hardware; operation cannot continue. If the fault does not prevent software processing the problem, the affected node will be rebooted under software control into the FAIL State. <ul style="list-style-type: none"> • If failure occurs on Primary node, it triggers a switchover to synchronized Secondary node. • If failure occurs on Secondary node, it results in loss of synchronization and reduced availability until the problem is resolved. • If failure occurs on non-redundant node, it results in loss of control and loss of view.
<i>Severe Failure</i>	Failure detected by software; operation cannot continue. The affected node will be rebooted under software control into the FAIL State. The failure scenarios are as listed in the row above for the Hard Failure.
<i>Soft Failure</i>	Failure detected by software; operation continues with full control and full view. Soft failures are alarmed to the operator. FTE will be monitored by the FTE System Management Tool. <ul style="list-style-type: none"> • If failure occurs on Primary node, it does not trigger a switchover to synchronized Secondary node. • If failure occurs on Secondary node, it does not result in loss of synchronization. • If failure occurs on non-redundant node, it does not result in loss of control and loss of view.
<i>Installation/Startup Failure</i>	Detected by software. Node may not become operational. <ul style="list-style-type: none"> • This failure does not apply to synchronized Primary node, since installation and startup must be successful to reach synchronized Primary state. • If failure occurs on Secondary node, it results in the inability to complete the initial synchronization and to view the node on the network. • If failure occurs on non-redundant node, it results in the inability to commence control and to view the node on the network.
<i>Communication</i>	Communication errors between peer nodes and/or I/O devices, including Fault Tolerant Ethernet Bridge (FTEB), do not cause any node state change.

<https://maxaut.com>
manski@cambi.com
 800-302-5725

15.3 Initial checks

This section offers some checks that you can make to help isolate the problem. The checks are arranged in no particular order.

Related topics

“Checking Control Builder error code reference” on page 242

“Checking front panel display and LEDs” on page 242

“Viewing flash log” on page 242

“Viewing release information log” on page 242

“Viewing trace log” on page 243

“Checking version and revision log” on page 243

“Checking server point build log” on page 243

“Checking server point build error log” on page 243

“Checking error log” on page 243

“Viewing link schedule log” on page 243

“Checking Fieldbus library manager log” on page 244

“Using CTool to capture diagnostic data” on page 244

15.3.1 Checking Control Builder error code reference

An indication of a problem may be in the form of an error dialog that includes an error message and possibly an error code in Control Builder.

The syntax for a typical Control Builder error message is as follows:

Connection to device is not open EPKS_E_CL_NOCONN(6L.101.3326)

In this syntax, the error code is the last four digits in the message or **3326**.

Please refer to the *Control Builder Error Codes Reference* book for applicable error code information.

15.3.2 Checking front panel display and LEDs

Check the Series C FIM 4-character display and Series C FIM/IOTA light emitting diodes (LEDs) indications and compare results with data in the “Series C FIM4/FIM8 IOTA display and LED descriptions” on page 161 Descriptions section of this book.

15.3.3 Viewing flash log

The Flash.txt log provides a list of firmware updates that have been initiated.

To view the log, navigate to this file location on the server: C:\Program Files\Honeywell\Experion PKS\Engineering Tools\system\bin\Flash.txt.

15.3.4 Viewing release information log

The ReleaseInfo.txt log provides a list of Experion software releases that have been installed on the computer.

To view the log, navigate to this file location on the server: C:\Program Files\Honeywell\Experion PKS\Engineering Tools\system\bin\ReleaseInfo.txt.

15.3.5 Viewing trace log

The TraceLogRs.txt log provides a list of definitions for strings associated with *breadcrumbs* data for given hardware components. The *breadcrumbs* provide a way to trace operations leading up to an event.

To view the log, navigate to this file location on the server: C:\Program Files\Honeywell\Experion PKS\Engineering Tools\system\bin\TraceLogRs.txt.

15.3.6 Checking version and revision log

The ver_rev.txt log provides a list of components by model number with software version/revision along with compatible Experion software release(s).

To check the log, navigate to this file location on the server: C:\Program Files\Honeywell\Experion PKS\Engineering Tools\system\bin\ver_rev.txt.

15.3.7 Checking server point build log

The SvrPtBld_servername.txt log provides list of process (CB) points built in the server database.

To check the log, navigate to this file location on the server: C:\Program Files\Honeywell\Experion PKS\Engineering Tools\temp\SvrPtBld_servername.txt.

15.3.8 Checking server point build error log

The svrptblderr_servername.txt log provides list of any errors associated with process (CB) points built in the server database.

To check the log, navigate to this file location on the server: C:\Program Files\Honeywell\Experion PKS\Engineering Tools\temp\svrptblderr_servername.txt.

15.3.9 Checking error log

The Errlog_n.txt log provides a running list of Control Builder detected errors in chronological order. The n represents any number that is assigned to the most recent log.

To check the log, navigate to this file location on the server: C:\ProgramData\Honeywell\Experion PKS\ErrLog_n.txt.

Prior to R400, the Errlog_n.txt file was stored in the following location on the server: C:\Documents and Settings\All Users\Application Data\Honeywell\Experion PKS\Errlog_n.txt.

15.3.10 Viewing link schedule log

The FFLinkSchedule20000nnnPROJECT.txt log provides a description of the link schedule associated with the given FFLink in Control Builder. The nnn represents the identifying portion of the FFLink block name configured in Control Builder. The link schedule must be viewed in Control Builder for this log to be generated. The log includes the following information categories.

- **NATURAL SCHEDULE:** Shows the execution and publish entries in the schedule by Control Module (CM) point.
- **SCHEDULE STATS:** Shows the schedule statistics for the natural schedule.
- **FB LIST:** Lists the function blocks added to the list of scheduled objects.
- **PUB LIST:** Lists the connections added to the list of scheduled objects.
- **CHAIN LIST:** Lists the chains and the elements contained in each chain.

- **OPTIMIZED SCHEDULE:** Shows the execution and publish entries in the schedule with the optimized schedule start times by Control Module (CM) point.
- **SCHEDULE STATS:** Shows the schedule statistics for the optimized schedule.
- **SCHEDULE FACTORS:** Shows the schedule factors for the *optimized* schedule compared to the *natural* schedule.

To view the log, navigate to this file location on the server: C:\Documents and Settings\All Users\Application Data\Honeywell\Experion PKS\FLinkSchedule20000nnnPROJECT.txt.

15.3.11 Checking Fieldbus library manager log

The FieldbusLibraryManagerLog.txt log provides list of information captured during generation of given Fieldbus device type from vendor DD file in chronological order.

To check the log, navigate to this file location on the server: C:\Documents and Settings\All Users\Application Data\Honeywell\Experion PKS\FieldbusLibraryManagerLog.txt.

15.3.12 Using CTool to capture diagnostic data

Please refer to the *Using CTool to capture diagnostic data* section in the *Control Hardware Troubleshooting and Maintenance Guide* for more information.

<https://maxautoland.com/>
+86 18030205725
manski@cambid.com.cn

15.4 Series C FIM4/FIM8 self-test diagnostic codes

The following table lists the self-test diagnostic codes that the Series C FIM4/FIM8 steps through upon power up.

Test Code	Target Device(s)	Failure Modes	Function
T000			Signals start of selftest.
<i>Display Diagnostics</i>			
T001	Display Test	Bad display, Incorrect assembly	Steps through horizontal/vertical bars, then flashes all segments of the display through stages of brightness. For this test to work, CPU, Flash ROM, address bus, data bus, and some I/O ports must be working. The module status LED is set to GREEN, OFF, then RED for the duration of self test.
<i>CPU Diagnostics</i>			
T002	CPU Mask Revision Test	Obsolete or unexpected new, CPU	This test is done before the ROM tests, because a wrong CPU could appear to work, but might fail timing tests. The Instruction Cache may be enabled after this test.
T003	CPU Speed Test	Invalid jumper configuration	The software-visible hardware jumpers are verified. This is necessary because the PPC Timebase and Decrementer run at CPU clock /4.
T004	Miscellaneous Speed Test	Register configuration	Checks the value of the system clock mode register to ensure that bus division factor, CPM division factor, the PLL predivision factor, and the PLL multiplication factor are correct.
T010	Boot Image Test	Bad flash memory, Bad instruction cache	The CRC-32 and other parameters of the boot image in ROM are computed and verified. Running this test with the Instruction and Data Cache enabled provides an acceptable SIL-2 cache test because it involves comparing against a known value. Data cache is disabled after this test.
T012	First Stuck Interrupt Test	Bad wiring, Improper PLD configuration, Improper FPGA configuration	Checks for interrupts stuck on at power-on. Clears the interrupt pending register (SIPNR) and then re-checks if any interrupts are still asserted.
T013	Main RAM Initialization	None	Initializes all main RAM locations with 0 while error detection functionality is turned off
<i>Main RAM Diagnostics</i>			
T020	Main RAM Data Bus Test	Stuck high and Stuck low data bus lines caused by shorts and unconnected data lines	Tests the data bus lines from the CPU to the SDRAM for stuck high and stuck low bus lines.
T021	Main RAM Address Bus Test	Stuck high and stuck low address bus lines caused by shorts and unconnected data lines	Tests the address bus lines from the CPU to the SDRAM for stuck high and stuck low bus lines.

Test Code	Target Device(s)	Failure Modes	Function
T022	Main RAM Device Test	Bad memory device	Confirms that each bit in every memory location can be set to either a 1 or 0 and can maintain that value for a period of time. This diagnostics consists of writing 0 and 0xFFFFFFFF, walking 1s, and walking 0s to all memory locations in SDRAM.
T030	Main RAM Byte Access Test	Bad memory controller configuration, Faulty wiring between CPU and SDRAM	Confirms that Main RAM can support byte-sized memory accesses.
T031	Main RAM Half Word Access Test	Bad memory controller configuration, Faulty wiring between CPU and SDRAM	Confirms that main RAM can support half-word (16-bit) sized memory access.
T032	Main RAM Word Access Test	Bad memory controller configuration, Faulty wiring between CPU and SDRAM	Confirms that main RAM can support word (32-bit) sized memory access.
T033	Main RAM Double Word Access Test	Bad memory controller configuration, Faulty wiring between CPU and SDRAM	Confirms that main RAM can support double word (64-bit) sized memory access.
T038	Main RAM SBE Test	Improper EDAC configuration in BR and/or MCR register, improper wiring from CPU to SDRAM	Confirms that the memory controller's error detection and correction functionality works properly with respect to single bit errors. This includes ensuring that single bit errors are corrected and recorded in the TESCR1 register's ECC1 bit.
T039	Main RAM MBE Test	Improper EDAC configuration in BR and/or MCR register, improper wiring from CPU to SDRAM	Confirms that the memory controller's error detection and correction functionality works properly with respect to double bit errors. This includes ensuring that double bit errors are correctly flagged in the TESCR1 register's ECC2 bit.
<i>Cache Diagnostics</i>			
T040	Instruction Cache Test	Bad CPU, Instruction cache not activated	Confirms that executing code with instruction cache turned on speeds up execution time. Significantly, faster execution time will indicate that the instruction cache works as expected.
T045	Data Cache Test	CPU, Data cache is not activated	Confirms that executing code with the data cache turned on speeds up execution time when there are repeated data accesses to the same memory location. Significantly faster execution time will indicate that the data cache works as expected.
T046	Motorola Data Cache Test	Bad CPU, Data cache not activated	Tests the data cache as rigorously as it can be tested. Honeywell wrote the source code for this test.
<i>EEPROM Diagnostics</i>			
T050	EEPROM Read Test	Bad wiring between CPU and EPROM, Invalid port configuration	Confirms that we can read from EEPROM. (This does not include validating the contents of EEPROM.)

Test Code	Target Device(s)	Failure Modes	Function
T051	EEPROM Write Protect Test	Bad wiring between CPU and EPROM, Invalid port configuration	Verifies that the write protect line defaults to the protected state
<i>Thermometer Diagnostics</i>			
T052	Thermometer Test	Bad wiring from CPU to thermometers, Bad thermometers, invalid ambient temperature, invalid IO port configuration	SPI Digital Thermometers- Verify that data and clock lines can be set to both states. Verify that chip select lines can be set to both states. Read temperature from all digital thermometers, verify acceptable values (acceptable operating temperature range -10 to +70 degrees C indicates parts are working).
<i>Miscellaneous Diagnostics</i>			
T065	EEPROM Checksum Test	Bad EEPROM, Unprogrammed EEPROM, Bad wiring to CPU	Calculates the checksum of the factory data stored in EEPROM.
T066	PHY Interface Test	Stuck high or low PHY configuration lines	Wiggles MDIO and MDCLK lines.
T067	Second Stuck Interrupt Test	Bad FPGA image, faulty wiring	Checks for any asserted interrupt lines. Once the FPGA has been configured there should initially be no asserted interrupts from the application board (IRQ1).
<i>Fieldbus Network Number 1 Diagnostics</i>			
T110	Communication Controller Data Path	Bad CPLD image, Bad interboard connections, Invalid memory controller configuration	Writes a set of values to a communication controller register in which all the bits are writeable. The values written will include walking ones and walking zeros on all data bus bits.
T111	Initialize Communication Controller	Bad memory controller configuration, Faulty wiring, Bad communication controller chip	Initializes the Fieldbus communication controller by setting up its internal registers with a base configuration used during power-on self-test. Since this involves writing to the communication controller's registers, this function implicitly tests the data path from the host processor to the communication processor via the local bus. This test is performed on Fieldbus network number 1.
T112	Communication Controller Token Timer	Bad communication controller	Checks the communication controller's internal token timer. This timer is used to indicate the token holding time remaining.
T113	Communication Controller Node Timer	Bad communication controller	Checks the communication controller's internal node timer.
T114	Communication Controller Watch Timer Test	Invalid communication controller configuration	Checks the communication controller's internal watch timer. The watch timer expires and generates an interrupt, if there is no bus activity after a specified period of time.
T115	Communication Controller Gap Timer	Bad communication controller	Checks the communication controller's internal gap timer. The gap timer governs the minimum amount of time between two transmissions.
T116	FIFO Threshold Interrupt Generation	Bad communication controller	Checks the implementation of the FIFO threshold interrupts (TFI and RFI). These interrupts are generated when the TX and/or RX FIFOs exceed a specified limit.

Test Code	Target Device(s)	Failure Modes	Function
T117	Communication Controller Interrupt Generation	Bad communication controller interrupt aggregation	Checks to see that an interrupt generated by the communication controller can be seen by the host processor.
T118	Communication Controller Loopback	Bad communication controller	Puts the communication controller into internal loopback mode and tests to see that data can be transmitted and received with internal loopback on. This test is performed on Fieldbus network number 1
<i>Fieldbus Network Number 2 Diagnostics</i>			
T120	Communication Controller Data Path	Bad CPLD image, Bad interboard connections, Invalid memory controller configuration	Writes a set of values to a communication controller register in which all the bits are writeable. The values written will include walking ones and walking zeros on all data bus bits.
T121	Initialize Communication Controller	Bad memory controller configuration, Faulty wiring, Bad communication controller chip	Initializes the Fieldbus communication controller by setting up its internal registers with a base configuration used during power-on self-test. Since this involves writing to the communication controller's registers, this function implicitly tests the data path from the host processor to the communication processor via the local bus. This test is performed on Fieldbus network number 2.
T122	Communication Controller Token Timer	Bad communication controller	Checks the communication controller's internal token timer. This timer is used to indicate the token holding time remaining.
T123	Communication Controller Node Timer	Bad communication controller	Checks the communication controller's internal node timer.
T124	Communication Controller Watch Timer Test	Invalid communication controller configuration	Checks the communication controller's internal watch timer. The watch timer expires and generates an interrupt, if there is no bus activity after a specified period of time.
T125	Communication Controller Gap Timer	Bad communication controller	Checks the communication controller's internal gap timer. The gap timer governs the minimum amount of time between two transmissions.
T126	FIFO Threshold Interrupt Generation	Bad communication controller	Checks the implementation of the FIFO threshold interrupts (TFI and RFI). These interrupts are generated when the TX and/or RX FIFOs exceed a specified limit.
T127	Communication Controller Interrupt Generation	Bad communication controller interrupt aggregation	Checks to see that an interrupt generated by the communication controller can be seen by the host processor.
T128	Communication Controller Loopback	Bad communication controller	Puts the communication controller into internal loopback mode and tests to see that data can be transmitted and received with internal loopback on. This test is performed on Fieldbus network number 2
<i>Fieldbus Network Number 3 Diagnostics</i>			
T130	Communication Controller Data Path	Bad CPLD image, Bad interboard connections, Invalid memory controller configuration	Writes a set of values to a communication controller register in which all the bits are writeable. The values written will include walking ones and walking zeros on all data bus bits.

Test Code	Target Device(s)	Failure Modes	Function
T131	Initialize Communication Controller	Bad memory controller configuration, Faulty wiring, Bad communication controller chip	Initializes the Fieldbus communication controller by setting up its internal registers with a base configuration used during power-on self-test. Since this involves writing to the communication controller's registers, this function implicitly tests the data path from the host processor to the communication processor via the local bus. This test is performed on Fieldbus network number 3.
T132	Communication Controller Token Timer	Bad communication controller	Checks the communication controller's internal token timer. This timer is used to indicate the token holding time remaining.
T133	Communication Controller Node Timer	Bad communication controller	Checks the communication controller's internal node timer.
T134	Communication Controller Watch Timer	Invalid communication controller configuration	Checks the communication controller's internal watch timer. The watch timer expires and generates an interrupt, if there is no bus activity after a specified period of time.
T135	Communication Controller Gap Timer	Bad communication controller	Checks the communication controller's internal gap timer. The gap timer governs the minimum amount of time between two transmissions.
T136	FIFO Threshold Interrupt Generation	Bad communication controller	Checks the implementation of the FIFO threshold interrupts (TFI and RFI). These interrupts are generated when the TX and/or RX FIFOs exceed a specified limit.
T137	Communication Controller Interrupt Generation	Bad communication controller interrupt aggregation	Checks to see that an interrupt generated by the communication controller can be seen by the host processor.
T138	Communication Controller Loopback	Bad communication controller	Puts the communication controller into internal loopback mode and tests to see that data can be transmitted and received with internal loopback on. This test is performed on Fieldbus network number 3.
<i>Fieldbus Network Number 4 Diagnostics</i>			
T140	Communication Controller Data Path	Bad CPLD image, Bad interboard connections, Invalid memory controller configuration	Writes a set of values to a communication controller register in which all the bits are writeable. The values written will include walking ones and walking zeros on all data bus bits.
T141	Initialize Communication Controller	Bad memory controller configuration, Faulty wiring, Bad communication controller chip	Initializes the Fieldbus communication controller by setting up its internal registers with a base configuration used during power-on self-test. Since this involves writing to the communication controller's registers, this function implicitly tests the data path from the host processor to the communication processor via the local bus. This test is performed on Fieldbus network number 4.
T142	Communication Controller Token Timer	Bad communication controller	Checks the communication controller's internal token timer. This timer is used to indicate the token holding time remaining.
T143	Communication Controller Node Timer	Bad communication controller	Checks the communication controller's internal node timer.

Test Code	Target Device(s)	Failure Modes	Function
T144	Communication Controller Watch Timer	Invalid communication controller configuration	Checks the communication controller's internal watch timer. The watch timer expires and generates an interrupt, if there is no bus activity after a specified period of time.
T145	Communication Controller Gap Timer	Bad communication controller	Checks the communication controller's internal gap timer. The gap timer governs the minimum amount of time between two transmissions.
T146	FIFO Threshold Interrupt Generation	Bad communication controller	Checks the implementation of the FIFO threshold interrupts (TFI and RFI). These interrupts are generated when the TX and/or RX FIFOs exceed a specified limit.
T147	Communication Controller Interrupt Generation	Bad communication controller interrupt aggregation	Checks to see that an interrupt generated by the communication controller can be seen by the host processor.
T148	Communication Controller Loopback	Bad communication controller	Puts the communication controller into internal loopback mode and tests to see that data can be transmitted and received with internal loopback on. This test is performed on Fieldbus network number 4.
<i>Pre-OS Diagnostics</i>			
T400	Application Image Validation	Missing Application Image, Incomplete load of Application Image, Bad flash memory	Checks for valid Application Image stored in flash memory.
T401	Unused Port Pin	Unanticipated usage of spare port pins	Confirms that unused parallel port pins on the CPU can be driven into both high and low states.
T511	End of POST Diagnostics		Confirms that self test is successful and there is a valid Application Image stored in Flash.

15.5 FIM link communication error

FIM link communication error is defined as the failure to communicate with the FF link.

Diagnostic check

- Failure to communicate with the FF link.
- Link state in Control Builder displays as “COMMINTERR” and the Link appears in red color.
- FIM LED display: XX-CE, here “XX” indicates link number and “CE” indicates communication error.

Cause

Physical layer disturbances, such as poor grounding, noise, electrical interference, and so on.

Solution

1. Correct the physical layer disturbances.
2. On the Monitoring view, right-click the FIM link to select **Module Properties**.
The **FLink Block Parameters Configuration** page appears.
3. On the Main tab, click **SEG Command** box and then select **SHUTDOWN** from the drop-down list.
4. Click **Yes** to confirm.
5. Under the **SEG Command** box, select **STARTUP** from the drop-down list.
6. Click **Yes** to confirm.

<https://maxautoland.com/>
manski@cambid.com +86 18030205125

15.6 Fixing common problems

This section identifies some common problems and describes how you might fix them.

Related topics

- “Loss of power” on page 252
- “Poweron Self-Test Fault” on page 252
- “Fatal ECC error” on page 253
- “Background Diagnostic failure” on page 253
- “No IP address” on page 253
- “No time reference” on page 254
- “Isolated (lonely) Node” on page 254
- “Device Index setting does not match displayed value” on page 255
- “Duplicate Device Index setting” on page 255
- “Device Index value is zero upon power up” on page 256
- “Device reload or replacement fails” on page 256
- “Generation of excessive alarms” on page 256
- “Alarms not occurring when expected” on page 257
- “Connected Fieldbus device is not detected by the FF link” on page 257

15.6.1 Loss of power

The power supply has failed or the main power source has been shut down or is experiencing a *brownout* or *blackout* condition.

Diagnostic Check	<ul style="list-style-type: none"> • The 4-character display on the Series C FIM4/FIM8 and LEDs on the Series C FIM and the IOTA are off. • In the Monitoring tab, the FIM4/FIM8 icon turns red.
Cause 1	Main power source has been disconnected or shut down either manually or temporarily by <i>brownout</i> or <i>blackout</i> condition.
Solution	Re-connect the main power source or turn it On or wait for temporary <i>brownout</i> or <i>blackout</i> condition to pass.
Cause 2	The 24 Vdc power supply failed or power cable has been disconnected or failed.
Solution	Replace the 24 Vdc power supply or re-connect/replace the power cable.
Cause 3	Power fuse opens on IOTA.
Solution	Replace power fuse.

15.6.2 Poweron Self-Test Fault

The Series C FIM4/FIM8 poweron selftest has detected a fault.

Diagnostic Check	A self-test diagnostic code remains on display and the poweron selftest does not continue.
Cause	The Series C FIM4/FIM8 power on self test has detected a failure that does not allow operation to continue.
Solution	Try shorting the reset pads on the IOTA to re-start the Series C FIM4/FIM8. If error persists, replace the Series C FIM4/FIM8. See “Replacing failed Series C FIM4 CC- or CU-PFB401” on page 221 for details.

15.6.3 Fatal ECC error

The Series C FIM4/FIM8 software has detected a fatal Error Checking and Correction (ECC) condition that can be a multiple-bit error or excessive single bit errors in main Random Access memory (RAM).

Diagnostic Check	<ul style="list-style-type: none"> The 4-character display on the Series C FIM4/FIM8 displays FAIL. In the Monitoring tab, the FIM4/FIM8 icon turns red.
Cause	The Series C FIM4/FIM8 software has detected a failure that does not allow operation to continue. There can be many causes for a failure including hardware, use the Series C Platform Analyzer to capture a crash block for the device to determine the possible cause before proceeding.
Solution	<p>Try shorting the reset pads on the IOTA to re-start the Series C FIM4/FIM8. If error persists, replace the Series C FIM4/FIM8. See “Replacing failed Series C FIM4 CC- or CU-PFB401” on page 221 for details.</p> <p>Check the Trace log for breadcrumbs that occurred prior to the event. See “Viewing trace log” on page 243 and “Using CTool to capture diagnostic data” on page 244 for more information. Provide the results of the trace log to our Solutions Support Center (SSC) for analysis.</p>

15.6.4 Background Diagnostic failure

The Series C FIM4/FIM8 detects failure in system integrity checks, such as Watch Dog Timer (WDT), error detection circuits, Field Programmable Gate Array (FPGA) readback, microprocessor static configuration registers, and Read Only Memory (ROM) checksum.

Diagnostic Check	<ul style="list-style-type: none"> The 4-character display on the Series C FIM4/FIM8 displays FAIL. In the Monitoring tab, the FIM4/FIM8 icon turns red.
Cause	The Series C FIM4/FIM8 software has detected a background diagnostic failure that does not allow operation to continue.
Solution	<p>Try recycling power to the Series C8 FIM4/FIM8. If error persists, replace the Series C FIM4/FIM8. See “Replacing failed Series C FIM4 CC- or CU-PFB401” on page 221 for details. Check the Trace log for breadcrumbs that occurred prior to the event. See “Viewing trace log” on page 243 and “Using CTool to capture diagnostic data” on page 244 for more information. Provide the results of the trace log to our Solutions Support Center (SSC) for analysis.</p>

15.6.5 No IP address

The Series C FIM4/FIM8 cannot obtain an IP address.

Diagnostic Check	The 4-character display on the Series C FIM4/FIM8 displays -bp-.
Cause 1	A valid IP address has not been configured.
Solution	Configure a valid IP address through the System Preferences dialog in Control Builder.
Cause 2	The BOOTP server service is not running.
Solution	Check that the Experion BOOTP Server service is running through the Services dialog of the Control Panel application.
Cause 3	The BOOTP server was not re-started after a change in the Device Index or System Preferences.
Solution	Stop and start the Experion BOOTP Server service through the Services dialog of the Control Panel application.

Cause 4	Communication problems.
Solution	Check your FTE network and cables for proper operation.

15.6.6 No time reference

The Series C FIM4/FIM8 cannot obtain a system time reference.

Diagnostic Check	The 4-character display on the Series C FIM4/FIM8 displays -ts-.
Cause 1	Valid (S)NTP Server addresses have not been configured.
Solution	Configure valid (S)NTP Primary and Secondary Server IP addresses through the System Preferences dialog in Control Builder.
Cause 2	A prior release version of the BOOTP Server is running.
Solution	Be sure that only an R300 Experion PKS BOOTP Server service is running on the servers. Only the latest BOOTP server can provide all of the necessary information for the current and prior-release devices.
Cause 3	Not all FTE System Preferences for all Experion clusters have been configured with the same information.
Solution	Check that all FTE System Preferences are configured identically through the System Preferences dialog in Control Builder.
Cause 4	The designated (S)NTP Servers are not properly configured and operating.
Solution	See Setting up time synchronization in the <i>Supplementary Installation Tasks Guide</i> for information.
Cause 5	The BOOTP Server service on both servers was not re-started after a configuration change.
Solution	Re-start the BOOTP Server service on both servers through the Services dialog of the Control Panel application.
Cause 6	The Windows Time Service on Experion servers was not re-started after NTP server was enabled.
Solution	Be sure the Windows Time Service is running on Experion servers. Normally, NTPSetup takes care of this.

15.6.7 Isolated (lonely) Node

For redundant Series C FIM4/FIM8 pair, Fault Tolerant Ethernet (FTE) communications with partner and FTE network are lost.

Diagnostic Check	<ul style="list-style-type: none"> The Primary Series C FIM4/FIM8 negotiates whether to initiate a switchover or not. If the Secondary was known to be in better condition than the Primary at the time of fault determination, then the Primary should fail so the Secondary will switchover. But, the new Secondary (old Primary) still cannot restore FTE communications. The Secondary Series C FIM4/FIM8 should reboot once, in an attempt to restore communications. The Primary Series C FIM4/FIM8 will be able to report the problem in the Secondary. If the Secondary cannot restore FTE communications, it would still be able to resynchronize over the redundancy link and be a partially functional backup.
Cause 1	The Secondary Series C FIM4/FIM8 is defective.
Solution	Replace the Secondary Series C FIM4/FIM8 that initiated switchover when fault was detected. See “Replacing failed Series C FIM4 CC- or CU-PFB401” on page 221 for details. If Secondary Series C FIM4/FIM8 synchronizes after replacement, the removed Series C FIM4/FIM8 is defective. Otherwise, go to Cause 2.
Cause 2	The Primary Series C FIM4/FIM8 is defective

Solution	Replace the Primary Series C FIM4/FIM8. See “Replacing failed Series C FIM4 CC- or CU-PFB401” on page 221 for details. If you can command synchronization after replacement, the removed Series C FIM4/FIM8 is defective. Otherwise, go to Cause 3.
Cause 3	The redundant IOTA is defective.
Solution	Replace the redundant IOTA. See “Replacing IOTA DC-TFB402 or DC-TFB412, CC-or CU-TFB401, CC-or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412” on page 222 for details. If the Series C FIM4/FIM8 pair synchronize after IOTA replacement, The removed IOTA is defective. Other wise, go to Cause 4.
Cause 4	There is a software problem.
Solution	Contact our Solution Support Center (SSC).

15.6.8 Device Index setting does not match displayed value

The Device Index number shown in the Series C FIM4/FIM8's 4-character display does not match the value set on the IOTA's binary-coded decimal rotary switches.

Diagnostic Check	May be detected as a soft failure that triggers an alarm for the operator. The Device Index setting is important only at initial application startup, when the Device Index number is used to obtain the IP Address. The Device Index and IP Address are saved in non-volatile memory and reused on subsequent application startups.
Cause 1	Someone changed the setting on the binary-coded decimal rotary switches on the IOTA.
Solution	Change binary-coded decimal rotary switches to correct setting. See for more information.
Cause 2	The Primary or non-redundant Series C FIM4/FIM8 is defective
Solution	Replace the Primary or non-redundant Series C FIM4/FIM8. See “Replacing failed Series C FIM4 CC- or CU-PFB401” on page 221 for details. If Device Index switch setting matches Device Index number in 4-character display upon Series C FIM4/FIM8 power up, the removed Series C FIM4/FIM8 is defective. Otherwise, go to Cause 3.
Cause 3	The redundant or non-redundant IOTA is defective.
Solution	Replace the IOTA. See “Replacing IOTA DC-TFB402 or DC-TFB412, CC-or CU-TFB401, CC-or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412” on page 222 for details. If Device Index switch setting matches Device Index number in 4-character display upon Series C FIM4/FIM8 power up, the removed IOTA is defective. Otherwise, go to Cause 4.
Cause 4	There is a software problem.
Solution	Contact our Solution Support Center (SSC).

15.6.9 Duplicate Device Index setting

The FTE subsystem detects duplicate Device Index settings in separate nodes.

Diagnostic Check	All nodes will stop tracking cable status for the detected duplicate Device Index value. Communications will continue and will not impact system performance until there is a cable fault. This fault will also be detected by the FTE System Management Tool. A duplicate Device Index could cause a duplicate IP Address. In most cases, the duplicate IP Address would be detected first and prevent the FTE diagnostic messages from being sent.
Cause 1	Have set binary-coded decimal rotary switches on separate IOTA's to same value.

Solution	Change binary-coded decimal rotary switches setting on one of the IOTA's to a unique value. See for more information.
-----------------	-----------------------------------------------------------------------------------------------------------------------

15.6.10 Device Index value is zero upon power up

The Series C FIM4/FIM8 4-character display shows a Device Index value of zero (#000).

Diagnostic Check	Be sure binary-coded decimal rotary switches on the IOTA were not intentionally set to zero to initiate a Device Index/IP Address reset.
Cause 1	Binary-coded decimal rotary switches set to zero.
Solution	Change binary-coded decimal rotary switches to correct setting. See for more information.
Cause 2	The Primary or non-redundant Series C FIM4/FIM8 is defective
Solution	Replace the Primary or non-redundant Series C FIM4/FIM8. See “Replacing failed Series C FIM4 CC- or CU-PFB401” on page 221 for details. If Device Index switch setting matches Device Index number in 4-character display upon Series C FIM4/FIM8 power up, the removed Series C FIM4/FIM8 is defective. Otherwise, go to Cause 3.
Cause 3	The redundant or non-redundant IOTA is defective.
Solution	Replace the IOTA. See “Replacing IOTA DC-TFB402 or DC-TFB412, CC-or CU-TFB401, CC-or CU-TFB411, CC- or CU-TFB402, or CC- or CU-TFB412” on page 222 for details. If Device Index switch setting matches Device Index number in 4-character display upon Series C FIM4/FIM8 power up, the removed IOTA is defective.

15.6.11 Device reload or replacement fails

The device load goes into infinite loop and the load dialog displays the *Validating license* message.

Diagnostic Check	Be sure at least one VCR is free on the given Fieldbus segment.
Cause	Fieldbus segment is configured for maximum VCRs (128).
Solution	Delete a Control Module or device from the Monitoring tab in Control Builder to free a VCR.

15.6.12 Generation of excessive alarms

Diagnostic Check	Alarms generating more frequently than expected.
Causes	<ul style="list-style-type: none"> • Lack of understanding of device behaviors. • Improper behavior of device. • Improper behavior of alarm generation software in the FIM.
Solutions	<ul style="list-style-type: none"> • Confirm the correct bit (s) in the device parameters are set for alarms by confirming the configuration and viewing the corresponding parameters in the device block. • Confirm to set the bit(s) based on the condition of the device. • Check for the device documentation. • Report to the device vendor. • Investigate the root condition(s) by eliminating the alarm or change its priority or criticality. • To change the advanced alarming configuration at the device template level and then reload the device(s). This solution is not ideal if the problem is isolated to only one or few devices as other devices of the same type receives re-configuration when loaded.

15.6.13 Alarms not occurring when expected

Diagnostic Check	Alarms do not occur when expected.
Causes	<ul style="list-style-type: none"> • Correct bit(s) in the device parameters are set for the alarm. • Bit(s) not set appropriately, based on the condition of the device. • Improper behavior of alarm generation software in the FIM.
Solutions	<ul style="list-style-type: none"> • Confirm the correct bit (s) in the device parameters are set for alarms by confirming the configuration and viewing the corresponding parameters in the device block. • Confirm to set the bit(s) based on the condition of the device. • Check for the device documentation. • Report to the device vendor. • Investigate the root condition(s) by eliminating the alarm or change its priority or criticality. • To change the advanced alarming configuration at the device template level and then reload the device(s). This solution is not ideal if the problem is isolated to only one or few devices as other devices of the same type receives re-configuration when loaded.

15.6.14 Connected Fieldbus device is not detected by the FF link

Diagnostic check

Connected Fieldbus device is not detected by the FF link.

Cause

- If the device address provided by the vendor appears outside the range of polled node address. • •
- Slot Time Value might be too low.
- Physical layers issues such as, voltage, signal level, noise, and shield shorts and so on.

Solution

- Increase the Slot Time Value through the Network Management (LM) tab on the FFLink block parameters configuration form.
- Temporarily set the NUN parameter to zero to see if the device appears on the link, and then restore NUN after changing the device node address to valid setting
- Check for the physical layer connections as follows.
 - Voltage at the device end must not exceed 10 V.
 - Cable shield grounded at more than one location or not shielded.
 - Screw terminals are not tight/loose wires.
 - Only two terminators are used in the segment.
 - Noise levels (any AC power cables near Fieldbus cable, loose connection, variable frequency drive, high-powered equipment turned on/off).

For more detailed information, contact Honeywell TAC.

15.7 Getting further assistance

Related topics

“Other troubleshooting sources” on page 258

“Guidelines for requesting support” on page 259

15.7.1 Other troubleshooting sources

The following table lists other documents and sections that contain troubleshooting information for other Experion subsystems.

All of these documents are available on PDF Collection. Some documents are also supplied as part of Station Help. For documents that can be accessed directly from this page, click on the link, otherwise look for the document within PDF Collection where RXXX represents the latest release number designation.

Document/Section	Comments
Experion RXXX > Reference	There is a separate interface reference for each type of controller other than the Process Controller; for example, the ASEA Interface Reference. Most of these references contain an interface-specific troubleshooting section.
Experion RXXX > Reference > TPS Integration Guide > Troubleshooting	Troubleshooting an integrated system that uses Experion "TPS Integration" option.
Experion RXXX > Reference > Control Builder Error Codes Reference	Describes error codes generated from within Control Builder.
Experion RXXX > Troubleshooting and Maintenance > Control Hardware Troubleshooting and Maintenance Guide	The main repository for troubleshooting, maintenance and repair of Process Controllers.
Experion RXXX > Configuration > DeviceNet Implementation Guide > Troubleshooting DeviceNet Status Failures	Describes error codes generated from DeviceNet Interface Board.
Experion RXXX > Installation and Upgrades > Fault Tolerant Ethernet Bridge Implementation Guide > Service > Troubleshooting	Troubleshooting FTE bridges.
Experion RXXX > Installation and Upgrades > Fault Tolerant Ethernet Installation and Service Guide > Troubleshooting FTE Nodes	Troubleshooting FTE nodes.
Experion RXXX > Reference > Honeywell TDC 3000 Data Hiway Interface Reference > TDC error codes and Troubleshooting	Troubleshooting TDC 3000 Hiway problems.
Experion RXXX > Configuration > Qualification and Version Control System User Guide > QVCS Troubleshooting	Troubleshooting QVCS.
Experion RXXX > Operations > SafeView User's Guide > Appendix D - SafeView Error Messages	Describes the meaning of SafeView configuration errors.
Experion RXXX > Reference > Server Scripting Reference > Server scripting error messages	Describes the meaning of error messages in the server log specific to server scripting.
Experion RXXX > Reference > System Management Configuration Guide > Troubleshooting System Management	Describes the meaning of System Management Configuration errors.

Document/Section	Comments
Experion RXXX > Reference > System Management Configuration Guide > Troubleshooting SES	Describes the meaning of SES Configuration errors.
Experion RXXX > Reference > System Management Configuration Guide > Troubleshooting SPS	Describes the meaning of SPS Configuration errors.
Experion RXXX > Planning and Design > Planning, Installation, and Service for WS360	Troubleshooting workstation nodes used in Experion and TPN.

15.7.2 Guidelines for requesting support

If you cannot resolve a problem using this guide, you can request support from your Honeywell Solution Support Center.

When requesting support, please supply as many relevant details as possible, including:

- Short summary of the problem
- Product Name and release.
- **Recent changes**, such as upgrades/service packs, to Experion software, Windows or other applications.
- **Subsystem and its version/build**, if the problem relates to a particular subsystem, such as Station or Quick Builder. If the problem relates to **Display Builder**, please specify whether it is HMIWeb Display Builder (for HMIWeb displays) or Display Builder (for DSP displays).
- **Operating system, variant and service pack**, for example 'Windows 2000 Server, SP5'.
- **Instructions on how to reproduce the problem**. If the problem is reproducible, please supply step-by-step instructions - the more detailed the steps the better.
- Diagnostic package which contains any relevant logs.

<https://maxautol.com/>
 manski@cambid.com.cn +86 18030205125

<https://maxautoland.com/>
manski@cambodia.cn +86 18030205725

16 Fieldbus integration with Experion control reference

This section provides conceptual type information about the integration of Fieldbus devices with Experion control functions. The following table lists the topics included in this section. If you are viewing this information online, just click the topic title to jump to the information location.

Topic
“Series C FIM4/FIM8 handles data integration” on page 263
“About link object” on page 264
“Network management description” on page 265
“System management description” on page 266
“About device objects” on page 267
“About VFD objects” on page 268
“Type creation makes integration possible” on page 269
“Fieldbus device analog input integration” on page 270
“Fieldbus analog input data manipulation” on page 271
“Fieldbus device analog output or PID integration” on page 272
“Fieldbus analog output or PID data manipulation” on page 274
“Fieldbus device discrete input integration” on page 275
“Fieldbus discrete input data manipulation” on page 276
“Fieldbus device discrete output data integration” on page 277
“Fieldbus discrete output data manipulation” on page 278
“Interface connections summary” on page 279
“About SCM parameter interaction” on page 280
“Fieldbus status data details” on page 281
“Fieldbus status indications” on page 282

Related topics

- “Series C FIM4/FIM8 handles data integration” on page 263
- “About link object” on page 264
- “Network management description” on page 265
- “System management description” on page 266
- “About device objects” on page 267
- “About VFD objects” on page 268
- “Type creation makes integration possible” on page 269
- “Fieldbus device analog input integration” on page 270

- “Fieldbus analog input data manipulation” on page 271
- “Fieldbus device analog output or PID integration” on page 272
- “Fieldbus analog output or PID data manipulation” on page 274
- “Fieldbus device discrete input integration” on page 275
- “Fieldbus discrete input data manipulation” on page 276
- “Fieldbus device discrete output data integration” on page 277
- “Fieldbus discrete output data manipulation” on page 278
- “Interface connections summary” on page 279
- “About SCM parameter interaction” on page 280
- “Fieldbus status data details” on page 281
- “Fieldbus status indications” on page 282

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

16.1 Series C FIM4/FIM8 handles data integration

The Series C Fieldbus Interface Module (FIM4/FIM8) functions as a dual network bridge using a dynamic data cache to facilitate the exchange of data between the control communication network and the Fieldbus H1 links. It supports both publish/subscribe and client/server communications methods to implement control connections between Control Builder function blocks and Fieldbus function blocks. The Series C FIM capability includes converting Control Builder value-status structure to Fieldbus value-status by mapping similar fields to one another and defaulting others. This means the Experion system can monitor Fieldbus control functions, fully integrate with control functions, or provide a combination that includes using Fieldbus based control as backup for selected Experion system control functions.

The Series C FIM uses low and high-priority send queues to make sure that publish/subscribe data normally used for control is processed before less important display access data. Publish/subscribe requests are placed in the high-priority send queue and client/server requests are placed in the low one.

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

16.2 About link object

The link object represents one Fieldbus H1 link. It consists of Network Management and System Management information, along with several application parameters related to link functions such as startup, shutdown, and diagnostics.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

16.3 Network management description

Network Management provides the following capabilities for managing the communication system of a Fieldbus device.

- Loading a Virtual Communication Relationship (VCR) list or single entries in this list; (A VCR represents a communication channel through the complete communication stack.)
- Configuring the communication stack;
- Loading the Link Schedule;
- Monitoring performance; and
- Monitoring fault detection.

The collection of managed variables is called the Network Management Information Base (NMIB).

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

16.4 System management description

System Management provides the following functions to coordinate the operation of various devices in a distributed Fieldbus system.

- Assigning node addresses for devices;
- Synchronizing the application clock;
- Distributing application scheduling across the link; and
- Providing support for locating application tags.

It provides the needed facilities for bringing new devices on the link to an operational state and for controlling the overall system operation. Information, which is used to control system management operation, is organized as objects stored in the System Management Information Base (SMIB).

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

16.5 About device objects

The device object represents a physical device entity connected to the Fieldbus link. It provides access to the device's Network Management (NM) and System Management (SM) parameters. The client/server VCR is configured in the Series C FIM to access the Management Interface Base (MIB) of the device as soon as it joins the network. The Control Builder does not configure the MIB VCR explicitly. Once the MIB VCR is configured and opened, Series C FIM retrieves MIB information, SM directory, and NM directory. Knowledge of these directories allows Series C FIM to transform writes into domain object variables into proper sequence of domain download operations. The SM directory is also used to determine the number of application VFDs. The NM directory is key in attempting to configure VCRs to access Function Block Application Process VFDs in the device.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

16.6 About VFD objects

The Virtual Field Device object represents an application VFD and provides parameter access to that VFD. Each physical device may have one or more application VFDs. The Series C FIM attempts to build a client/server VCR to every VFD in the device, when it is added to the network. If the VCR configuration is successful, the Series C FIM obtains VFD and resource identification from the device's VFD. During device download, you can overwrite VCR configuration used to access VFD parameters through the Control Builder application.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

16.7 Type creation makes integration possible

The Fieldbus device Type function included with Control Builder makes integrating Fieldbus function blocks with Control Builder ones possible. The **Type** function reads the manufacturer's DD for the Fieldbus device and creates a device block type that is stored in the Control Builder **Library** tab. The device block type includes the device's Fieldbus function blocks, so it can be configured and integrated with control strategies through Control Builder.


<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

16.8 Fieldbus device analog input integration

A user can functionally 'wire' the output from an Analog Input (AI) function block in a Fieldbus device residing on an H1 link to the input of a regulatory control type function block contained in a Control Module in the Experion Control Builder application. The Proportional, Integral, Derivative (PID) function block is a typical regulatory control type function block.

The following simplified functional diagram shows how the output from an Analog Input function block in a Fieldbus compliant transmitter is integrated with a PID function block in a Control Module that is assigned and loaded to the CEE in the Control Processor Module (CPM).

Table 6: Integration of Fieldbus device analog input signal with Control Builder control strategy



16.9 Fieldbus analog input data manipulation

When the OUT from the Fieldbus analog input function block is wired to the PV input for a PID function block, the Control Builder creates a CEE input agent to handle the analog input from the Fieldbus block. The block-like input agent maps the data structure (DS-65) of the OUT parameter to the Control Builder PV with status parameter. It interprets the value portion in Fieldbus terms and converts it to Control Builder representation. The floating-point representation is identical, in most cases, but the Fieldbus +/-infinity value must be converted to a Control Builder representation.

If the Fieldbus status byte indicates 'BAD', the value must be converted to Not a Number (NaN) for Control Builder representation. The Fieldbus data quality of good, bad, and uncertain is mapped to the appropriate Control Builder parameter of PVSTS, PVSTSFL.NORM, PVSTSFL.BAD, or PVSTSFL.UNCER.

The Fieldbus limit indications of no-limit, limited-low, limited-high, and constant are mapped to the same four indications for Control Builder blocks.

The Fieldbus data sub status indicator maps only the limited number of sub status conditions that have corresponding Control Builder indications. Note that the handshaking provided by the sub status associated with Good [cascade] status is **not** supported from an upstream Fieldbus device. This means that control may **not** originate in the field and cascade into the Controller.


<https://maxautoland.com/>
+86 18030205725
manski@cambid.com.cn

16.10 Fieldbus device analog output or PID integration

A user can functionally 'wire' the output from a regulatory control type function block contained in a Control Module in the Control Builder application to the input of an Analog Output (AO) or Proportional, Integral, Derivative (PID) function block in a Fieldbus device residing on an H1 link. The Proportional, Integral, Derivative (PID) function block is a typical Control Builder regulatory control type function block.


The following simplified functional diagram shows how the output from a PID function block in a Control Module that is assigned and loaded to the CEE in the Control Processor Module (CPM) is integrated with an Analog Output function block in a Fieldbus compliant device.

Table 7: Integration of Fieldbus device analog output signal with Control Builder control strategy



The following simplified functional diagram shows how the output from a PID function block in a Control Module that is assigned and loaded to the CEE in the Control Processor Module (CPM) is integrated with a cascaded Proportional, Integral, Derivative function block in a Fieldbus compliant device.

Table 8: Integration of Fieldbus device PID control with Control Builder control strategy



<https://maxautolab.com/>
 manski@cambia.cn
 18030205725

16.11 Fieldbus analog output or PID data manipulation

When the Output from the PID function block is wired to the CAS_IN input for a Fieldbus Analog Output or Proportional, Integral, Derivative function block, the Control Builder automatically creates a CEE output agent to handle the analog output to the Fieldbus block. The block-like output agent maps the Cont OP with status parameter to the Fieldbus data structure (DS-65) of the CAS_IN parameter. It interprets the value portion in Experion terms and converts it to Fieldbus representation. The floating-point representation is identical, in most cases, but the Experion +/-infinity value must be converted to a Fieldbus representation. If the status of OP is 'BAD', its value must be converted from NaN to zero (0.0) for Fieldbus representation or it may retain its previous good value, as long as the Fieldbus status byte indicates 'BAD'.



WARNING

The Fieldbus Foundation specifications do not clearly state the expectations of Fieldbus devices for handling Not-a-Number (NaN) values. This means that some may behave as the user desires and others may not.

If you compute a data type float + status value that uses data structure (DS-65), which includes all **Foundation** Fieldbus inputs, outputs and some contained parameters, a resulting NaN value passed outbound through the Series C FIM sets the status element to BAD and changes the value element from NaN to 0.0 (zero). If you compute a data type float value, which includes many contained values such as alarm trip points, set points or output limits, gains, and filter time values, a resulting NaN value that is to be passed outbound through the FIM4/FIM8 will not be written and usually results in retention of the previous value. If the device would not behave in the application as you desire, you must add appropriate function blocks or logic to test for and replace the NaN with an acceptable value.

The CEE output agent also accepts a single BKCAL_OUT parameter with the Fieldbus data structure (DS-65) and maps it to the BACKCALIN parameter of the PID block in Experion terms.



Attention

The Experion Control Builder application automatically makes the appropriate back calculation connections during configuration and the connections are 'hidden' in Control Chart views.

Like the Series C FIM, the output agent supports both publish/subscribe and client/server communication methods. The publish/subscribe method allows the Series C FIM to appear as a Fieldbus device on the H1 link. The Series C FIM publishes the output (OP) for subscribing Fieldbus device resident blocks such as Analog Output and Proportional, Integral, Derivative (PID) through their CAS_IN parameter input connection. This connection is generally used when the downstream control block is in the Cas (cascade) mode. This means that the Fieldbus block's BKCAL_OUT parameter is published by the downstream block and subscribed to by the Series C FIM.

The client/server method allows the Series C FIM to appear as a computing device on the H1 link. The Series C FIM writes the output (OP) to be read by Fieldbus device resident blocks such as Analog Output and Proportional, Integral, Derivative (PID) through their RCAS_IN parameter input connection. This connection is generally used when the downstream control block is in the RCas (Remote Cascade) mode. This means that the Fieldbus block's BKCAL_OUT parameter is written by the downstream block and read by the Series C FIM.

The client/server method also allows the Series C FIM to function in a Direct Digital Control (DDC) mode or the Remote Out mode in Fieldbus terms. In this case, the Series C FIM writes the output to be read by the Fieldbus PID block through its ROUT_IN parameter input connection. In turn, the PID block publishes the ROUT_OUT or back calculation output value for the subscribing Series C FIM.

The Control Builder data quality is converted to Fieldbus data quality. The Control Builder Good indication is represented as Fieldbus Good (Cascade).

The Control Builder limit indications of no-limit, limited-low, limited-high, and constant are mapped to the same four indications for Fieldbus.


The Control Builder control initialization indicators map only to the limited number of sub status conditions that have corresponding indications in Fieldbus Good (Cascade).

16.12 Fieldbus device discrete input integration

A user can functionally 'wire' the output from a Discrete Input (DI) function block in a Fieldbus device residing on an H1 link to the input of a Device Control (DEVCTL) function block or other block with a digital input contained in a Control Module in the Experion Control Builder application.

The following simplified functional diagram shows how the output from an Discrete Input function block in a Fieldbus compliant transmitter is integrated with a Device Control (DEVCTL) function block in a Control Module that is assigned and loaded to the CEE in the Control Processor Module (CPM).

Table 9: Integration of Fieldbus device digital input signal with Control Builder control strategy



<https://maxautol.com/>
manski@campia.ch +86 18030205725

16.13 Fieldbus discrete input data manipulation

When the OUT from the Fieldbus Discrete Input function block is wired to the DI[n] input for a DEVCTL function block, the Control Builder creates a CEE discrete input agent to handle the digital input from the Fieldbus block. The block-like discrete input agent maps the data structure (DS-66) of the OUT parameter to the Experion DI[n] with status parameter. It interprets the value portion in Fieldbus terms as a Boolean for Discrete Input (DI) block and as the appropriate multi-state representation for special Fieldbus Device Control (DC) block. The value is converted and represented in Control Builder at the output.

The discrete input agent accepts inputs from either a published parameter or a client/server read parameter, depending upon the communication method used.

The Fieldbus data quality of good (cascade), good (non-cascade), bad, and uncertain is mapped to the appropriate Control Builder parameter for good, bad, and uncertain.


<https://maxautoland.com/>
+86 18030205725
manski@cambia.cn

16.14 Fieldbus device discrete output data integration

A user can functionally 'wire' the output from a discrete process or control value producing Control Builder function block like Device Control to the input of a Discrete Output block in a Fieldbus device residing on an H1 link.

The following simplified functional diagram shows how the output from a Device Control (DEVCTL) function block in a Control Module that is assigned and loaded to the CEE in the Control Processor Module (CPM) is integrated with a Discrete Output function block in a Fieldbus compliant device.

Table 10: Integration of Fieldbus device digital output signal with Control Builder control strategy



16.15 Fieldbus discrete output data manipulation

When the DO[n] from the Device Control (DEVCTL) function block is wired to the CAS_IN_D input for a Fieldbus Discrete Output function block, the Control Builder automatically creates a CEE output agent to handle the discrete output to the Fieldbus block. The block-like output agent maps the Control Builder DO[n] with status parameter to the Fieldbus data structure (DS-66) of the CAS_IN_D parameter. It interprets the value portion in Control Builder terms and converts it to Fieldbus representation.

The CEE output agent also accepts a single BKCAL_OUT_D parameter with the Fieldbus data structure (DS-66) and maps it to the BACKCALIN parameter of the DEVCTL block in Control Builder terms.

It sends the outgoing 'control signal' either to a subscribed parameter or a client/server written parameter through the CAS_IN_D or RCAS_OUT_D connection. It can optionally receive the backcalculation signal from either the corresponding published parameter or client/server read parameter.

The Control Builder data quality is converted to Fieldbus data quality. The Control Builder Good indication is represented as Fieldbus Good (Cascade).

The Control Builder control initialization indicators map only to the limited number of sub status conditions that have corresponding indications in Fieldbus Good (Cascade).

<https://maxautoland.com/>
+86 18030205725
manski@cambid.com.cn

16.16 Interface connections summary

Since the downstream action with the upstream feedback is the same for all Fieldbus blocks, there are essentially the following six types of interface connections through the FIM4/FIM8.

Analog process value into the FIM4/FIM8.

Discrete process value into the FIM4/FIM8.

Analog process output from the FIM4/FIM8.

Discrete process output from the FIM4/FIM8.

Analog process output from the FIM4/FIM8 with backcalculation feedback.

Discrete process output from the FIM4/FIM8 with backcalculation feedback.

Note that types 5 and 6 support publish/subscribe communications in Cascade mode or client/server communications in Remote Cascade mode. And, the analog values can also be used in the Remote Out mode.

Fieldbus also supports direct device-to-device (peer-to-peer) publish/subscribe connections independent of the FIM4/FIM8. The FIM4/FIM8 can also monitor (subscribe to) the data published between the functions blocks of these Fieldbus devices.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

16.17 About SCM parameter interaction

Sequential Control Module (SCM) Steps and Transitions can write to any contained parameter of a Fieldbus function block. The value of a contained parameter can be configured, set by an operator, higher level device, or calculated. For example, the GRANT_DENY parameter can be used to check access rights, the MODE_BLK parameter can be used to request mode changes, and the RCAS_IN and RCAS_OUT parameters can be used to control set points in the Remote Cascade mode.

If the contained parameter has a DS-65 or DS-66 data structure, you must use multiple SCM Step outputs to write to the different fields in the parameter's data structure. For example, if you use a Step output to write to the SP parameter of a Fieldbus PID block, when it is in Auto mode, you will need Step outputs for the related parameter attributes of value, status, sub status and limits, as defined by its structure. A typical SCM write SP scenario would include the following actions.

- Transition checks if Target MODE of the Fieldbus block is AUTO.
- Step output sets Target MODE to AUTO, if required.
- Step output sets SP value and GOOD (Non Cascade) status.
- Optional Step output to set SP Limits.
- Optional Transition to verify that the value got stored in the Fieldbus device.

The SCM will issue a fail alarm, if the store fails for any reason.



Attention

Avoid SCM configurations that would push a NaN (Not a Number) value as an output to a Fieldbus device. If this is not possible, be sure to test the field device to observe how it reacts to the possible NaN value.

<https://maxautoland.com/>
+86 18030203725
manski@cambiala.cn

16.18 Fieldbus status data details

According to Fieldbus Foundation specifications, every Fieldbus function block input and output connection must support a status byte that provides the following status indications.

- Data Quality (usability)
- Bad Data Cause
- Degraded Data Cause
- Limit Conditions
- Cascade Control Initialization, Rejection
- Fault-State Initiation, Indication
- Local Override Indication
- Worst Case Alarm Indication
- Upstream Block Class Identification

The status byte structure consists of a 2-bit quality, most significant bit, field; a 4-bit sub status field; and a 2-bit limits, least significant bit, field. The following table provides a breakdown of bit assignments for general reference. The value of the quality field determines the applicable sub status field indication.

Bit	Quality	Sub status, if Quality field is				Limits
		BAD	UNCERTAIN	GOOD (Non-Cascade)*	GOOD (Cascade)*	
0	BAD Data Quality	Non-Specific	Non-Specific	Non-Specific	Non-Specific	No Limits
1	UNCERTAIN Data Quality	Configuration Error	Last Usable Value	Active Block Alarm	Initialization Acknowledge (IA)	Low Limit
2	GOOD (Non-Cascade) Data Quality	Not Connected	Substitute	Active Advisory Alarm	Initialization Request (IR)	High Limit
3	GOOD (Cascade) Data Quality	Device Failure	Initial Value	Active Critical Alarm	Not Invited (NI)	Constant
4		Sensor Failure	Sensor Conversion Not Accurate	Unacknowledged Block Alarm	Not Selected (NS)	
5		No Communication, with Last Usable Value	Engineering Unit Range Violation	Unacknowledged Advisory Alarm	Do Not Select (DNS)	
6		No Communication, with no Last Usable Value	Sub-Normal	Unacknowledged Critical Alarm	Local Override (LO)	
7		Out-Of-Service			Fault-State Active (FSA)	
8					Initiate Fault-State (IFS)	

* The Good (non-cascade) sub status is used by output connections for Fieldbus blocks such as Analog Input and Discrete Input. The Good (cascade) sub status is used by output connections for Fieldbus blocks such as PID. Both of these sub statuses are converted to the single system data quality of Good.

16.19 Fieldbus status indications

The following tables include a list of possible display indications associated with a given Fieldbus status and definitions of related sub statuses.

Fieldbus Status Byte			1-Char Suffix	12-Char Independent Status Field
Quality	Sub status	Limits		
BAD	Non-Specific	No Limits	B	Bad
BAD	Non-Specific	Low Limit	B	Bad,LowLimit
BAD	Non-Specific	High Limit	B	Bad,HiLimit
BAD	Non-Specific	Constant	B	Bad,Constant
BAD	Configuration Error	No Limits	B	Bad,Config
BAD	Configuration Error	Low Limit	B	Bad,Config,L
BAD	Configuration Error	High Limit	B	Bad,Config,H
BAD	Configuration Error	Constant	B	Bad,Config,C
BAD	Not Connected	No Limits	B	Bad,NotCon
BAD	Not Connected	Low Limit	B	Bad,NotCon,L
BAD	Not Connected	High Limit	B	Bad,NotCon,H
BAD	Not Connected	Constant	B	Bad, NotCon,C
BAD	Device Failure	No Limits	B	Bad,DevFail
BAD	Device Failure	Low Limit	B	Bad,DevFail,L
BAD	Device Failure	High Limit	B	Bad,DevFail,H
BAD	Device Failure	Constant	B	Bad,DevFail,C
BAD	Sensor Failure	No Limits	B	Bad,SensFail
BAD	Sensor Failure	Low Limit	B	Bad,SnFail,L
BAD	Sensor Failure	High Limit	B	Bad,SnFail,H
BAD	Sensor Failure	Constant	B	Bad,SnFail,C
BAD	No Comm, Last Usable	No Limits	B	Bad,LUValue
BAD	No Comm, Last Usable	Low Limit	B	Bad,LUV,L
BAD	No Comm, Last Usable	High Limit	B	Bad,LUV,H
BAD	No Comm, Last Usable	Constant	B	Bad,LUV,C
BAD	No Comm, No Last Usable	No Limits	B	Bad,NoComm
BAD	No Comm, No Last Usable	Low Limit	B	Bad,NoComm,L
BAD	No Comm, No Last Usable	High Limit	B	Bad,NoComm,H
BAD	No Comm, No Last Usable	Constant	B	Bad,NoComm,C
BAD	Out-Of-Service	No Limit	B	Bad,OutSvc

Fieldbus Status Byte			1-Char Suffix	12-Char Independent Status Field
Quality	Sub status	Limits		
BAD	Out-Of-Service	Low Limit	B	Bad,OutSvc,L
BAD	Out-Of-Service	High Limit	B	Bad,OutSvc,H
BAD	Out-Of Service	Constant	B	Bad,OutSvc,C
UNCERTAIN	Non-Specific	No Limits	U	Uncertain
UNCERTAIN	Non-Specific	Low Limit	U	Uncertain,L
UNCERTAIN	Non-Specific	High Limit	U	Uncertain,H
UNCERTAIN	Non-Specific	Constant	U	Uncertain,C
UNCERTAIN	Last Usable	No Limits	U	Unc,LastOK
UNCERTAIN	Last Usable	Low Limit	U	Unc,LastOK,L
UNCERTAIN	Last Usable	High Limit	U	Unc,LastOK,H
UNCERTAIN	Last Usable	Constant	U	Unc,LastOK,C
UNCERTAIN	Substitute	No Limits	U	Unc,Subst
UNCERTAIN	Substitute	Low Limit	U	Unc,Subst,L
UNCERTAIN	Substitute	High Limit	U	Unc,Subst,H
UNCERTAIN	Substitute	Constant	U	Unc,Subst,C
UNCERTAIN	Initial Value	No Limits	U	Unc,Initial
UNCERTAIN	Initial Value	Low Limits	U	Unc,Init,L
UNCERTAIN	Initial Value	High Limits	U	Unc,Init,H
UNCERTAIN	Initial Value	Constant	U	Unc,Init,C
UNCERTAIN	Sensor Conversion Not Accurate	No Limit	U	Unc,NotAcc
UNCERTAIN	Sensor Conversion Not Accurate	Low Limit	U	Unc,NotAcc,L
UNCERTAIN	Sensor Conversion Not Accurate	High Limit	U	Unc,NotAcc,H
UNCERTAIN	Sensor Conversion Not Accurate	Constant	U	Unc,NotAcc,C
UNCERTAIN	Engineering Unit Range Violation	No Limits	U	Unc,Range
UNCERTAIN	Engineering Unit Range Violation	Low Limit	U	Unc,Range,L
UNCERTAIN	Engineering Unit Range Violation	High Limit	U	Unc,Range,H
UNCERTAIN	Engineering Unit Range Violation	Constant	U	Unc,Range,C
UNCERTAIN	Sub-Normal	No Limits	U	Unc,SubNorm
UNCERTAIN	Sub-Normal	Low Limit	U	Unc,SubNrm,L
UNCERTAIN	Sub-Normal	High Limit	U	Unc,SubNrm,H
UNCERTAIN	Sub-Normal	Constant	U	Unc,SubNrm,C
GOOD (Non-Cascade)	Non-Specific	No Limits	<blank>	<blank>
GOOD (Non-Cascade)	Non-Specific	Low Limit	L	Low Limit

Fieldbus Status Byte			1-Char Suffix	12-Char Independent Status Field
Quality	Sub status	Limits		
GOOD (Non-Cascade)	Non-Specific	High Limit	H	High Limit
GOOD (Non-Cascade)	Non-Specific	Constant	C	Constant
GOOD (Non-Cascade)	Active Block Alarm	No Limits	A	Alarm-Block
GOOD (Non-Cascade)	Active Block Alarm	Low Limit	A	Alarm-Blck,L
GOOD (Non-Cascade)	Active Block Alarm	High Limit	A	Alarm-Blck,H
GOOD (Non-Cascade)	Active Block Alarm	Constant	A	Alarm-Blck,C
GOOD (Non-Cascade)	Active Advisory Alarm	No Limits	A	Alarm-Advis
GOOD (Non-Cascade)	Active Advisory Alarm	Low Limit	A	Alarm-Advis,L
GOOD (Non-Cascade)	Active Advisory Alarm	High Limit	A	Alarm-Advis,H
GOOD (Non-Cascade)	Active Advisory Alarm	Constant	A	Alarm-Advis,C
GOOD (Non-Cascade)	Active Critical Alarm	No Limits	A	Alarm-Crit
GOOD (Non-Cascade)	Active Critical Alarm	Low Limit	A	Alarm-Crit,L
GOOD (Non-Cascade)	Active Critical Alarm	High Limit	A	Alarm-Crit,H
GOOD (Non-Cascade)	Active Critical Alarm	Constant	A	Alarm-Crit,C
GOOD (Non-Cascade)	Unacknow-ledged Block Alarm	No Limits	A	Alm-U-Block
GOOD (Non-Cascade)	Unacknow-ledged Block Alarm	Low Limit	A	Alm-U-Blck,L
GOOD (Non-Cascade)	Unacknow-ledged Block Alarm	High Limit	A	Alm-U-Blck,H
GOOD (Non-Cascade)	Unacknow-ledged Block Alarm	Constant	A	Alm-U-Blck,C
GOOD (Non-Cascade)	Unacknow-ledged Advisory Alarm	No Limits	A	Alm-U-Advis
GOOD (Non-Cascade)	Unacknow-ledged Advisory Alarm	Low Limit	A	Alm-U-Advs,L
GOOD (Non-Cascade)	Unacknow-ledged Advisory Alarm	High Limit	A	Alm-U-Advs,H
GOOD (Non-Cascade)	Unacknow-ledged Advisory Alarm	Constant	A	Alm-U-Advs,C
GOOD (Non-Cascade)	Unacknow-ledged Critical Alarm	No Limits	A	Alm-U-Crit

Fieldbus Status Byte			1-Char Suffix	12-Char Independent Status Field
Quality	Sub status	Limits		
GOOD (Non-Cascade)	Unacknow-ledged Critical Alarm	Low Limit	A	Alm-U-Crit,L
GOOD (Non-Cascade)	Unacknow-ledged Critical Alarm	High Limit	A	Alm-U-Crit,H
GOOD (Non-Cascade)	Unacknow-ledged Critical Alarm	Constant	A	Alm-U-Crit,C
GOOD (Cascade)	Non-Specific	No Limits	<blank>	<blank>
GOOD (Cascade)	Non-Specific	Low Limit	L	Low Limit
GOOD (Cascade)	Non-Specific	High Limit	H	High Limit
GOOD (Cascade)	Non-Specific	Constant	C	Constant
GOOD (Cascade)	Acknowledge Initialization (IA)	No Limit		InitAck
GOOD (Cascade)	Acknowledge Initialization (IA)	Low Limit		InitAck,L
GOOD (Cascade)	Acknowledge Initialization (IA)	High Limit		InitAck,H
GOOD (Cascade)	Acknowledge Initialization (IA)	Constant		InitAck,C
GOOD (Cascade)	Request Initialization (IR)	No Limits	R	ReqInit
GOOD (Cascade)	Request Initialization (IR)	Low Limit	R	ReqInit,L
GOOD (Cascade)	Request Initialization (IR)	High Limit	R	ReqInit,H
GOOD (Cascade)	Request Initialization (IR)	Constant	R	ReqInit,C
GOOD (Cascade)	Not Invited (NI)	No Limits	N	NotInvited
GOOD (Cascade)	Not Invited (NI)	Low Limit	N	NotInvited,L
GOOD (Cascade)	Not Invited (NI)	High Limit	N	NotInvited,H
GOOD (Cascade)	Not Invited (NI)	Constant	N	NotInvited,C
GOOD (Cascade)	Not Selected (NS)	No Limits	N	NotSelected
GOOD (Cascade)	Not Selected (NS)	Low Limit	N	NotSelectd,L
GOOD (Cascade)	Not Selected (NS)	High Limit	N	NotSelectd,H
GOOD (Cascade)	Not Selected (NS)	Constant	N	NotSelectd,C
GOOD (Cascade)	Local Override (LO)	No Limits	O	OverrideLoel
GOOD (Cascade)	Local Override (LO)	Low Limit	O	OverrideLc,L
GOOD (Cascade)	Local Override (LO)	High Limit	O	OverrideLc,H
GOOD (Cascade)	Local Override (LO)	Constant	O	OverrideLc,C
GOOD (Cascade)	Fault-State Active (FSA)	No Limits	F	FaultState
GOOD (Cascade)	Fault-State Active (FSA)	Low Limit	F	FaultState,L
GOOD (Cascade)	Fault-State Active (FSA)	High Limit	F	FaultState,H

Fieldbus Status Byte			1-Char Suffix	12-Char Independent Status Field
Quality	Sub status	Limits		
GOOD (Cascade)	Fault-State Active (FSA)	Constant	F	FaultState,C
GOOD (Cascade)	Initiate Fault-State (IFS)	No Limits	<blank>	InitFaultSt
GOOD (Cascade)	Initiate Fault-State (IFS)	Low Limit	L	LoLim,InitFS
GOOD (Cascade)	Initiate Fault-State (IFS)	High Limit	H	HiLim,InitFS
GOOD (Cascade)	Initiate Fault-State (IFS)	Constant	C	Const,InitFS

16.19.1 Sub status Definitions for Quality Status

Quality	Sub status	Description
Bad	Non-Specific	There is no specific reason why the value is bad. Used for propagation.
	Configuration Error	Set if the value is not useful because there is some other problem with the block, depending on what a specific manufacturer can detect.
	Not Connected	Set if this input is required to be connected and is not.
	Device Failure	Set if the source of the value is affected by a device failure.
	Sensor Failure	Set if the device can determine this condition. The Limits define which direction has been exceeded.
	No Communication, with last usable value	Set if this value had been set by communication, which has now failed.
	No Communication, with no usable value	Set if there has never been any communication with this value, since it was last Out of Service.
Uncertain	Non-Specific	There is no specific reason why this value is uncertain. Used for propagation.
	East Usable Value	Whatever was writing this value has stopped. (This happens when one disconnects an input.)
	Substitute	Set when the value is written when the block is Out of Service.
	Initial Value	Set when the value of an input parameter is written while the block is Out of Service.
	Sensor Conversion Not Accurate	Set if the value is at one of the sensor limits. The limits define which direction has been exceeded. Also, set if the device can determine that the sensor has reduced accuracy, in which case no limits are set.
	Engineering Unit Range Violation	Set if the value lies outside of the range of values defined for this parameter. The limits define which direction has been exceeded.
	Sub-Normal	Set if value derived from multiple values has less than the required number of Good sources.
Good (Non-Cascade)	Non-Specific	There is no specific reason why the value is good. No error or special condition is associated with this value.
	Active Block Alarm	Set if the value is good and the block has an active Block alarm.

Quality	Sub status	Description
	Active Advisory Alarm	Set if the value is good and the block has an active alarm with a priority less than 8.
	Active Critical Alarm	Set if the value is good and the block has an active alarm with a priority greater than or equal to 8.
	Unacknowledged Block Alarm	Set if the value is good and the block has an unacknowledged Block alarm.
	Unacknowledged Advisory Alarm	Set if the value is good and the block has an unacknowledged alarm with a priority of less than 8.
	Unacknowledged Critical Alarm	Set if the value is good and the block has an unacknowledged alarm with a priority greater than or equal to 8.
Good (Cascade)	Non-Specific	There is no specific reason why the value is good. No error or special condition associated with this value.
	Initialization Acknowledge	The value is an initialized value from a source (cascade input, remote-cascade in, and remote-output in parameters).
	Initialization Request	The value is an initialization value from a source (back calculation input parameter), because the lower loop is broken or the mode is wrong.
	Not Invited	The value is from a block, which does not have a target mode that would use this input. This covers all cases other than Fault State Active, Local Override, and Not Selected. The target mode can be the next permitted mode of higher priority in the case of shedding a supervisory computer.
	Not Selected	The value is from a Control Selector that has not selected the corresponding input. This tells the upper block to limit in one direction, not initialize.
	Do Not Select	The value is from a block that should not be selected by a control selection block, due to conditions in or above the block. As an option, a block may generate this output status if its actual mode is not Auto or not Cascade.
	Local Override	The value is from a block that has been overridden by a local key switch or is a complex AO/DO with interlock logic active. The failure of normal control must be propagated to a PID block for alarm and display purposes. This also implies Not Invited.
	Fault State Active	The value is from a block that has Fault State active. The failure of normal control must be propagated to a PID block for alarm and display purposes. This also implies Not Invited.
	Initiate Fault State	The value is from a block that wants its downstream output block to go to Fault State. This is determined by a block option to initiate Fault State if the status of the primary input and/or cascade input goes Bad.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

17 Control mode interaction reference

This section provides conceptual type information about Fieldbus block mode interaction with Experion control modes. The following table lists the topics included in this section. If you are viewing this information online, just click the topic title to jump to the information location.

Topic
“Fieldbus block modes versus control modes” on page 290
“Control mode priorities and indications” on page 292
“Rotary Switch Model versus Toggle Switch Model” on page 293
“Display indications and mode calculation” on page 294
“Mode change conditions” on page 295
“Access control through GRANT_DENY parameter” on page 297

Related topics

- [“Fieldbus block modes versus control modes” on page 290](#)
- [“Control mode priorities and indications” on page 292](#)
- [“Rotary Switch Model versus Toggle Switch Model” on page 293](#)
- [“Display indications and mode calculation” on page 294](#)
- [“Mode change conditions” on page 295](#)
- [“Access control through GRANT_DENY parameter” on page 297](#)

https://manuals.diaand.com/18030205725
manski@cambium.com

17.1 Fieldbus block modes versus control modes

Every Fieldbus function block including Resource and Transducer blocks contain the MODE_BLK parameter. This structured parameter consists of the Actual, Target, Permitted, and Normal modes. The eight possible modes are described in the “About modes of operation” on page 322 paragraph in the “Standard Function Blocks” on page 321 section in this book.

For use within the Experion system, the structure of the MODE_BLK parameter is expanded to add MODE to the existing Actual, Target, Permitted, and Normal modes as outlined in the following table.

Control Mode Structure	Data Type	Description
MODE	Enumeration	Write Only Experion system style mode enumeration MAN, AUTO, CAS, NORMAL, BCAS, NONE
MODE.TARGET	Enumeration	Read/Write Target mode OOS, MAN, AUTO, CAS, RCAS, ROUT
MODE.ACTUAL	Enumeration	Read Only Actual Mode OOS, IMAN, IO, MAN, AUTO, CAS, RCAS, ROUT
MODE.PERMITTED	Bitstring	Read/Write Permitted mode MAN, AUTO, CAS, RCAS, ROUT OOS is always permitted
MODE.NORMAL	Enumeration	Read/Write Normal mode MAN, AUTO, CAS, RCAS, ROUT OOS is not Normal

The Experion system uses the name MODE instead of MODE_BLK and its enumeration set is identical to that used in Fieldbus. Mode is a write only parameter and the /FIM8 will reject all reads. The FIM4/FIM8 captures all writes to MODE and maps valid changes to MODE.TARGET. If the value NORMAL is written to the MODE.TARGET, the FIM4/FIM8 replaces it with the value from MODE.NORMAL. If a new MODE.NORMAL value is entered, it is validated against the MODE.PERMITTED values. The OOS mode is not an acceptable normal mode.

When a new MODE.PERMITTED value is entered, the FIM4/FIM8 forces the OOS mode to be permitted. Only a user with an access level of Engineer is allowed to put a block into its OOS mode or to return the block to an operating mode. This means a user must have an access level of Engineer to put a block in Man, Auto, Cas, Rcas, or Normal, if the blocks current target mode is OOS. When a mode is changed, the FIM4/FIM8 clears the GRANT_DENY.GRANT parameter bits. It is standard Experion system behavior to take a grant back after an operator changes a mode relative to its mode attribute (MODATTR) parameter.

The following table shows how control modes are mapped to Fieldbus ones.

Control Mode	Fieldbus Mode	Comment
MAN	Man	
AUTO	Auto	
CAS	Cas	

Control Mode	Fieldbus Mode	Comment
NORMAL	Normal	When setting as target mode, read MODE.NORMAL value and write to MODE.TARGET.
BCAS	Error!	Not used in Fieldbus blocks. Attempt to set to target is illegal.
NONE	Error!	Not used in Fieldbus blocks. Attempt to set to target is illegal.

<https://maxautoland.com/>
 manski@cambria.cn +86 18030205725

17.2 Control mode priorities and indications

The following table shows the 2-character and 4-character mode indications to be used in operating displays and lists the mode priorities based on several interpretations. The Priority Order interpretation is based on the Out-of-Service mode being serviced over all others. The Control Order interpretation is based on the traditional control engineer's concept that Cascade is a higher mode of operation than Automatic, Automatic is a higher mode of operation than Manual, and so on. The Dominance Order interpretation is based on Fieldbus Foundation special rules for modes dominating one another. For example, Out-of-Service dominates over Manual, Manual dominates over Remote Out, and Remote Out dominates over Remote Cascade. This is relevant, if multiple mode bits are set in the target (or normal) mode bitstrings.

A block uses the concept of priority to compute an actual mode that is different from the target mode, and to determine if the particular actual mode allows write access.

2-Char	Mode Abbreviation		Priority Interpretation		
	4-Char	Priority Order (8=highest)	Control Order (8=highest)	Dominance Order (6=Highest)	
Out-of-Service	OS	OOS	8	1	6
Initialization Manual	IM	IMan	7	2	-
Local Override	LO	LO	6	3	-
Manual	M	Man	5	4	5
Auto	A	Auto	4	5	1
Cascade	C	Cas	3	6	2
Remote Cascade	RC	RCas	2	7	3
Remote Output	RO	ROut	1	8	4

While every type or block instance does not need to support all eight modes, all eight indicator bits are present in the database. The mode bit assignments are listed below for reference.

Bit		Mode
0 (LSB)	=	Remote Output (ROut)
1	=	Remote Cascade (RCas)
2	=	Cascade (Cas)
3	=	Automatic (Auto)
4	=	Manual (Man)
5	=	Local Override (LO)
6	=	Initialization Manual (IMan)
7 (MSB)	=	Out of Service (OOS)

17.3 Rotary Switch Model versus Toggle Switch Model

The Fieldbus Foundation supports both the Rotary Switch and the Toggle Switch models of mode operation. The Rotary Switch model supports only one mode request at a time. For example, an operator can request OOS, Man, Auto, Cas, RCas, or ROut. It has no memory of previous target modes.

The Toggle Switch model supports more than one mode request at a time. For example, an operator can request Manual override of Cascade, Manual override of Remote Cascade, and so on.

Experion supports the Rotary Switch model as well as the following two instances of the Toggle Switch model.

- An operator may request the Cas mode at the same time the RCas mode is requested
- An operator may request the Cas mode at the same time the ROut mode is requested

Experion also ignores the following illegal mode combinations as defined by the Fieldbus Foundation.

- If ROut is set, RCas may not be set. If it is set, it will be ignored.
- The Auto and Man bits must always be of opposite states. If neither Auto nor Man or both are set, and the ROut, RCas, or Cas mode is set, Auto mode will be assumed with Man cleared. Likewise, if neither Auto nor Man or both are set, and neither ROut, RCas, nor Cas mode is set, Man mode will be assumed with Auto cleared. For the OOS mode, the Man bit should be set unless it is not permitted. If Man is not permitted, the Auto bit should be set unless it is not permitted. If neither Auto nor Man is permitted, the OOS bit should be set.

! Attention

- An operator needs an access level of ENGR or higher to invoke the OOS mode or to return a block to an in-service mode.

The Experion system adheres to the following additional rules for setting Fieldbus target mode bits for its MODE supported subset of combinations.

Fieldbus Mode	Rule
OOS	When setting as the target mode, obtain the target mode, preserve the Auto and Man bits, set the OOS bit, and optionally reset all the other bits. Reject the request, if the access level is not ENGR or higher.
IMan	This is a Read Only parameter and cannot be set as the target mode. Never set the IMan as the target mode.
LO	This is a Read Only parameter and cannot be set as the target mode. Never set the LO as the target mode.
Man	When setting as the target mode, set the Man bit and reset all the other bits. Reject the request, if the current mode is OOS and the access level is not ENGR or higher.
Auto	When setting as the target mode, set the Auto bit and reset all the other bits. Reject the request, if the current mode is OOS and the access level is not ENGR or higher.
Cas	When setting as the target mode, set both Cas and Auto bits and reset all the other bits. Reject the request, if the current target mode is OOS and the access level is not ENGR or higher.
RCas	When setting as the target mode, set both RCas and Auto bits and reset all the other bits. Reject the request, if the current target mode is OOS and the access level is not ENGR or higher.
ROut	When setting as the target mode, set both ROut and Auto bits and reset all the other bits. Reject the request, if the current target mode is OOS and the access level is not ENGR or higher.
Normal	When setting as the target mode, read the MODE.NORMAL value and write to the MODE.TARGET. Reject the request, if the current target mode is OOS and the access level is not ENGR or higher.

17.4 Display indications and mode calculation

The Fieldbus mode indications for actual mode and composite actual/target modes will appear in the following formats on Station displays.

Format	Description	Examples
a	Satisfied in mode a; actual same as target.	OOS, MAN, AUTO, CAS, RCAS, ROUT
a (t)	In mode a; not satisfied in higher target mode t.	MAN (A), CAS (RC), IM (A), LO (CAS), AUTO (M), CAS (M)

The block mode calculation of actual mode considers the input parameter status attributes, input values, and resource state as represented graphically in the figure below.




Figure 35: Block mode calculation summary

17.5 Mode change conditions

The following table provides a list of conditions, which will change the mode in order of priority with Good (Non-Cascade) status on input parameter as the lowest priority.

Input Parameters Status Attributes, Inputs Values and Resource States	Mode Parameter - Target Attribute Value					
	Manual (MAN)	Auto-matic (Auto)	Cascade (CAS)	Remote Cascade (RCAS)	Remote Output (ROUT)	
Out of Service (OOS)						
All input parameters have Good Status or Uncertain status with option set to treat Uncertain as Good.	OOS	MAN	AUTO	CAS	RCAS	ROUT
Remote cascade in has BAD status.	OOS	MAN	AUTO	CAS	Shed based on Shed Option	ROUT
Remote out in has BAD status.	OOS	MAN	AUTO	CAS	RCAS	Shed based on Shed Option
Cascade input has a status attribute of BAD	OOS	MAN	AUTO	Shed to next permitted mode*	RCAS	ROUT
Target mode is RCAS and remote cascade in does not have status of Good - Initialization Acknowledge; and actual mode attribute last execution was not RCAS.	N/A	N/A	N/A	N/A	Actual mode from last execution or AUTO	N/A
Target mode is ROUT and remote out in status is not Good - Initialization Acknowledge; and actual mode attribute last execution was not ROUT	N/A	N/A	N/A	N/A	N/A	Actual mode from last execution or MAN or mode as determined by Shed Option
Target mode is CAS and cascade input status is not Good - Initialization Acknowledge and actual mode attribute last execution was not CAS	N/A	N/A	N/A	Actual mode from last execution or AUTO or MAN	N/A	N/A
Status attribute of primary input parameter is BAD or Uncertain with option to treat Uncertain as BAD and bypass not set	OOS	MAN	MAN	MAN	MAN	ROUT
Status attribute of back calculation input parameter is BAD	OOS	IMAN	IMAN	IMAN	IMAN	IMAN

Input Parameters Status Attributes, Inputs Values and Resource States	Mode Parameter - Target Attribute Value					
Out of Service (OOS)	Manual (MAN)	Auto-matic (Auto)	Cascade (CAS)	Remote Cascade (RCAS)	Remote Output (ROUT)	
Status attribute of back calculation input parameter Good - fault state active, local override, not invited, or initialization request	OOS	IMAN	IMAN	IMAN	IMAN	IMAN
Tracking is enabled, track input active and track override manual is Enabled.	OOS	LO	LO	LO	LO	LO
Tracking is enabled, initiated and track override manual is Disabled.	OOS	MAN	LO	LO	LO	LO
Fault State is active in an output function block	OOS	LO	LO	LO	LO	LO
If target mode has changed from OOS to another mode since the block was last executed.	-	MAN or evaluated mode	MAN or evaluated mode	MAN or evaluated mode	MAN or evaluated mode	MAN or evaluated mode
Resource state as reflected in the resource block parameter resource state is Standby.	OOS	OOS	OOS	OOS	OOS	OOS

*Shed to the next lowest priority that is permitted and supported by the available inputs.

<https://maxautoland.com/>
 manski@cambid.com +86 18030295725

17.6 Access control through GRANT_DENY parameter

Every Fieldbus function block includes a GRANT_DENY parameter. It allows users to Grant and Deny access permission to groups of function block parameters by other devices. The following table summarizes the attributes for the Grant and Deny elements of the parameter.

Element and Bit	Attribute	Description
GRANT_DENY.GRANT:0	Program Operations	Grants permission to higher level device to change the target mode, set point or output of a block, depending on block mode.
GRANT_DENY.GRANT:1	Tune	Grants permission to higher level device to change tuning parameters of the block.
GRANT_DENY.GRANT:2	Alarm	Grants permission to higher level device to change alarm parameters of the block
GRANT_DENY.GRANT:3	Local Operations	Grants permission to a local operator's panel or hand-held device to change target mode, set point, or output of the block, depending on block mode.
GRANT_DENY.DENY:0	Program Operations	Turns off Program Operations permission grant.
GRANT_DENY.DENY:1	Tune	Turns off Tune permission grant.
GRANT_DENY.DENY:2	Alarm	Turns off Alarm permission grant.
GRANT_DENY.DENY:3	Local Operations	Turns off Local Operations grant.

The Grant selections are mutually exclusive. If you select Program Operations, the Local Operations selection is turned off. If Local Operations is selected, neither an operator nor a high level device (program) has the right to modify a parameter value of the block. Note that access by another function block is always granted and is independent of GRANT_DENY selections. Also, an operator can always change the MODE of a block with Program or Local Operations Granted. When an operator changes the MODE, it automatically resets all four Grants to off.

<https://maxautomation.com/1893920512>
 manski@cambid.com

<https://maxautoland.com/>
manski@cambodia.cn +86 18030205725

18 Fieldbus Link Active scheduler and Link Master functions

This section provides conceptual type information about Fieldbus Link Active Scheduler and Link Master functions. The following table lists the topics included in this section. If you are viewing this information online, just click the topic title to jump to the information location.

Topic
<i>Link Active Scheduler (LAS) and Link Master</i>
“Link Schedule” on page 301
“Function block execution schedule” on page 302

All links must have a Link Active Scheduler (LAS). The LAS operates at the data link layer as the bus arbiter for the link. It provides the following functions.

- Recognizes and adds new devices to the link.
- Removes non-responsive devices from the link
- Distributes Data Link and Link Scheduling time on the link. The data link layer synchronizes the network-wide Data Link Time. Link scheduling time is a link specific time represented as an offset from Data Link Time. It is used to indicate when the LAS on each link begins and repeats its schedule. System Management uses it to synchronize function block execution with the data transfers scheduled by the LAS.
- Polls devices for buffered data at scheduled transmission times.
- Distributes a priority-driven token to devices between scheduled transmissions.

Any device on the link may become the LAS as long as it is capable. The devices that are capable of becoming the LAS are called Link Master devices. All other devices are referred to as Basic devices.

The FIM4/FIM8 is Link Master capable and supports both primary and backup link schedules. It is designated as the primary Link Master. It is always assigned the lowest network address.

Upon startup or failure of the existing LAS, the Link Master capable devices on the link bid to become the LAS. The Link Master that wins the bid begins operating as the LAS immediately upon completion of the bidding process. The Link Master capable device with the lowest address usually wins the bid. Link Masters that do not become the LAS act as basic devices when viewed by the LAS. They also act as LAS backups by monitoring the link for failure of the LAS, and by bidding to become the LAS when a LAS failure is detected.

Attention

- If the LAS is too large to fit in the active Link Master capable device, the user must reconfigure the device to become a **Basic** one through Control Builder, and restart the device to initiate the change.

Most Link Master capable devices can only support one sub schedule and **cannot** support blocks that are running two different macrocycles. Each macrocycle includes one sub schedule. Each sub schedule includes sequences that specify the start time of each element in the sequence. The elements are actual publications that initiate schedule operations. Devices have predefined limits on the number of sub schedules that can exist per LAS and the number of sequences that can exist in a sub schedule. If the number of sub schedules and/or sequences in the current schedule (backup LAS) exceed the Link Master capable device's predefined limits, a load of the device through Control Builder will generate load errors identifying sub schedule problems. In this case, the user must reconfigure the device to become a **Basic** one through Control Builder, and restart the device to initiate the change. Otherwise, if the FIM4/FIM8 fails, the potential for a 'no schedule' condition exists. Since the schedule is cleared from the Link Master capable device upon the detection of load errors, it cannot function as the backup LAS without a schedule.

Related topics

“Link Schedule” on page 301

“Function block execution schedule” on page 302

“About using mixed macrocycles on FF Links” on page 304

<https://maxautoland.com/>
+86 18030205725
manski@cambia.cn

18.1 Link Schedule

The Link Schedule is the overall schedule for the link. It includes both the link data transfer and the device function block execution schedules. A Link Schedule is provided for the FIM4/FIM8 interface port for each link. A backup Link Schedule is provided for all Link Master capable devices on the link.

The link data transfer schedule is derived from the portion of the link schedule that deals with publication of parameters. The Control Builder (CB) provides a default link schedule of publications and function block execution phasing based on the function block connections in the user configured control strategy. The basis for the link schedule is this link's content from all currently loaded Control Modules (CM). Execution phasing is based solely on function block existence in the CM. Order of execution is based on the order in CM (ORDERINCM) parameter for each block. Publications are based on inter-device function block connections and device to Experion system or Experion system to device function block connections. The following publication rules apply.

- Function block publications appear in the link data transfer schedule in the order specified by their ORDERINCM parameters. (Duplicate values of ORDERINCM may produce indeterminate ordering of those blocks involved.)
- If the user changes the sequence of execution order for function blocks in a schedule, the ORDERINCM parameters of the involved function blocks are appropriately adjusted.
- Publication of each output is scheduled immediately after execution of the function block that produces the value, considering inter-publication delays and potential conflicts.
- Blocks publish, if their output is connected to an input in another device or the FIM4/FIM8.
- No unneeded time delay is allowed in the default link data transfer schedule.
- The macrocycle is the least common multiple of the execution periods of all the CMs involved in the link data transfer schedule.

Note that users will be able to add extra time before and after the execution of a Fieldbus function block through the Pre-execution delay (PREXEGAP) and the Post execution delay (POSTEXEGAP) parameters that appear on the block configuration forms in Control Builder. This means users can adjust the schedule to achieve such actions as forcing multiple AI blocks to execute at the same time (even though they must publish serially).

<https://maxautoblog.com/2016/06/20/205125>
manski@cambria.com

18.2 Function block execution schedule

The function block execution schedule is derived from the portion of the link schedule that deals with starting the execution of each function block or FB_START indications. The link schedule provides only those entries that pertain to the blocks residing in a given Fieldbus device. While device function blocks may be synchronized to the link schedule, it is not a Fieldbus Foundation mandated feature. They may run asynchronously.

The block execution time can be broken into these three phases.

Preprocessing - Snap of parameter values

Execution - Function block outputs are determined

Post processing - Block output values, alarm and associated trend parameters are updated.

Since input parameter values used by a function block must not change during execution, a copy of the input parameter values is captured or snapped at the beginning of execution. Also, since block outputs to other blocks must be time coincident, the output values are only updated at the completion of the function block execution. The block algorithm execution phase is always executed in the following ordered sequence as shown in the following figure.

Determine the actual mode attribute of the mode parameter. This calculation is based on the target mode and the status attributes of input parameters.

Calculate the set point, if the Set Point parameter is defined for the function block. The calculation of working set point is based on the actual mode, set point input parameters such as cascade and remote cascade, and any backward path input status. Also, the value of the controlled parameter, process variable, may be used for set point tracking. The resulting set point is shown in the set point parameter.

Execute the control or calculation algorithm to determine the value and status of output parameters in the forward path. The conditions that determine the status attribute of output parameters. The value attributes of the block's input parameters and contained parameters, the actual mode and the working set point are used in this algorithm. Also, where defined by the block profile, some blocks may use the status of selected inputs. In general, the calculation of actual mode and the use of actual mode in the algorithm accounts for the status of critical inputs.

Calculate output parameters in the backward path. This phase applies only to output blocks and calculation blocks designed for use in a cascade path.



Tip

A Fieldbus device whose period of function block execution is an integer factor of the macrocycle of the link will have a function block execution schedule prepared that has the optimal shorter cycle. For example, if the control strategy includes a CM with a 2 second period for a temperature loop, a second CM with a 1 second period for a pressure loop, and a third CM with a 250 millisecond period for a flow loop, a 1 second macrocycle can be downloaded to the device that contains functions blocks used in the 1 second and 250 ms CMs.




Figure 36: Algorithm execution phase sequence

<https://maxautol.com/>
 manski@cambi.a.cn +86 18030205725

18.3 About using mixed macrocycles on FF Links

18.3.1 About macrocycles

The macrocycle period, which is the period of the overall schedule, is equal to the largest configured FF execution period from the CMs that contribute to the link. Blocks in the CMs with shorter FF execution periods will have repeated executions within the overall schedule.

18.3.2 About mixed macrocycles

In Experion, an FF link can have devices for which the function blocks are assigned to different CMs. In addition, CMs can have individually configured execution periods. This means that a link schedule may be built using blocks and data publications executing at different rates. This is known as mixed macrocycle.

Although not commonly used, the need for mixed macrocycles may arise in the following scenarios:

- A link must be configured with a large number of devices.
- A link must be configured with devices that support a large number of blocks.

In these scenarios, it is recommended to use a single, relatively slow macrocycle. However, in some cases it may be necessary to use slower monitoring blocks on the same link as faster control blocks.



Attention

Using mixed macrocycles increases the risk of mode shed. Honeywell recommends avoiding the use of mixed macrocycles. However, if the use of mixed-macrocycles in Experion is absolutely necessary or has already been commissioned, appropriate precautions need to be taken to avoid mode shed.

18.3.3 Scenarios during which mode shed occurs when using mixed macrocycles

When mixed macrocycles are used, the mode shed may occur in the following scenarios:

- The link schedule may pause and restart from the beginning (at the next scheduled macrocycle start time) during certain events. For example, the schedule is re-loaded (CM load) or redundancy switchover has occurred.
- The amount of schedule pause is dependent on when the event occurs, and may include almost the full schedule period.
- When the schedule is paused, publications cease although block executions continue.
- Blocks that subscribe to these publications count the number of times publication is not received.
- The number of missed publications exceeds the configured stale count limit. This is most likely to happen on the faster-executing blocks on a mixed-macrocycle link.

Note: The default setting for stale count is 3. However, this is configurable by the user, as required. If the ratio of fast-to-slow execution rates in a mixed macrocycle is higher than the configured stale count limit, then a mode shed is likely to occur.

For example, consider the following scenario.

The link schedule contains blocks running at both 500 ms and 2 second periods. This means that the ratio of execution rates is 4:1.

The stale count limit in all CMs is set to 3.

In such a scenario, if an event occurs that restarts the link schedule, then the faster-executing blocks (blocks with execution period of 500ms) may miss all of their inputs, depending on exactly when the link schedule was restarted. In addition, this may result in mode shed and disrupt control.

! Attention

- If the use of mixed-macrocycle is absolutely necessary or has already been commissioned, you must adhere to the following guidelines to avoid mode shed.

- For each link with a mixed-macrocycle schedule, calculate the ratio of fast-to-slow execution rates.
- Set the stale count limit for the faster CMs to be slightly higher than this ratio.

For example, if the ratio of execution rate is 4:1, then set the stale count limit to 5.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

19 Tags, Addresses, and Live List Reference

This section provides conceptual type information about Fieldbus tags, addresses, and live list functions. The following table lists the topics included in this section. If you are viewing this information online, just click the topic title to jump to the information location.

Topic
“Tag and address assignments” on page 308
“About Fieldbus address assignments in Control Builder” on page 309
“Live list and uncommissioned devices” on page 310

Related topics

[“Tag and address assignments” on page 308](#)

[“About Fieldbus address assignments in Control Builder” on page 309](#)

[“Live list and uncommissioned devices” on page 310](#)

<https://maxautoland.com/>
manski@cambia.cn +86 18030205725

19.1 Tag and address assignments

Before a Fieldbus device can actively join a network it must be assigned a name and data link address. Device names are system specific identifiers called physical device tags (PD_TAG).

The PD_TAGS may be assigned by the vendor or through the System Management Kernel (SMK), normally in an off-line configuration environment so devices without tags are kept off the operational network.

The SMK for devices without tags are set to the Uncommissioned state and connected to the bus at one of four default device addresses. The Data Link Layer specifies these default addresses as non-visitor node addresses. The following figure shows the general allocation of data link layer addresses to field devices.




Figure 37: Summary of address allocations for Fieldbus devices



Attention

- Temporary devices such as handheld interfaces are not assigned tags or addresses. They join the network through one of four data link visitor addresses reserved for them in the data link layer protocol.
- Note that the Experion system will show address assignments in Decimal notation rather than Hexadecimal in Control Builder configuration forms and Station displays. The address range in Decimal is 0 to 255 and 0 to FF in Hexadecimal.

19.2 About Fieldbus address assignments in Control Builder

The Fieldbus Interface Module will be given 16 as its assigned address. The preferred address range for Fieldbus devices is 20 to 40 decimal (14 to 28 hexadecimal). This provides the most optimized default network range where the first unused node address (FUN) is 41 decimal (29 hexadecimal) and the number of unused addresses (NUN) is 206. We recommend that the Fieldbus device designated as the backup Link Master be given 21 decimal (15 hexadecimal) as its assigned address.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

19.3 Live list and uncommissioned devices

FOUNDATION Fieldbus defines a live list as a 32-byte bitstring (256 bits) where each bit represents an address of the Fieldbus network. A set bit at a particular bit number means that a device is present at that address. The LAS of the network owns the live list and maintains it as part of its operation.

The FIM4/FIM8 constantly monitors the live list for each Fieldbus link connected to it. When the LAS for the link recognizes a new device at a default address, it adds it to its live list according to the data link layer procedures. The FIM4/FIM8 detects the change in the live list and makes a connection to the new uncommissioned device. It gathers the following information from the device to be passed to Control Builder.

Name	Description	Data Type	Access
PdTag	Physical Device Tag	32-byte string	Read/Write
Address	Device Address	Unsigned8	Read/Write
DevID	Globally unique Device Identifier	32-byte string	Read Only
Honeywell	Honeywell name string	32-byte string	Read Only
ModelName	Model Name string	32-byte string	Read Only
Rev	Application Revision	32-byte string	Read Only
ManufID	Manufacturer Identifier	Unsigned32	Read Only
DevType	Device Type code	Unsigned16	Read Only
DevRev	Device Revision	Unsigned8	Read Only
DdRev	DD Revision	Unsigned8	Read Only
Capability Level	Device Capability Level	Unsigned8	Read Only

Control Builder uses the device information to create an item in its Monitoring tree to represent the new uncommissioned device on the given link. Users can now view and configure pertinent information for the uncommissioned device through appropriate Link block and device block configuration forms in Control Builder.



Tip

The FIM4/FIM8 must be configured and loaded through Control Builder before you can view it and its links through the **Monitoring** tab of Control Builder.

20 Notification Scheme Reference

This section provides conceptual type information about how Fieldbus alarms relate to Experion system alarms. The following table lists the topics included in this section. If you are viewing this information online, just click the topic title to jump to the information location.

Topic
“Fieldbus versus Experion Alarm Priorities” on page 312
“Advanced Alarming” on page 312

Related topics

- [“Fieldbus versus Experion Alarm Priorities” on page 312](#)
- [“Fieldbus Alarm Conditions” on page 314](#)

<https://maxautoland.com/>
manski@cambia.cn +86 18030205725

20.1 Fieldbus versus Experion Alarm Priorities

The Fieldbus alarms will be closely integrated with the existing Experion notification system. The Experion server will handle FIM4/FIM8 alarms in the same way it handles Control Processor ones. But, the Fieldbus devices themselves own their alarm data and generate the alarms, clears, and events. Function blocks that support alarming also allow each different alarm condition to be disabled. It is always good to check that the disables are set appropriately.

Fieldbus devices use 0 to 15 as numeric priorities for alarm reporting. Priority 0 clears any alarm status, clearing reports and preventing new ones from being issued. Priority 1 clears any alarm reports and prevents new ones from being issued, but allows the alarm status to continue to be observed in the ALARM_SUM and alarm object status. Priorities 2 through 7 are considered *advisory* and priorities 8 through 15 are considered *critical* in Fieldbus. Experion alarms use Journal, Low, High and Urgent as priorities with a sub-priority of 0 to 255. The following table shows how Fieldbus priorities are mapped to Experion priorities and severities.

Fieldbus Alarm Priority	Experion Alarm Priority	Experion Alarm Severity
0	(Can never be seen by FIM4/FIM8 or above)	(Can never be seen by FIM4/FIM8 or above)
1	(Can never be seen by FIM4/FIM8 or above)	(Can never be seen by FIM4/FIM8 or above)
2 BLOCK_ERR bit 14 (power-up) BLOCK_ERR bit 15 (Out- of-Service)	Journal (Event System Only)	2
2 All other bitstring indications: (BLOCK_ERR bits 0-13, XD_ERROR bits 16-25)	System Level Diagnostic (High)	2
2 (User selected)	Journal	2
3	Low	3
4	Low	4
5	Low	5
6	Low	6
7	Low	7
8	High	8
9	High	9
10	High	10
11	High	11
12	Urgent	12
13	Urgent	13
14	Urgent	14
15	Urgent	15

20.1.1 Advanced Alarming

FF devices are configured with a feature of configuring diagnostic parameters to generate alarms. The alarms that are generated are based on the status of these parameters in a device. Individual bits in these strings are

selected and configured as a condition to generate the alarms. Therefore, the conditions that are used for generating manufacturer-specific alarms are contained in bitstring parameters of FF Transducer blocks and Resource blocks. FIM monitors all the parameters in the condition to generate corresponding alarms, which are activated.

Note: You can configure alarm conditions and save in the ERDB.

Considerations

Following are some of the considerations for configuring diagnostic parameters.

- Each condition is associated with at most 5 parameters of a device.
- You can select any combination of available bits.
- Different conditions can utilize the same or different parameters/bits.
- You can enable and disable the conditions at the template level and device level from both Project and Monitoring modes.

<https://maxautoland.com/>
manski@cambia.cn +86 18030205725

20.2 Fieldbus Alarm Conditions

Fieldbus devices provide both process and device related alarms. The process alarms are associated with process variable conditions and they are reported as process alarms into the Experion system. The device alarms are associated with actual device conditions or processes within the block as indicated by BLOCK_ERR and XD_ERROR bitstring alarms. These alarms are reported as device or system alarms into the Experion notification system. The following table summarizes the possible Fieldbus alarm enumerations and lists the alarm/event type identification to be used in the alarm summary and event summary displays in Station.



Attention

Only the first alarm in an overlapping series of alarms associated with BLOCK_ERR and XD_ERROR bitstring alarms is reported due to a flaw in the Fieldbus Foundation Specifications regarding the alert state machine. This has been reported to the Fieldbus Foundation through their Action Request system and the Foundation has agreed to permit future devices to issue alerts on changes to the status of any element of these bitstring alarms.

If no more than one of the bits is set at a time, the alarms are reported and cleared properly



Tip

Fieldbus alarm functions do not support rate of change (ROC) alarms. ROC alarms can only be generated in applications that use Control Builder Data Acquisition blocks for input signal conditioning.

Enumeration	Description	Alarm/Event Type
UNDEF	Undefended Alarm	No Action
LO	Low Limit Alarm	PVLO
HI	High Limit Alarm	PVHI
LO LO	Critical Low Limit Alarm	PVLOLO
HI HI	Critical High Limit Alarm	PVHIHI
DV LO	Deviation Low Alarm	DEVLO
DV HI	Deviation High Alarm	DEVHI
DISC	Standard Discrete Alarm	OFFNORM
DISC	Standard Discrete Alarm	CHNGOFST
DISC	DevCtl Fail Alarm	FBDCFAIL
DISC	DevCtl Accept Alarm	FBDCACC
DISC	DevCtl Ignore Alarm	FBDCIGN
BLOCK	BLOCK_ERR: 0 (Other (LSB))	FFOTHER (Unspecified Error)
BLOCK	BLOCK_ERR: 1 (Block Configuration Error)	FFBLKCFG (Block Config Error)
BLOCK	BLOCK_ERR: 2 (Link Configuration Error)	FFLNKCFG (Link Config Error)
BLOCK	BLOCK_ERR: 3 (Simulate Active)	FFSIMACT (Simulation Activ)
BLOCK	BLOCK_ERR: 4 (Local Override)	FFLO (Local Override)
BLOCK	BLOCK_ERR: 5 (Dev Fault State Set)	FFFLSAFE (Device Fault State)

Enumeration	Description	Alarm/Event Type
BLOCK	BLOCK_ERR: 6 (Dev Needs Maintenance Soon)	FFDEVNMS (Maintain Device Soon)
BLOCK	BLOCK_ERR: 7 (I/P Failure or PV BAD Status)	FFINFL (Device Input Failure)
BLOCK	BLOCK_ERR: 8 (O/P Failure)	FFOUTFL (Device Output Fail)
BLOCK	BLOCK_ERR: 9 (Memory Failure)	FFMEMFL (Memory Failure)
BLOCK	BLOCK_ERR: 10 (Lost Static Data)	FFLSTDTA (Static Data Lost)
BLOCK	BLOCK_ERR: 11 (Lost NV Data)	FFLNVDTA (Non-Vol Data Lost)
BLOCK	BLOCK_ERR: 12 (Readback Check Failed)	FFRBCKFL (Readback Check Fail)
BLOCK	BLOCK_ERR: 13 (Dev Needs Maintenance Soon)	FFDEVNMS (Maintain Device Now)
BLOCK	BLOCK_ERR: 14 (Power Up)	FFPWRUP (Powered-Up)
BLOCK	BLOCK_ERR: 15 (Out-Of-Service)	FFOOS (Out-Of-Service)
BLOCK	XD_ERROR: 16 (Unspecified Error)	TBUNSPEC (Unspecified TB Error)
BLOCK	XD_ERROR: 17 (General Error)	TBGENRAL (General Error)
BLOCK	XD_ERROR: 18 (Calibration Error)	TBCALERR (Calibration Error)
BLOCK	XD_ERROR: 19 (Configuration Error)	TBCFGERR (Configuration Error)
BLOCK	XD_ERROR: 20 (Electronics Failure)	TBELECFL (Electronics Failure)
BLOCK	XD_ERROR: 21 (Mechanical Failure)	TBMECHFL (Mechanical Failure)
BLOCK	XD_ERROR: 22 (I/O Failure)	TBIOFL (I/O Failure)
BLOCK	XD_ERROR: 23 (Data Integrity Error)	TBDTAERR (Data Integrity Error)
BLOCK	XD_ERROR: 24 (Software Error)	TBSWERR (Software Error)
BLOCK	XD_ERROR: 25 (Algorithm Error)	TBALGERR (Algorithm Error)
UPDATE	TB Static Data Update Event	TBSTCHNG

Enumeration	Description	Alarm/Event Type
UPDATE	FB Static Data Update Event	FBSTCHNG (Static Revision)
WRITE	Write Protect Change Alarm	RBWPCHNG (Write Lock)
UPDATE	Link Object Update Event	FBLOCHNG (Link Object Changed)
UPDATE	Trend Object Update Event	No Action

20.2.1 Loading alarm conditions

After configuring the alarm conditions, you must load the saved conditions to the FIM. Conditions are loaded only after loading the device. For more information on loading the conditions, see “Loading a Series C FIM4/ FIM8 and its links” on page 134

! Attention

- Before loading, turn off the device blocks as it can affect the execution of associated control strategies.
- When you perform device like replacement, advanced alarming conditions are also loaded from Project mode configuration when the device is loaded.
- When you change the device's template with an unlike template replacement, all advanced alarm configuration settings are loaded from the replacement template.
- When you commission the device using Commission Without Reconfiguration, the device automatically loads the settings from the selected device template. However, if there are multiple templates that match the device profile and revision information, you must select the template before commissioning.

20.2.2 Alarm server operation

User defined conditions are configured to generate the System Alarm.

System Alarm: System alarms appear in the System Status Display. The alarm attributes are set as follows:

Attribute	Value
Source	Device tag
Condition	DIAG
Priority	User specified (Low, High, Urgent)
Severity	Set to '00'
Description	The name of the condition configured
Criticality	User specified criticality (Failed, Maintenance, Check, OffSpec)

21 Fieldbus Technology Overview

This section provides an overview of **Foundation** Fieldbus technology concepts. The following table lists the topics included in this section. If you are viewing this information online, just click the topic title to jump to the information location.

Topic
“Open communications architecture” on page 318
“Communication layer description” on page 319
<i>Standard Function Blocks</i>
“Device Descriptions and Block Parameters” on page 344

Related topics

- [“Open communications architecture” on page 318](#)
- [“Communication layer description” on page 319](#)
- [“Standard Function Blocks” on page 321](#)
- [“Device Descriptions and Block Parameters” on page 344](#)

https://maxautoland.com/
manski@cambid.com.cn +86 18030205725

21.1 Open communications architecture

Foundation Fieldbus is an enabling technology for dynamically integrating dedicated field devices with digitally based control systems. It defines how all 'smart' field devices are to communicate with other devices in the control network. The technology is based upon the International Standards Organization's Open System Interconnection (OSI) model for layered communications.

As shown in the following figure, OSI layer 1 is the Physical Layer, OSI layer 2 is the Data Link Layer, and OSI layer 7 is the application layer or the Fieldbus Message Specification. A Fieldbus Access Sublayer maps the Fieldbus Message Specification onto the Data Link Layer. Fieldbus does not use OSI layers 3 to 6, and layers 2 and 7 form the Communication Stack. Also, the OSI model does not define a User Application, but the Fieldbus Foundation does.




Figure 38: OSI versus Fieldbus communication model.

21.2 Communication layer description

The following table provides a summarized description of the communication layers that make up the **Foundation Fieldbus**. The Fieldbus Foundation maintains a complete library of detailed reference specifications including a Technical Overview and Wiring and Installation Guides.

Please refer to “Fieldbus network wiring and installation references” on page 21 for a list of available documents or visit the Fieldbus Foundation web site <http://www.Fieldbus.org/> for additional details and ordering data.

Layer	Functional Description	Associated Terms
Physical	<p>Defines the transmission medium for Fieldbus signals and the message conversion tasks to/from the Communication Stack.</p> <p>Based on the Manchester Biphase-L Encoding technique, so a Foundation Fieldbus (FF) device interprets a positive transition in the middle of a bit time as logical '0' and a negative transition as logical '1'.</p> <p>Complies with existing International Electrotechnical Commission (IEC 1158-2) and the Instrumentation, Systems, and Automation Society (ISA S50.02) physical layer standards. And, it can be used with existing 4 to 20mA wiring.</p>	<p>H1, 31.25 kbit/s signal rate</p> <p>H1 Link</p> <p>H1 Segment</p> <p>HSE, High Speed Ethernet</p>
Data Link (DLL)	<p>Defines how messages are transmitted on a multi-drop network. It uses a deterministic centralized bus scheduler called a Link Active Scheduler (LAS) to manage access to the Fieldbus. It controls scheduled and unscheduled communications on the Fieldbus in a publish/subscribe environment.</p> <p>Identifies device types as Basic Device, Link Master, or Bridge. A Link Master device type can become a Link Active Scheduler (LAS) for the network.</p>	<p>Compel Data (CD) message</p> <p>Pass Token (PT) message</p> <p>Time Distribution (TD) message</p> <p>Live List</p> <p>Link Active Scheduler (LAS)</p>
Fieldbus Access Sublayer (FAS)	<p>Defines the types of services used to pass information to the Fieldbus Message Specification layer. The types of services are defined as Virtual Communication Relationships (VCR).</p> <p>The VCR types are Client/Server, Report Distribution, and Publisher/Subscriber. The Client/Server type handles all operator messages. The Report Distribution type handles event notification and trend reports. The Publisher/Subscriber type handles the publishing of User Application function block data on the network.</p>	<p>Virtual Communication Relationship (VCR)</p>
Fieldbus Message Specification (FMS)	<p>Defines how Fieldbus devices exchange User Application messages across the Fieldbus using a set of standard message formats. It uses object descriptions that are stored in an object dictionary (OD) to facilitate data communication. The OD also includes descriptions for standard data types such as floating point, integer, Boolean, and bitstring.</p> <p>A Virtual Field Device (VFD) mirrors local device data described in the OD. A physical device may have more than one VFD.</p> <p>Provides these communication services to standardize the way the User Applications such as function blocks communicate over the Fieldbus - Context Management, Object Dictionary, Variable Access, Event, Upload/Download, and Program Invocation.</p> <p>Uses a formal syntax description language called Abstract Syntax Notation 1 (ASN-1) to format FMS messages and applies special behavioral rules for certain types of objects.</p>	<p>Object Dictionary (OD)</p> <p>Virtual Field Device (VFD)</p> <p>Network Management Information Base (NMIB)</p> <p>System Management Information Base (SMIB)</p>

<p>User Application or Function Block Application Process (FBAP)</p>	<p>Defines blocks to represent different types of application functions. The three types of blocks are the Resource block, the Function block, and the Transducer block. See the illustration that follows this table.</p> <p>The Resource block is used to describe characteristics of the Fieldbus device such as the device name, manufacturer, and serial number. Each Fieldbus device requires one Resource block.</p> <p>The Function block is used to define the specific characteristics of the process control function. The Fieldbus Foundation provides a set of pre-defined function blocks. A single Fieldbus device can include many Function blocks to achieve the desired control functionality. See the next section <i>Standard Function Blocks</i> for more information.</p> <p>The Transducer block is used to interface Function blocks with local input/output devices. They read sensors and command outputs, and contain information such as calibration date and sensor type. One Transducer block is usually included for each input or output Function block.</p> <p>These associated objects are also defined in the User Application: Link Objects, Trend Objects, Alert Objects, and View Objects. They provide linking between internal Function block inputs and outputs, trending of Function block parameters, reporting of alarms and events, viewing of predefined block parameter sets through one of four defined views.</p> <p>The four defined views are View 1 - Operation Dynamic, View 2 - Operation Static, View 3 - All Dynamic, and View 4 - Other Static.</p>	<p>Resource block</p> <p>Function block</p> <p>Transducer block</p> <p>Link Objects</p> <p>Trend Objects</p> <p>Alert Objects</p> <p>View Objects</p> <p>View 1 - Operation Dynamic</p> <p>View 2 - Operation Static</p> <p>View 3 - All Dynamic</p> <p>View 4 - Other Static</p>
----------------------------------------------------------------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------	-----------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------




Figure 39: User Application (or Function Block Application Process) based on blocks.

21.3 Standard Function Blocks



WARNING

- The Fieldbus Foundation specifications do not clearly state the expectations of Fieldbus devices for handling Not-a-Number (NaN) values. This means that some may behave as the user desires and others may not.
- If you compute a data type float + status value that uses data structure (DS-65), which includes all **Foundation** Fieldbus inputs, outputs and some contained parameters, a resulting NaN value passed outbound through the FIM4/FIM8 sets the status element to BAD and changes the value element from NaN to 0.0 (zero). If you compute a data type float value, which includes many contained values such as alarm trip points, set points or output limits, gains, and filter time values, a resulting NaN value that is to be passed outbound through the FIM4/FIM8 will not be written and usually results in retention of the previous value. If the device would not behave in the application as you desire, you must add appropriate function blocks or logic to test for and replace the NaN with an acceptable value.

21.3.1 Blocks for basic control functionality

The key to Fieldbus interoperability is the User Application or Function Block Application Process (FBAP) that defines standard function blocks that can reside in field devices and be interconnected as a distributed process control system. A function block is a named entity that has inputs, outputs, and parameters. It performs certain functions that operate on its inputs and produce outputs in accordance with its assigned parameters. The Fieldbus Foundation Function Blocks are similar in nature to the Function Blocks used to build control strategies in the Control Builder application in the Experion system.

The Fieldbus Foundation provides the standard Function Blocks listed below for basic control functionality. They also support additional blocks for more complex applications. Please refer to the applicable Fieldbus Foundation specification for more information about these additional blocks.

Function Block	Abbreviation	Class
Analog Input	AI	Input
Analog Output	AO	Output
Bias/Gain	BG	Control
Control Selector	CS	Control
Discrete Input	DI	Input
Discrete Output	DO	Output
Manual Loader	ML	Control
Proportional/Derivative	PD	Control
Proportional/Integral/Derivative	PID	Control
Ratio	RA	Control

Function blocks make it possible to build a control loop using Fieldbus devices that include the appropriate Function block types. For example, a pressure transmitter that contains an Analog Input and Proportional/Integral/Derivative blocks can be used with a valve containing an Analog Output block to form a control loop, as shown in the following figure.




Figure 40: Using Function Blocks in Fieldbus devices to form a control loop.

21.3.2 About modes of operation

Every Function block includes a mode parameter with configured permitted modes. This structured parameter is composed of the actual mode, the target mode, the permitted mode, and the normal mode. The normal mode is the desired operating mode. The actual mode reflects the mode used during block execution. The target mode may be set and monitored through the mode parameter. The permitted mode defines the allowable target mode settings. The following table provides a summary of the available modes of operation and their effect on operation.

Mode	Abbreviation	Operation Effect
Out of Service	OOS	The block is not being evaluated. The output is maintained at the last value, an assigned fault state value -last value or configured fault state value. Set Point is maintained at last value.
Initialization Manual	IMan	The block output is being set in response to the back-calculation input parameter status. When status is no path to the final output element, control blocks must initialize to provide for bumpless transfer, when the condition clears. The Set Point may be maintained or initialized to the Process Variable parameter value.
Local Override	LO	Applies to control and output blocks that support a track input parameter. Also, manufacturers may provide a local lockout switch on the device to enable the Local Override mode. The block output is being set to track the value of the track input parameter. The algorithm must initialize to avoid a bump, when the mode switches back to the target mode. The Set Point may be maintained or initialized to the Process Variable parameter value.
Manual	Man	The block is not being calculated, although it may be limited. The operator directly sets it through an interface device. The algorithm must initialize to avoid a bump, when the mode switches. The Set Point may be maintained, initialized to the Process Variable parameter value, or initialized to the Set Point value associated with the previous (retained) target mode. .

Mode	Abbreviation	Operation Effect
Automatic	Auto	The block's normal algorithm uses a local Set Point value to determine the primary output. An operator may set the value of the Set Point through an interface device.
Cascade	Cas	The block's normal algorithm uses a Set Point value fed through the Cascade input parameter from another block to determine the primary output value.
Remote-Cascade	RCas	The block's Set Point is being set by a Control Application running on an interface device through the remote-cascade in parameter. The block's normal algorithm uses this Set Point to determine the primary output value. The block maintains a remote-cascade out parameter to support initialization of the control application, when the block mode is not remote-cascade.
Remote-Out	ROut	The block's output is being set by a Control Application running on an interface device through the remote-output in parameter. The algorithm must initialize to avoid a bump, when the mode switches. The block maintains a remote-output out parameter to support initialization of the Control Application, when the block mode is not remote-output. The Set Point may be maintained or initialized to the Process Variable parameter value.

21.3.3 Analog Input block




Figure 41: Functional schematic for Analog Input function block.

Description	The AI function block takes the input data from a Transducer block and calculates an output to be fed to other Fieldbus function blocks. A functional schematic of the block is shown in the previous illustration for reference.
Function Notes	<ul style="list-style-type: none"> • Supports Out of Service (OOS), Manual (Man), and Automatic (Auto) modes. • The XD_SCALE units code must match the channel units code, or the block will remain in OOS mode after being configured. • The OUT_SCALE is normally the same as the transducer, unless the L_TYPE is set to Indirect or Ind Sqr Root, then the OUT_SCALE determines the conversion from FIELD_VAL to the output. • If the mode is Auto, the PV is the value the block puts in OUT. • If the mode is Man, an operator can write a value to OUT. • The SIMULATE parameter is for testing purposes only and always initializes in the disabled state.

Equation Options	<ul style="list-style-type: none"> • $FIELD_VAL = 100 \times (\text{channel value} - EU@0\%) / (EU@100\% - EU@0\%)$ [XD_SCALE] • Direct: PV = channel value • Indirect : $PV = (FIELD_VAL / 100) \times (EU@100\% - EU@0\%) + EU@0\%$ [OUT_SCALE] • Ind Sqr Root: $PV = \sqrt{(FIELD_VAL / 100) \times (EU@100\% - EU@0\%) + EU@0\%}$ [OUT_SCALE] 	
Parameters	ACK_OPTION ALARM_HYS ALARM_SUM ALERT_KEY BLOCK_ALM BLOCK_ERR BLOCK_ERR.DISABLED CHANNEL FIELD_VAL GRANT_DENY HI_ALM HI_HI_ALM HI_HI_LIM HI_HI_PRI HI_LIM HI_PRI IO_OPTS L_TYPE LO_ALM	LO_LIM LO_LO_ALM LO_LO_LIM LO_LO_PRI LO_PRI LOW_CUT MODE_BLK OUT OUT_SCALE PV PV_FTIME SIMULATE ST_REV STATUS_OPTS STRATEGY TAG_DESC UPDATE_EVT XD_SCALE
Reference	Refer to the “Standard Function Block Parameters Reference” on page 347 section in this book for definitions of each parameter.	

<https://maxwellind.com/>
 manski@cambodia.cn +86 18030205125

21.3.4 Analog Output block




Figure 42: Functional schematic for Analog Output function block.

Description	<p>The Analog Output function block converts the set point (SP) value to a number that can be used by the hardware associated with the CHANNEL selection. A functional schematic of the block is shown in the previous illustration for reference.</p>
Function Notes	<ul style="list-style-type: none"> • Can use either the Set point (SP) value after limiting or the Process Variable (PV) value for the BKCAL_OUT value. • Supports Out of Service (OOS), Local Override (LO), Manual (Man), Automatic (Auto), Cascade (Cas), and Remote Cascade (RCas) modes. • The conversion of Set point (SP) to percent of span is based on the PV_SCALE range. • The conversion of the percent of span to a compatible value for the hardware is based on the XD_SCALE range. • Use the Increase to Close Option in IO_OPTS to invert the span. • Use the Cascade mode to transfer the output of another block to the Set point of the AO block. • If the hardware, such as a valve positioner, supports a readback value, run this value backwards through the XD scaling to act as the PV for this block. If this is not supported, READBACK is generated from OUT. • In the Man mode, an operator can write a value to OUT. A manufacturer must put operational limits in the Transducer, where an operator cannot access them, to permit the Man mode. If Man mode is not permitted, it must be supported as a transition mode for exiting the OOS mode • The SIMULATE parameter is for testing purposes only and always initializes in the disabled state.
Equation Options	<ul style="list-style-type: none"> • $Temp = (SP - EU@0\%) / (EU@100\% - EU@0\%) [PV_SCALE]$ • $OUT = Temp \times (EU@100\% - EU@0\%) + EU@0\% [XD_SCALE]$ • $Temp = (READBACK - EU@0\%) / (EU@100\% - EU@0\%) [XD_SCALE]$ • $PV = Temp \times (EU@100\% - EU@0\%) + EU@0\% [PV_SCALE]$

Parameters	ALERT_KEY BKCAL_OUT BLOCK_ALM BLOCK_ERR BLOCK_ERR.DISABLED CAS_IN CHANNEL FSTATE_TIME FSTATE_VAL GRANT_DENY IO_OPTS MODE_BLK OUT PV PV_SCALE RCAS_IN	RCAS_OUT READBACK SHED_OPT SIMULATE SP SP_HI_LIM SP_LO_LIM SP_RATE_DN SP_RATE_UP ST_REV STATUS_OPTS STRATEGY TAG_DESC UPDATE_EVT XD_SCALE
Reference	Refer to the “Standard Function Block Parameters Reference” on page 347 section in this book for definitions of each parameter.	

21.3.5 Bias/Gain block




Figure 43: Functional schematic for Bias/Gain function block.

Description	The Bias/Gain function block can be used for biased external feedforward control or to set several unit controllers, such as boiler masters, from one controller output, such as a plant master. A functional schematic of the block is shown in the previous illustration for reference.
Function Notes	<ul style="list-style-type: none"> • Supports Out of Service (OOS), Initialization Manual (IMan) Local Override (LO), Manual (Man), Automatic (Auto), Cascade (Cas), and Remote Cascade (RCas) modes. • The output supports the track algorithm. • The Balance Ramp option is supported. • The CONTROL_OPTS selection Act on IR determines whether initialization requests are to be passed on or acted on locally by changing the BIAS value. • If the Act on IR option is false, a status of Not Invited (NI) or Initialization Request (IR) at BKCAL_IN will be passed to BKCAL_OUT. The BKCAL_OUT value will be calculated from the value of BKCAL_IN adjusted for SP and GAIN, as determined by the control or process status of IN_1. When the upstream block sends an Initialization Acknowledge (IA) status, this block will send IA status, since its output will now be nearly equal to the value of BKCAL_IN. • If the Act on IR option is true, a status of NI or IR at BKCAL_IN results in an adjustment to SP to balance OUT to the value of BKCAL_IN. The IA status can be sent as soon as IR is detected. BKCAL_OUT will not request initialization. • The TRK_VAL input brings in an external value or uses a constant. The TRK_SCALE values convert the TRK_VAL to a percent of output span value. If the CONTROL_OPTS Track Enable selection is true and TRK_IN_D is true, the converted TRK_VAL replaces the output (OUT), when the block is in Automatic, Cascade, or Remote Cascade mode. The CONTROL_OPTS Track in Manual selection must be true for this to occur in Manual mode. If the actual mode is OOS or IMan, the track request is ignored. • If the TRK_VAL replaces the OUT, its status becomes Locked Out with Limits set to Constant. The actual mode goes to LO. The status of RCAS_OUT goes to Not Invited (NI), if not already there. • If the status of TRK_IN_D is Bad, its last usable value will be maintained and acted upon. If the device restarts, losing the last usable value, it will be set to false. • If the status of TRK_VAL is Bad, the last usable value will be used. If there is no last usable value, the present value of the OUT will be used.
Equation Options	<ul style="list-style-type: none"> • In Automatic mode: $OUT = (IN_1 + SP) \times GAIN$ • If IN_1 has Non-Cascade status: $BKCAL_OUT = (BKCAL_IN / GAIN) - IN_1$ • If IN_1 has Cascade status: $BKCAL_OUT = (BKCAL_IN / GAIN) - SP$

<https://maxaut.com/forums/20525>
 manski@cambria.com

Parameters	ALERT_KEY BAL_TIME BKCAL_IN BKCAL_OUT BLOCK_ALM BLOCK_ERR BLOCK_ERR.DISABLED CAS_IN CONTROL_OPTS GAIN GRANT_DENY IN_1 MODE_BLK OUT OUT_HI_LIM OUT_LO_LIM OUT_SCALE	RCAS_IN RCAS_OUT SHED_OPT SP SP_HI_LIM SP_LO_LIM SP_RATE_DN SP_RATE_UP ST_REV STATUS_OPTS STRATEGY TAG_DESC TRK_IN_D TRK_SCALE TRK_VAL UPDATE_EVT
Reference	Refer to the “Standard Function Block Parameters Reference” on page 347 section in this book for definitions of each parameter.	

21.3.6 Control Selector block




Figure 44: Functional schematic for Control Selector function block.

Description	The Control Selector function block accepts input from up to three control signals and selects one for output based on the SEL_TYPE setting of High, Middle, or Low. A functional schematic of the block is shown in the previous illustration for reference.
-------------	---------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Function Notes	<ul style="list-style-type: none"> • All inputs must have the same scaling as OUT, since any one can be selected for OUT. • Supports Out of Service (OOS), Initialization Manual (IMan) Local Override (LO), Manual (Man), and Automatic (Auto) modes. • If an input has a sub-status of Do Not Select, it will not be selected. • Three separate back calculation outputs (BKCAL_SEL_1, 2, 3) are available - one for each input (SEL_1, 2, 3). • The status will identify those inputs that are not selected. Control signals that are not selected are limited in one direction only as determined by the SEL_TYPE selection. • The value of each BKCAL_SEL_1, 2, 3 output is the same as OUT. The limits of back calculation outputs corresponding to not-selected inputs will be high for a low selection, low for a high selection, or one of each for a middle selection. • If the status of an input is Bad, it is not eligible for selection. If the status of an input is Uncertain, it is treated as Bad unless the STATUS_OPTS selection is Use Uncertain as Good. • When all inputs are Bad, the actual mode goes to Manual. This condition will set Initiate Fault State (IFS) in the output status, if the STATUS_OPTS setting is IFS if BAD IN. • If SEL_TYPE selection is Middle and only two inputs are good, the higher input will be selected. • If the status of BKCAL_IN is Not Invited (NI) or Initialization Request (IR), it is passed back on all three back calculation outputs. This causes all initializable inputs to initialize to the BKCAL_IN value. Otherwise, if the status of BKCAL_IN is not normal, it is passed back on the BKCAL_SEL_N, where N is the number of the selected input. The back calculation outputs for not-selected inputs just have the Not Selected status with the appropriate high or low limit set. • When the mode is Manual, no input is selected. All three back calculation outputs will have a Not Invited status and Constant limits, with a value equal to OUT. 	
Parameters	ALERT_KEY BKCAL_IN BKCAL_SEL_1 BKCAL_SEL_2 BKCAL_SEL_3 BLOCK_ALM BLOCK_ERR BLOCK_ERR.DISABLED GRANT_DENY MODE_BLK OUT OUT_HI_LIM	OUT_LO_LIM OUT_SCALE SEL_1 SEL_2 SEL_3 SEL_TYPE ST_REV STATUS_OPTS STRATEGY TAG_DESC UPDATE_EVT
Reference	Refer to the “Standard Function Block Parameters Reference” on page 347 section in this book for definitions of each parameter.	

21.3.7 Discrete Input block




Figure 45: Functional schematic for Discrete Input function block.

Description	<p>The Discrete Input function block takes the discrete input data from a selected Transducer block channel, and provides it as an output for other Fieldbus function blocks. A functional schematic of the block is shown in the previous illustration for reference.</p>
Function Notes	<ul style="list-style-type: none"> • Supports Out of Service (OOS), Manual (Man), and Automatic (Auto) modes. • The FIELD_VAL_D represents the true ON/OFF state of the value from the Transducer, using XD_STATE. • Use the IO_OPTS Invert selection to do a Boolean NOT function between the field value and the output. • Use the PV_FTIME to set the time that the input must be in one state before it gets passed to the PV_D. <p>The PV_D is always the value that the block places in OUT_D, when the mode is Automatic.</p> <ul style="list-style-type: none"> • In Manual mode, if allowed, an operator can write a value to OUT_D. • The SIMULATE_D parameter is for testing purposes only and always initializes in the disabled state.

Parameters	ACK_OPTION ALARM_SUM ALERT_KEY BLOCK_ALM BLOCK_ERR BLOCK_ERR.DISABLED CHANNEL DISC_ALM DISC_LIM DISC_PRI FIELD_VAL_D GRANT_DENY IO_OPTS	MODE_BLK OUT_D OUT_STATE PV_D PV_FTIME SIMULATE_D ST_REV STATUS_OPTS STRATEGY TAG_DESC UPDATE_EVT XD_STATE
Reference	Refer to the “Standard Function Block Parameters Reference” on page 347 section in this book for definitions of each parameter.	

21.3.8 Discrete Output block




Figure 46: Functional schematic for Discrete Output function block.

Description	The Discrete Output function block converts the value in SP_D to something useful for the hardware linked to the CHANNEL selection. A functional schematic of the block is shown in the previous illustration for reference.
-------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Function Notes	<ul style="list-style-type: none"> • Supports Out of Service (OOS), Local Override (LO), Manual (Man), Automatic (Auto), Cascade (Cas), and Remote Cascade (RCas) modes. • The Set point (SP_D) supports the full cascade sub-function. • Use the Cascade mode to transfer the output of another block to the Set point (SP_D) of the DO block. • Use the IO_OPTS Invert selection to do a Boolean NOT function between the field value and the output. • Use the IO_OPTS Invert selection to do a Boolean NOT function between the SP_D and the output. • If the hardware supports a readback value, it is used for READBACK_D, and, after accounting for the IO_OPTS Invert selection, acts as the PV_D for this block. If this is not supported, READBACK is generated from OUT_D. • In the Man mode, an operator can force the output, in a programmable logic controller sense. If Man mode is not permitted, it must be supported as a transition mode for exiting the OOS mode • The SIMULATE_D parameter is for testing purposes only and always initializes in the disabled state. 	
Parameters	<p>ALERT_KEY BKCAL_OUT_D BLOCK_ALM BLOCK_ERR BLOCK_ERR.DISABLED CAS_IN_D CHANNEL FSTATE_TIME FSTATE_VAL_D GRANT_DENY IO_OPTS MODE_BLK OUT_D PV_D</p>	<p>PV_STATE RCAS_IN_D RCAS_OUT_D READBACK_D SHED_OPT SIMULATE_D SP_D ST_REV STATUS_OPTS STRATEGY TAG_DESC UPDATE_EVT XD_STATE</p>
Reference	<p>Refer to the “Standard Function Block Parameters Reference” on page 347 section in this book for definitions of each parameter.</p>	

<https://maxoutput.com/>
manski@cambridge.com
 +86 180307203725

21.3.9 Manual Loader block




Figure 47: Functional schematic for Manual Loader function block.

Description	<p>The Manual Loader function block output is not set by the block's algorithm. An operator can set its output in the Manual mode or a program in the Remote-Out mode. A functional schematic of the block is shown in the previous illustration for reference.</p>
Function Notes	<ul style="list-style-type: none"> • Supports Out of Service (OOS), Initialization Manual (IMan), Local Override (LO), Manual (Man), and Remote-Out (ROut) modes. • Accepts output from an AI block as its input (IN) to get a PV filtered by PV_FTME. • The block's algorithm uses value and status for alarming only. • If selected, the STATUS_OPTS of IFS if BAD IN will work. • The BKCAL_IN value and status can force balancing of the output. • The TRK_VAL input brings in an external value or uses a constant. The TRK_SCALE values convert the TRK_VAL to a percent of output span value. If the CONTROL_OPTS Track Enable selection is true and TRK_IN_D is true, the converted TRK_VAL replaces the output (OUT), when the block is in Remote-Out (ROut) mode. The CONTROL_OPTS Track in Manual selection must be true for this to occur in Manual mode. If the actual mode is OOS or IMan, the track request is ignored. • If the TRK_VAL replaces the OUT, its status becomes Locked Out with Limits set to Constant. The actual mode goes to LO. The status of ROUT_OUT goes to Not Invited (NI), if not already there. • If the status of TRK_IN_D is Bad, its last usable value will be maintained and acted upon. If the device restarts, losing the last usable value, it will be set to false. • If the status of TRK_VAL is Bad, the last usable value will be used. If there is no last usable value, the present value of the OUT will be used.

Parameters	ACK_OPTION ALARM_HYS ALARM_SUM ALERT_KEY BKCAL_IN BLOCK_ALM BLOCK_ERR BLOCK_ERR.DISABLED CONTROL_OPTS GRANT_DENY HI_ALM HI_HI_ALM HI_HI_LIM HI_HI_PRI HI_LIM HI_PRI IN LO_ALM LO_LIM LO_LO_ALM LO_LO_LIM LO_PRI	LO-LO_PRI MODE_BLK OUT OUT_HI_LIM OUT_LO_LIM OUT_SCALE PV PV_FTIME PV_SCALE ROUT_IN ROUT_OUT SHED_OPT ST_REV STATUS_OPTS STRATEGY TAG_DESC TRK_IN_D TRK_SCALE TRK_VAL UPDATE_EVT
Reference	Refer to the "Standard Function Block Parameters Reference" on page 347 section in this book for definitions of each parameter.	

<https://maxautomation.com/>
 manski@cambia.com +86 18030705725

21.3.10 Proportional/Derivative block




Figure 48: Functional schematic for Proportional/Derivative function block.

<p>Description</p>	<p>The Proportional/Derivative function block provides classic two-mode control function for processes that handle their own integration. When the Process Variable deviates from the Set point, the PD function acts upon the error to move the output in a direction to correct the deviation. PD blocks support cascade applications to compensate for the difference in process time constants of a primary and secondary process measurement. A functional schematic of the block is shown in the previous illustration for reference</p>
--------------------	------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Function Notes	<ul style="list-style-type: none"> • Supports Out of Service (OOS), Initialization Manual (IMan), Local Override (LO), Manual (Man), Automatic (Auto), Cascade (Cas), Remote Cascade (RCas) and Remote-Out (ROut) modes. • The input (IN) passes through a filter with a time constant (PV_FTIME). The filtered value becomes the Process Variable (PV) to be used with the Set point (SP) in the block's algorithm. • The full cascade SP sub-function is used, with rate and absolute limits. Additional control options are available to have the SP value track the PV value, when the block's actual mode is IMan, LO, Man, or ROut. Limits do not cause SP-PV tracking. • A BYPASS switch function is available for operators to use, when secondary cascade controllers have a bad PV and the Bypass Enable (LSB) CONTROL_OPTS is ON. The Bypass Enable option is required, since some control schemes may become unstable when BYPASS is ON. An operator can only set the BYPASS switch, when the block is in the Man or OOS mode. While BYPASS is ON, the SP value, in percent of range, is passed directly to the target output, and the value of OUT is used for BKCAL_OUT. When block mode switches to Cascade, the upstream block is requested to initialize to the value of OUT. Upon transition to bypass OFF, the upstream block is requested to initialize to the PV value, regardless of the Use PV for BKCAL_OUT CONTROL_OPTS status. • The tuning constant used for the Proportional term is GAIN and RATE is used for the Derivative term. Some controllers use the inverse values of Proportional Band and repeats per minutes for their tuning constants. Users can choose which tuning constants they want to display. • Use the Balance Ramp CONTROL_OPTS to maintain the BIAS value, when the block is in Manual (Man) mode. An internal value follows the actual value required to maintain balance. When block mode changes to Automatic (Auto), the internal value ramps to zero contribution in BAL_TIME seconds. If Balance Ramp option is OFF or not used, the BIAS value immediately changes to follow the changes to the input or output, when the block is in Man mode. • Use the Act on IR CONTROL_OPTS to select whether to ignore initialization requests or act on them by changing the BIAS. If this option is ON, a status of Not Invited (NI) or Initialization Request (IR) at BKCAL_IN causes the BIAS term to be adjusted to balance OUT to the value of BKCAL_IN. • Use the Direct Acting CONTROL_OPTS to define how a change in PV relative to the SP affects the output. When Direct Acting is ON, the output increases when the PV exceeds the SP. When Direct Acting is OFF, the output decreases when the PV exceeds the SP. Be sure this option is set correctly and never changed while in the Automatic mode, since it makes the difference between positive and negative feedback. This option setting also affects the calculation of the limit states for BKCAL_OUT. • This block includes a Feed Forward algorithm. It accepts a value that is proportional to some disturbance in the control loop as its FF_VAL input. The FF_SCALE values convert the FF_VAL to a percent of output span value. The converted value is multiplied by the FF_GAIN and added to the target output of the block's algorithm. If the status of FF_VAL is Bad, the last usable value will be used to prevent a bump in the output. When the status returns to Good, the block adjusts its BIAS term to maintain the previous output. • The TRK_VAL input brings in an external value or uses a constant. The TRK_SCALE values convert the TRK_VAL to a percent of output span value. If the CONTROL_OPTS Track Enable selection is true and TRK_IN_D is true, the converted TRK_VAL replaces the output (OUT), when the block is in Automatic (Auto), Cascade (Cas), Remote Cascade (RCas), or Remote-Out (ROut) mode. The CONTROL_OPTS Track in Manual selection must be true for this to occur in Manual mode. If the actual mode is OOS or IMan, the track request is ignored. • If the TRK_VAL replaces the OUT, its status becomes Locked Out with Limits set to Constant. The actual mode goes to LO. The status of BKCAL_OUT, RCAS_OUT and ROUT_OUT goes to Not Invited (NI), if not already there.
----------------	-------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

	<ul style="list-style-type: none"> • If the status of TRK_IN_D is Bad, its last usable value will be maintained and acted upon. If the device restarts, losing the last usable value, it will be set to false. • If the status of TRK_VAL is Bad, the last usable value will be used. If there is no last usable value, the present value of the OUT will be used. • Use the Obey SP limits if Cas or RCas CONTROL_OPTS to use SP value after limiting in Cas or RCas mode. • Use the Use PV for BKCAL_OUT CONTROL_OPTS to the PV value for the BKCAL_OUT value. 	
Parameters	ACK_OPTION ALARM_HYS ALARM_SUM ALERT_KEY BAL_TIME BIAS BKCAL_HYS BKCAL_IN BKCAL_OUT BLOCK_ALM BLOCK_ERR BLOCK_ERR.DISABLED BYPASS CAS_IN CONTROL_OPTS DV_HI_ALM DV_HI_LIM DV_HI_PRI DV_LO_ALM DV_LO_LIM DV_LO_PRI FF_GAIN FF_SCALE FF_VAL GAIN GRANT_DENY HI_ALM HI_HI_ALM HI_HI_LIM HI_HI_PRI HI_LIM HI_PRI IN LO_ALM	LO_LIM LO_LO_ALM LO_LO_LIM LO_LO_PRI LO_PRI MODE_BLK OUT OUT_HI_LIM OUT_LO_LIM OUT_SCALE PV PV_FTIME PV_SCALE RATE RCAS_IN RCAS_OUT ROUT_IN ROUT_OUT SHED_OPT SP SP_HI_LIM SP_LO_LIM SP_RATE_DN SP_RATE_UP ST_REV STATUS_OPTS STRATEGY TAG_DESC TRK_IN_D TRK_SCALE TRK_VAL UPDATE_EVT

<https://maxoutput.com/>
manski@cambria.cn +86 18030293125

Reference	Refer to the “Standard Function Block Parameters Reference” on page 347 section in this book for definitions of each parameter.
-----------	---------------------------------------------------------------------------------------------------------------------------------

21.3.11 Proportional/Integral/Derivative block




Figure 49: Functional schematic for Proportional/Integral/Derivative function block.

Description	The Proportional/Integral/Derivative function block provides classic three-mode control function for closed-loop control applications. When the Process Variable deviates from the Set point, the PID function acts upon the error to move the output in a direction to correct the deviation. PID blocks support cascade applications to compensate for the difference in process time constants of a primary and secondary process measurement. A functional schematic of the block is shown in the previous illustration for reference.
-------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Function Notes	<ul style="list-style-type: none"> • Supports Out of Service (OOS), Initialization Manual (IMan), Local Override (LO), Manual (Man), Automatic (Auto), Cascade (Cas), Remote Cascade (RCas) and Remote-Out (ROut) modes. • The input (IN) passes through a filter with a time constant (PV_FTIME). The filtered value becomes the Process Variable (PV) to be used with the Set point (SP) in the block's algorithm. A PID algorithm will not integrate, if the limit status of the input (IN) is constant. • The full cascade SP sub-function is used, with rate and absolute limits. Additional control options are available to have the SP value track the PV value, when the block's actual mode is IMan, LO, Man, or ROut. Limits do not cause SP-PV tracking. • A BYPASS switch function is available for operators to use, when secondary cascade controllers have a bad PV and the Bypass Enable (LSB) CONTROL_OPTS is ON. The Bypass Enable option is required, since some control schemes may become unstable when BYPASS is ON. An operator can only set the BYPASS switch, when the block is in the Man or OOS mode. While BYPASS is ON, the SP value, in percent of range, is passed directly to the target output, and the value of OUT is used for BKCAL_OUT. When block mode switches to Cascade, the upstream block is requested to initialize to the value of OUT. Upon transition to bypass OFF, the upstream block is requested to initialize to the PV value, regardless of the Use PV for BKCAL_OUT CONTROL_OPTS status. • The tuning constant used for the Proportional term is GAIN, RESET is used for the Integral term, and RATE is used for the Derivative term. Both RESET and RATE are time constants expressed in seconds. Some controllers use the inverse values of Proportional Band and repeats per minutes for their tuning constants. Users can choose which tuning constants they want to display. • Use the Direct Acting CONTROL_OPTS to define how a change in PV relative to the SP affects the output. When Direct Acting is ON, the output increases when the PV exceeds the SP. When Direct Acting is OFF, the output decreases when the PV exceeds the SP. Be sure this option is set correctly and never changed while in the Automatic mode, since it makes the difference between positive and negative feedback. This option setting also affects the calculation of the limit states for BKCAL_OUT. • This block includes a Feed Forward algorithm. It accepts a value that is proportional to some disturbance in the control loop as its FF_VAL input. The FF_SCALE values convert the FF_VAL to a percent of output span value. The converted value is multiplied by the FF_GAIN and added to the target output of the block's algorithm. If the status of FF_VAL is Bad, the last usable value will be used to prevent a bump in the output. When the status returns to Good, the block adjusts its Integral (RESET) term to maintain the previous output. • The TRK_VAL input brings in an external value or uses a constant. The TRK_SCALE values convert the TRK_VAL to a percent of output span value. If the CONTROL_OPTS Track Enable selection is true and TRK_IN_D is true, the converted TRK_VAL replaces the output (OUT), when the block is in Automatic (Auto), Cascade (Cas), Remote Cascade (RCas), or Remote-Out (ROut) mode. The CONTROL_OPTS Track in Manual selection must be true for this to occur in Manual mode. If the actual mode is OOS or IMan, the track request is ignored. • If the TRK_VAL replaces the OUT, its status becomes Locked Out with Limits set to Constant. The actual mode goes to LO. The status of BKCAL_OUT, RCAS_OUT and ROUT_OUT goes to Not Invited (NI), if not already there. • If the status of TRK_IN_D is Bad, its last usable value will be maintained and acted upon. If the device restarts, losing the last usable value, it will be set to false. • If the status of TRK_VAL is Bad, the last usable value will be used. If there is no last usable value, the present value of the OUT will be used. • Use the Obey SP limits if Cas or RCas CONTROL_OPTS to use SP value after limiting in Cas or RCas mode. • Use the Use PV for BKCAL_OUT CONTROL_OPTS to the PV value for the BKCAL_OUT value.
----------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

Parameters	ACK_OPTION ALARM_HYS ALARM_SUM ALERT_KEY BAL_TIME BKCAL_HYS BKCAL_IN BKCAL_OUT BLOCK_ALM BLOCK_ERR BLOCK_ERR.DISABLED BYPASS CAS_IN CONTROL_OPTS DV_HI_ALM DV_HI_LIM DV_HI_PRI DV_LO_ALM DV_LO_LIM DV_LO_PRI FF_GAIN FF_SCALE FF_VAL GAIN GRANT_DENY HI_ALM HI_HI_ALM HI_HI_LIM HI_HI_PRI HI_LIM HI_PRI IN LO_ALM LO_LIM	LO_LO_ALM LO_LO_LIM LO_LO_PRI LO_PRI MODE_BLK OUT OUT_HI_LIM OUT_LO_LIM OUT_SCALE PV PV_FTIME PV_SCALE RATE RCAS_IN RCAS_OUT RESET ROUT_IN ROUT_OUT SHED_OPT SP SP_HI_LIM SP_LO_LIM SP_RATE_DN SP_RATE_UP ST_REV STATUS_OPTS STRATEGY TAG_DESC TRK_IN_D TRK_SCALE TRK_VAL UPDATE_EVT
Reference	Refer to the “Standard Function Block Parameters Reference” on page 347 section in this book for definitions of each parameter.	

21.3.12 Ratio block




Figure 50: Functional schematic for Ratio function block.

Description	<p>The Ratio function block set point is the ratio of its output to its input. A ratio set point of 0.5 produces an output that is one half of its input. The input (IN_1) is either a wild flow or the output of a blend-pacing controller. The output can be used as the set point for a secondary flow controller. An input (IN) from the secondary measurement is used to calculate the actual ratio, which is displayed as the PV. A functional schematic of the block is shown in the previous illustration for reference.</p>
-------------	--------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------------

<https://maxautol.com/cn>
 manski@cambi.cn +86 18030205172

<p>Function Notes</p>	<ul style="list-style-type: none"> • Supports Out of Service (OOS), Initialization Manual (IMan), Local Override (LO), Manual (Man), Automatic (Auto), Cascade (Cas), and Remote Cascade (RCas) modes. • The input 1 (IN_1) value to be ratioed passes through a filter with a time constant of RA_FTIME. The filtered value is multiplied by the Set point (SP) and GAIN to become the target output. The GAIN controls the number of zeros in the SP display. • The input (IN) value is the actual value of the ratioed variable and it passes through a filter with a time constant of PV_FTIME. The filtered IN value is divided by the filtered IN_1 value and the GAIN to become the PV. The units of IN are not PV, but OUT. The units of IN_1 are OUT units divided by PV units. • The full cascade SP sub-function is used, with rate and absolute limits. Additional control options are available to have the SP value track the PV value, when the block's actual mode is IMan, LO, Man, or ROut. Limits do not cause SP-PV tracking. • Use the Act on IR CONTROL_OPTS to select whether to pass initialization requests or act on them locally by changing the SP value. If this option is OFF or to pass, a status of Not Invited (NI) or Initialization Request (IR) at BKCAL_IN will be passed to BKCAL_OUT. The BKCAL_OUT value will be calculated from the value of BKCAL_IN divided by GAIN and IN_1. When the upstream block sends Initialization Acknowledge (IA) status, the block sends the IA status, since its output will now be nearly identical to the value BKCAL_IN. If this option is ON or to act, a status of NI or IR at BKCAL_IN adjusts the SP to balance the output to the value of BKCAL_IN. The IA status is sent as soon as IR is detected. The BKCAL_OUT will not request initialization. • Use the Balance Ramp CONTROL_OPTS to maintain the ratio SP value, when the block is in Manual (Man) mode. An internal value follows the actual value required to maintain balance. When block mode changes to Automatic (Auto), the internal value ramps to zero contribution in BAL_TIME seconds. If Balance Ramp option is OFF or not used, the ratio SP value immediately changes to follow the changes to the input or output, when the block is in Man mode. • The TRK_VAL input brings in an external value or uses a constant. The TRK_SCALE values convert the TRK_VAL to a percent of output span value. If the CONTROL_OPTS Track Enable selection is true and TRK_IN_D is true, the converted TRK_VAL replaces the output (OUT), when the block is in Automatic (Auto), Cascade (Cas), or Remote Cascade (RCas) mode. The CONTROL_OPTS Track in Manual selection must be true for this to occur in Manual mode. If the actual mode is OOS or IMan, the track request is ignored. If the TRK_VAL replaces the OUT, its status becomes Locked Out with Limits set to Constant. The actual mode goes to LO. The status of BKCAL_OUT, and RCAS_OUT goes to Not Invited (NI), if not already there. • If the status of TRK_IN_D is Bad, its last usable value will be maintained and acted upon. If the device restarts, losing the last usable value, it will be set to false. • If the status of TRK_VAL is Bad, the last usable value will be used. If there is no last usable value, the present value of the OUT will be used. • Use the Obey SP limits if Cas or RCas CONTROL_OPTS to use SP value after limiting in Cas or RCas mode. • Use the 'Use PV for BKCAL_OUT' CONTROL_OPTS to the PV value for the BKCAL_OUT value.
<p>Equation Options</p>	<ul style="list-style-type: none"> • If Auto mode, $OUT = IN_1 \text{ (filtered)} \times SP \times GAIN$ • $PV = IN \text{ (filtered)} / IN_1 \text{ (filtered)} / GAIN$ • If IN_1 has non-cascade status, $BKCAL_OUT = BKCAL_IN / GAIN / IN_1 \text{ (filtered)}$ • If IN_1 has cascade status, $BKCAL_OUT = BKCAL_IN / GAIN / SP$

Parameters	ACK_OPTION ALARM_HYS ALARM_SUM ALERT_KEY BAL_TIME BKCAL_IN BKCAL_OUT BLOCK_ALM BLOCK_ERR BLOCK_ERR.DISABLED CAS_IN CONTROL_OPTS DV_HI_ALM DV_HI_LIM DV_HI_PRI DV_LO_ALM DV_LO_LIM DV_LO_PRI GAIN GRANT_DENY HI_ALM HI_HI_ALM HI_HI_LIM HI_HI_PRI HI_LIM HI_PRI IN IN_1 LO_ALM LO_LIM	LO_LO_ALM LO_LO_LIM LO_LO_PRI LO_PRI MODE_BLK OUT OUT_HI_LIM OUT_LO_LIM OUT_SCALE PV PV_FTIME PV_SCALE RA_FTIME RCAS_IN RCAS_OUT SHED_OPT SP SP_HI_LIM SP_LO_LIM SP_RATE_DN SP_RATE_UP ST_REV STATUS_OPTS STRATEGY TAG_DESC TRK_IN_D TRK_SCALE TRK_VAL UPDATE_EVT
Reference	Refer to the “Standard Function Block Parameters Reference” on page 347 section in this book for definitions of each parameter.	

21.4 Device Descriptions and Block Parameters

21.4.1 About Device Descriptions

Device Descriptions (DD) are critical to the interoperability of Fieldbus devices. They define the data needed to establish communications between different Fieldbus devices from multiple vendors with control system hosts. The DD provides an extended description of each object in the User Application Virtual Field Device (VFD).

The Fieldbus Foundation provides Device Descriptions for all standard Function Blocks and Transducer Blocks on a CD-ROM and on its web site. Manufacturer's may provide an 'Incremental' DD that references the standard DDs and describes manufacturer specific features such as calibration and diagnostic procedures added to their devices.

21.4.2 Device Description Language

The Device Description Language (DDL) is a structured text language used to write a DDL source file. A DDL source file describes each device function, parameter, and special feature as well as how a field device can interact with a host application and other field devices. A completed DDL source file is converted into a binary formatted DD output file. The DD output file information can be provided in object form in the device itself, or on a removable storage media delivered with the device. A field device's Object Dictionary (OD) can be transferred from a device to a host using standard Fieldbus Message Specification services.

21.4.3 Device Description infrastructure

The Fieldbus Foundation defines a four-level infrastructure for Device Descriptions for the sake of consistency. See the following illustration for a graphical representation of the DD infrastructure.




Figure 51: Device Descriptions infrastructure.

Level 1 consists of Universal Parameters that define common attributes such as Tag, Revision, and Mode. All blocks must include Universal Parameters.

Level 2 consists of Function Block Parameters that define parameters for all standard Function Blocks including the standard Resource Block.

Level 3 consists of Transducer Block Parameters that define parameters for the standard Transducer block. In some cases, the Transducer Block specification may add parameters to the standard Resource Block.

The first three levels are the Device Descriptions provided by the Fieldbus Foundation.

Level 4 is the Manufacturer Specific Parameters that define the parameters a manufacturer has added to the standard Function Block and Transducer Block parameters. These added parameters will be included in the DD supplied by the manufacturer.

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

<https://maxautoland.com/>
manski@cambid.com.cn +86 18030205725

22 Standard Function Block Parameters Reference

This section provides definitions for some Fieldbus standard function block parameters for convenient reference.

Related topics

“ACK_OPTION” on page 351
“ALARM_HYS” on page 352
“ALARM_SUM” on page 353
“ALERT_KEY” on page 354
“BAL_TIME” on page 355
“BIAS” on page 356
“BKCAL_HYS” on page 357
“BKCAL_IN” on page 358
“BKCAL_OUT” on page 359
“BKCAL_OUT_D” on page 360
“BKCAL_SEL_1” on page 361
“BKCAL_SEL_2” on page 362
“BKCAL_SEL_3” on page 363
“BLOCK_ALM” on page 364
“BLOCK_ERR” on page 365
“BLOCK_ERR.DISABLED” on page 366
“BYPASS” on page 367
“CAS_IN” on page 368
“CAS_IN_D” on page 369
“CHANNEL” on page 370
“CLR_FSTATE” on page 371
“CONFIRM_TIME” on page 372
“CONTROL_OPTS” on page 373
“CYCLE_SEL” on page 374
“CYCLE_TYPE” on page 375
“DEV_REV” on page 376
“DEV_TYPE” on page 377
“DD_RESOURCE” on page 378
“DD_REV” on page 379
“DISC_ALM” on page 380
“DISC_LIM” on page 381
“DISC_PRI” on page 382
“DV_HI_ALM” on page 383
“DV_HI_LIM” on page 384
“DV_HI_PRI” on page 385

“DV_LO_ALM” on page 386
“DV_LO_LIM” on page 387
“DV_LO_PRI” on page 388
“FAULT_STATE” on page 389
“FEATURES” on page 390
“FEATURE_SEL” on page 391
“FF_GAIN” on page 392
“FF_SCALE” on page 393
“FF_VAL” on page 394
“FIELD_VAL” on page 395
“FIELD_VAL_D” on page 396
“FREE_SPACE” on page 397
“FREE_TIME” on page 398
“FSTATE_TIME” on page 399
“FSTATE_VAL” on page 400
“FSTATE_VAL_D” on page 401
“GAIN” on page 402
“GRANT_DENY” on page 403
“HARD_TYPES” on page 404
“HI_ALM” on page 405
“HI_HI_ALM” on page 406
“HI_HI_LIM” on page 407
“HI_HI_PRI” on page 408
“HI_LIM” on page 409
“HI_PRI” on page 410
“IO_OPTS” on page 411
“IN” on page 412
“IN_1” on page 413
“LIM_Notify” on page 414
“L_TYPE” on page 415
“LO_ALM” on page 416
“LO_LIM” on page 417
“LO_LO_ALM” on page 418
“LO_LO_LIM” on page 419
“LO_LO_PRI” on page 420
“LO_PRI” on page 421
“LOW_CLUT” on page 422
“MANUFAC_ID” on page 423
“MAX_NOTIFY” on page 424
“MEMORY_SIZE” on page 425
“MIN_CYCLE_T” on page 426
“MODE_BLK” on page 427
“NV_CYCLE_T” on page 428
“OFFNETALM_ENABLED” on page 429
“OUT” on page 430
“OUT_D” on page 431
“OUT_HI_LIM” on page 432
“OUT_LO_LIM” on page 433

“OUT_SCALE” on page 434
 “OUT_STATE” on page 435
 “PV” on page 436
 “PV_D” on page 437
 “PV_FTIME” on page 438
 “PV_SCALE” on page 439
 “PV_STATE” on page 440
 “RA_FTIME” on page 441
 “RATE” on page 442
 “RCAS_IN” on page 443
 “RCAS_IN_D” on page 444
 “RCAS_OUT” on page 445
 “RCAS_OUT_D” on page 446
 “READBACK” on page 447
 “READBACK_D” on page 448
 “RESET” on page 449
 “RESTART” on page 450
 “ROUT_IN” on page 451
 “ROUT_OUT” on page 452
 “RS_STATE” on page 453
 “SEL_1” on page 454
 “SEL_2” on page 455
 “SEL_3” on page 456
 “SEL_TYPE” on page 457
 “SET_FSTATE” on page 458
 “SHED_OPT” on page 459
 “SHED_RCAS” on page 460
 “SHED_ROUT” on page 461
 “SIMULATE” on page 462
 “SIMULATE_D” on page 463
 “SP” on page 464
 “SP_D” on page 465
 “SP_HI_LIM” on page 466
 “SP_LO_LIM” on page 467
 “SP_RATE_DN” on page 468
 “SP_RATE_UP” on page 469
 “ST_REV” on page 470
 “STATUS_OPTS” on page 471
 “STRATEGY” on page 472
 “TAG_DESC” on page 473
 “TEST_RW” on page 474
 “TRK_IN_D” on page 475
 “TRK_SCALE” on page 476
 “TRK_VAL” on page 477
 “UPDATE_EVT” on page 478
 “WRITE_ALM” on page 479
 “WRITE_LOCK” on page 480
 “WRITE_PRI” on page 481

“XD_SCALE” on page 482

“XD_STATE” on page 483

<https://maxautoland.com/>
manski@cambiala.cn +86 18030205725

22.1 ACK_OPTION

Classification	Simple Variable
Description	Selects whether alarms associated with the block will be automatically acknowledged.
FF Data Type	Bit String
Range	1: Unacknowledged
Usage	C/Contained
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	<p>Initial value is 0</p> <p>All function blocks that support alarming, such as AI, PID, and DI, provide an option to support operator acknowledgement status stored in the device or stored in the control system's alarm server. Experion systems support operator acknowledgement stored in the server to provide alarm acknowledgement operation consistent with the rest of Experion components, particularly with respect to multiple console independence of alarm acknowledgement. Therefore the Fieldbus parameter ACK_OPTION is always automatically set by Experion systems to ones for supported alarms, and the parameter is generally hidden to avoid confusion.</p>

<https://maxautoland.com/>
 manski@cambiala.cn +86 1803020512

22.2 ALARM_HYS

Classification	Simple Variable
Description	Defines the amount of change a PV value must attain within the alarm limits before the alarm condition clears.
FF Data Type	Float
Range	0 to 50 percent of PV span
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is 0.5 percent

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.3 ALARM_SUM

Classification	Record
Description	Detects the current alert status, unacknowledged states, and disable states of the alarms associated with the block
FF Data Type	DS-74
Range	
Usage	C/Alarm Summary
Length	8
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	<p>The data type summarizes 16 alerts using the following 4 elements.</p> <ul style="list-style-type: none"> • 1 Current • 2 Unacknowledged • 3 Unreported • 4 Disabled

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.4 ALERT_KEY

Classification	Simple Variable
Description	The identification number of the plant unit. This data may be used in the host for sorting alarms.
FF Data Type	Unsigned 8
Range	1 to 255
Usage	C/Alert Key
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is 0

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.5 BAL_TIME

Classification	Simple Variable
Description	Specifies the time in seconds for the internal working value of Bias or Ratio to return to the operator set value. In PID block, specifies the time constant to be used to move the integral term to obtain balance, when the output is limited and the mode is Auto, Cas, or RCas.
FF Data Type	Float
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is 0

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

22.6 BIAS

Classification	Simple Variable
Description	Specifies the Bias value in engineering units to be used in computing the function block output
FF Data Type	Float
Range	OUT_SCALE +/- 10 percent
Usage	C/Contained
Length	4
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	Normally, the operator has permission to write these values, but PROGRAM or LOCAL remove the permission and grant it to a supervisory computer or a local control panel.

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.7 BKCAL_HYS

Classification	Simple Variable
Description	Defines the amount of change an output value must attain from the limit before the limit status is turned OFF.
FF Data Type	Float
Range	0 to 50 percent of output span
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is 0.5 percent

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.8 BKCAL_IN

Classification	Record
Description	The value and status from a lower block's BKCAL_OUT that is used to prevent reset windup and to initialize the control loop.
FF Data Type	DS-65
Range	
Usage	I/Back-Calculation Input
Length	5
Valid Views	VIEW_3
Storage	Non-Volatile
Remarks	<p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.9 BKCAL_OUT

Classification	Record
Description	The value and status required by an upper block's BKCAL_IN so the upper block may prevent reset windup and provide bumpless transfer to closed loop control.
FF Data Type	DS-65
Range	
Usage	O/Back Calculation Output
Length	5
Valid Views	VIEW_3
Storage	Dynamic
Remarks	<p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.10 BKCAL_OUT_D

Classification	Record
Description	The output value and status provided to an upstream discrete block that is used to provide bumpless transfer for closed loop control.
FF Data Type	DS-66
Range	
Usage	O/Back Calculation Output
Length	2
Valid Views	VIEW_3
Storage	Dynamic
Remarks	<p>The data type consists of the value and status of discrete value parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.11 BKCAL_SEL_1

Classification	Record
Description	The selector output value and status associated with SEL_1 input that is provided to BKCAL_IN of the block connected to SEL_1 to prevent reset windup.
FF Data Type	DS-65
Range	
Usage	O/Back Calculation Output
Length	5
Valid Views	VIEW_3
Storage	Dynamic
Remarks	<p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.12 BKCAL_SEL_2

Classification	Record
Description	The selector output value and status associated with SEL_2 input that is provided to BKCAL_IN of the block connected to SEL_2 to prevent reset windup.
FF Data Type	DS-65
Range	
Usage	O/Back Calculation Output
Length	5
Valid Views	VIEW_3
Storage	Dynamic
Remarks	<p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.13 BKCAL_SEL_3

Classification	Record
Description	The selector output value and status associated with SEL_3 input that is provided to BKCAL_IN of the block connected to SEL_3 to prevent reset windup.
FF Data Type	DS-65
Range	
Usage	O/Back Calculation Output
Length	5
Valid Views	VIEW_3
Storage	Dynamic
Remarks	<p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.14 BLOCK_ALM

Classification	Record
Description	The block alarm is used for all configuration, hardware, connection failure, or system problems in the block. The cause of the alarm is entered in the sub-code field. The first alarm to become active will set the Active status in the Status attribute. As soon as the Unreported status is cleared by the alarm-reporting task, another block alarm may be reported without clearing the Active status, if the sub-code has changed.
FF Data Type	DS-72
Range	
Usage	C/Alarm
Length	13
Valid Views	
Storage	Dynamic
Remarks	<p>The data type describes discrete alarms using the following five elements:</p> <ul style="list-style-type: none"> • 1 Unacknowledged • 2 Alarm State • 3 Time Stamp • 4 Subcode • 5 Value

https://maxautoland.com/
 manski@cambid.com +86 18030205725

22.15 BLOCK_ERR

Classification	Simple Variable
Description	Reflects the error status associated with the hardware or software components associated with a block. It is a bit string that can show multiple errors.
FF Data Type	Bit String
Range	
Usage	C/Block Error
Length	2
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.16 BLOCK_ERR.DISABLED

Classification	
Description	Enables you to disable individual block errors.
FF Data Type	Bitstring
Range	
Usage	C/Contained
Length	
Valid Views	Dynamic
Storage	
Remarks	<ul style="list-style-type: none"> For the blocks such as AI block configured in Control Modules, when an inactive block error is disabled and if the block error turns active, the Alarm Display will not display the alarm and the Event Summary will not display the alarm event. For the devices only blocks such as, Resource or Transducer blocks, block error alarm appearance in the Alarm Display or System Status Display is affected. Regardless of disabling, the individual block error status is displayed on the block's Maintenance tab. When an active block error is disabled, the Alarm or Display or System Status Display alarm returns to normal, and Event Summary displays the alarm action as OK. In the Alarm Display or System Status Display, when you acknowledge block error alarms that have returned to normal, the alarms disappear and Event Summary displays the acknowledged alarms. When the disable is removed for an active block error, the Alarm Display or System Status Display displays the alarm as active and Event Summary receives the event for that particular alarm. <p>Note: This is not a Fieldbus block parameter. It is a Honeywell parameter, which is stored internally on the FIM but appears to reside on the Fieldbus block template.</p>

22.17 BYPASS

Classification	Simple Variable
Description	Provides the means to bypass the normal control algorithm. When BYPASS is On, the set point value is directly transferred to the output. To prevent a bump upon BYPASS switching, the set point automatically initializes to the output value or process variable and sets the path broken flag for one execution.
FF Data Type	Unsigned 8
Range	1: Off 2: On
Usage	C/Contained
Length	1
Valid Views	VIEW_2
Storage	Static
Remarks	Initial value is 0.

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.18 CAS_IN

Classification	Record
Description	Represents the remote set point value that must come from another Fieldbus block or a distributed control system (DCS) block through a defined link.
FF Data Type	DS-65
Range	
Usage	I/Cascade Input
Length	5
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	<p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.19 CAS_IN_D

Classification	Record
Description	Represents the remote set point value for a discrete block that must come from another Fieldbus block or a distributed control system (DCS) block through a defined link.
FF Data Type	DS-66
Range	
Usage	I/Cascade Input
Length	2
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	<p>The data type consists of the value and status of discrete value parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.20 CHANNEL

Classification	Simple Variable
Description	The number of the logical hardware channel that is connected to this I/O block. It defines the transducer used to connect to the physical world.
FF Data Type	Unsigned 16
Range	1 to Manufacturer Limit
Usage	C/Channel
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	The initial value is 0.

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.21 CLR_FSTATE

Classification	Simple Variable
Description	Serves as a switch to reset/clear the device fault state after the fault condition is cleared.
FF Data Type	Unsigned 8
Range	1: Off 2: Clear
Usage	C/Contained
Length	1
Valid Views	
Storage	Dynamic
Remarks	The operator can control PROGRAM or LOCAL access to these values.

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.22 CONFIRM_TIME

Classification	Simple Variable
Description	Defines the time between retries of alert reports.
FF Data Type	Unsigned 32
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_2
Storage	Static
Remarks	The initial value is 32000 milliseconds.

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.23 CONTROL_OPTS

Classification	Simple Variable
Description	Represents bit string for control options to alter the calculations done in an applicable function block.
FF Data Type	Bit String
Range	
Usage	C/Contained
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	See the following Table 2 for a list of the control options by bit and applicable function block.

Table 11: CONTROL_OPTS Bit Selections

Bit	Meaning	Function Block					
		ML	PB	PID	RA		
0	Bypass Enable (LSB)				X	X	
1	SP-PV Track in Man				X	X	X
2	SP-PV Track in ROut				X	X	
3	SP-PV Track in LO or IMan				X	X	X
4	SP Track retained target	X			X	X	X
5	Direct Acting				X	X	
6	Balance Ramp	X			X		X
7	Track Enable	X		X	X	X	X
8	Track in Manual	X		X	X	X	X
9	Use PV for BKCAL_OUT				X	X	X
10	Act on IR*	X			X		X
11	Use percent for IN_1	X					X
12	Obey SP limits if Cas or RCas	X			X	X	X
13	No_OUT limits in Manual	X	X	X	X	X	X
14	Reserved						
15	Reserved						

22.24 CYCLE_SEL

Classification	Simple Variable
Description	A bit string to identify the block execution method selected for this resource.
FF Data Type	Bit String
Range	
Usage	C/Contained
Length	2
Valid Views	VIEW_2
Storage	Static
Remarks	Changing this parameter may be fatal to communication.

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.25 CYCLE_TYPE

Classification	Simple Variable
Description	A bit string to identify the block execution methods available for this resource.
FF Data Type	Bit String
Range	Set by Manufacturer
Usage	C/Contained
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.26 DEV_REV

Classification	Simple Variable
Description	Identifies the manufacturer revision number associated with the resource. An interface device uses it to locate the DD file for the resource.
FF Data Type	Unsigned 8
Range	Set by manufacturer
Usage	C/Contained
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.27 DEV_TYPE

Classification	Simple Variable
Description	Identifies the manufacturer's model number associated with the resource. An interface device uses it to locate the DD file for the resource.
FF Data Type	Unsigned 16
Range	Set by manufacturer
Usage	C/Contained
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.28 DD_RESOURCE

Classification	Simple Variable
Description	Identifies the tag of the resource that contains the Device Description for this resource.
FF Data Type	Visible String
Range	
Usage	C/DD Resource
Length	32
Valid Views	
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.29 DD_REV

Classification	Simple Variable
Description	Identifies the revision of the Device Description associated with the resource so an interface device can locate the DD file for the resource.
FF Data Type	Unsigned 8
Range	
Usage	C/Contained
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.30 DISC_ALM

Classification	Record
Description	Identifies the status and time stamp associated with the discrete alarm.
FF Data Type	DS-72
Range	
Usage	C/Alarm
Length	13
Valid Views	
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type consists of data that describes discrete alarms. It uses the following five elements.</p> <ul style="list-style-type: none"> • 1 Unacknowledged • 2 Alarm State • 3 Time Stamp • 4 Subcode • 5 Value

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

22.31 DISC_LIM

Classification	Simple Variable
Description	Identifies state of discrete input that will generate an alarm.
FF Data Type	Unsigned 8
Range	PV state
Usage	C/Contained
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.32 DISC_PRI

Classification	Simple Variable
Description	Identifies the priority of the discrete alarm.
FF Data Type	Unsigned 8
Range	0 to 63
Usage	C/Alert Priority
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.33 DV_HI_ALM

Classification	Record
Description	Identifies the status and time stamp associated with the high deviation alarm.
FF Data Type	DS-71
Range	
Usage	C/Alarm
Length	16
Valid Views	
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The Data type consists of data that describes floating point alarms. It uses the following five elements.</p> <ul style="list-style-type: none"> • 1 Unacknowledged • 2 Alarm State • 3 Time Stamp • 4 Subcode • 5 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.34 DV_HI_LIM

Classification	Simple Variable
Description	Defines the high deviation alarm limit setting in engineering units.
FF Data Type	Float
Range	0 to PV Span, + infinity
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is + infinity

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.35 DV_HI_PRI

Classification	Simple Variable
Description	Defines priority of the high deviation alarm.
FF Data Type	Unsigned 8
Range	0 to 63
Usage	C/Alert Priority
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is 0

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.36 DV_LO_ALM

Classification	Record
Description	Identifies the status and time stamp associated with the low deviation alarm.
FF Data Type	DS-71
Range	
Usage	C/Alarm
Length	16
Valid Views	
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The Data type consists of data that describes floating point alarms. It uses the following five elements.</p> <ul style="list-style-type: none"> • 1 Unacknowledged • 2 Alarm State • 3 Time Stamp • 4 Subcode • 5 Value

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

22.37 DV_LO_LIM

Classification	Simple Variable
Description	Defines the low deviation alarm limit setting in engineering units.
FF Data Type	Float
Range	- infinity , - PV Span to 0,
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is - infinity

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.38 DV_LO_PRI

Classification	Simple Variable
Description	Defines priority of the low deviation alarm.
FF Data Type	Unsigned 8
Range	0 to 63
Usage	C/Alert Priority
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is 0

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.39 FAULT_STATE

Classification	Simple Variable
Description	Condition set by loss of communication to an output block, failure promoted to an output block or a physical contact. When the fault state action is active, the output function blocks will perform their FSTATE action
FF Data Type	Unsigned 8
Range	1: Clear 2: Active
Usage	C/Contained
Length	1
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.40 FEATURES

Classification	Simple Variable
Description	Bit string that identifies the supported resource block options.
FF Data Type	Bit String
Range	Set by manufacturer
Usage	C/Contained
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.41 FEATURE_SEL

Classification	Simple Variable
Description	Bit string that identifies the selected resource block options.
FF Data Type	Bit String
Range	
Usage	C/Contained
Length	2
Valid Views	VIEW_2
Storage	Static
Remarks	This parameter must have the Reports bit set (FEATURE_SEL[1]). Without it, the device never issues any alarm notifications.

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.42 FF_GAIN

Classification	Simple Variable
Description	Defines the gain value used to multiply the feed-forward signal before it is added to the calculated control output.
FF Data Type	Float
Range	
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.43 FF_SCALE

Classification	Record
Description	Defines the feed-forward input high and low scale values, engineering units code, and number of digits to the right of the decimal.
FF Data Type	DS-68
Range	0-100 percent
Usage	C/Scaling
Length	11
Valid Views	VIEW_4
Storage	Static
Remarks	<p>The Data type consists of data that describes floating point values for display purposes. It uses the following four elements.</p> <ul style="list-style-type: none"> • 1 Engineering Units at 100 percent • 2 Engineering Units at 0 percent • 3 Units Index • 4 Decimal Point

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

22.44 FF_VAL

Classification	Record
Description	Represents the feed-forward value.
FF Data Type	DS-65
Range	
Usage	I/Input
Length	5
Valid Views	VIEW_3
Storage	Non-Volatile
Remarks	<p>Read Only</p> <p>The Data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.45 FIELD_VAL

Classification	Record
Description	Represents the raw value from the field device in percent of transducer span, with a status reflecting the transducer condition, before signal characterization (L_TYPE) or filtering (PV_FTIME).
FF Data Type	DS-65
Range	
Usage	C/Contained
Length	5
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The Data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.46 FIELD_VAL_D

Classification	Record
Description	Represents the raw value of a field device discrete input with a status reflecting the transducer condition.
FF Data Type	DS-66
Range	
Usage	C/Contained
Length	2
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of discrete value parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.47 FREE_SPACE

Classification	Simple Variable
Description	Identifies the percent of memory available for further configuration. Zero in a preconfigured resource.
FF Data Type	Float
Range	0 - 100 percent
Usage	C/Contained
Length	4
Valid Views	VIEW_2
Storage	Dynamic
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.48 FREE_TIME

Classification	Simple Variable
Description	Identifies the percent of block processing time that is free to process additional blocks.
FF Data Type	Float
Range	0 - 100 percent
Usage	C/Contained
Length	4
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.49 FSTATE_TIME

Classification	Simple Variable
Description	Represents the reaction time in seconds from the detection of a failure at the output block remote set point to the output block action, if the condition still exists.
FF Data Type	Float
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.50 FSTATE_VAL

Classification	Simple Variable
Description	Defines the preset analog set point to use when a failure occurs. Value is ignored, if the IO_OPTS Fault state to value option is false.
FF Data Type	Float
Range	PV_SCALE +/- 10 percent
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.51 FSTATE_VAL_D

Classification	Simple Variable
Description	Defines the preset discrete set point to use when a failure occurs. Value is ignored, if the IO_OPTS Fault state to value option is false.
FF Data Type	Unsigned 8
Range	
Usage	C/Contained
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.52 GAIN

Classification	Simple Variable
Description	Represents dimensionless gain used by several different algorithms.
FF Data Type	Float
Range	
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.53 GRANT_DENY

Classification	Record
Description	Defines options for controlling access of host computer or local control panels to the block's operating, tuning, and alarm parameters.
FF Data Type	DS-70
Range	
Usage	C/Access Permission
Length	2
Valid Views	VIEW_2
Storage	Non-Volatile
Remarks	<p>The data type consists of access control flags for access to block parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Grant • 2 Deny

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.54 HARD_TYPES

Classification	Simple Variable
Description	Identifies types of hardware that are available as channel numbers on this resource.
FF Data Type	Bit String
Range	Set by manufacturer
Usage	C/Contained
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.55 HI_ALM

Classification	Record
Description	Identifies the status and time stamp associated with the high alarm.
FF Data Type	DS-71
Range	
Usage	C/Alarm
Length	16
Valid Views	
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The Data type consists of data that describes floating point alarms. It uses the following five elements.</p> <ul style="list-style-type: none"> • 1 Unacknowledged • 2 Alarm State • 3 Time Stamp • 4 Subcode • 5 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.56 HI_HI_ALM

Classification	Record
Description	Identifies the status and time stamp associated with the high alarm.
FF Data Type	DS-71
Range	
Usage	C/Alarm
Length	16
Valid Views	
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The Data type consists of data that describes floating point alarms. It uses the following five elements.</p> <ul style="list-style-type: none"> • 1 Unacknowledged • 2 Alarm State • 3 Time Stamp • 4 Subcode • 5 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.57 HI_HI_LIM

Classification	Simple Variable
Description	Defines the high high alarm limit setting in engineering units.
FF Data Type	Float
Range	PV_SCALE, + infinity
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is + infinity

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.58 HI_HI_PRI

Classification	Simple Variable
Description	Defines priority of the high high alarm.
FF Data Type	Unsigned 8
Range	0 to 63
Usage	C/Alert Priority
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is 0

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.59 HI_LIM

Classification	Simple Variable
Description	Defines the high alarm limit setting in engineering units.
FF Data Type	Float
Range	PV_SCALE, + infinity
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is + infinity

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.60 HI_PRI

Classification	Simple Variable
Description	Defines priority of the high alarm.
FF Data Type	Unsigned 8
Range	0 to 63
Usage	C/Alert Priority
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is 0

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.61 IO_OPTS

Classification	Simple Variable
Description	Identifies user-selectable options for altering the Input and Output block processing.
FF Data Type	Bit String
Range	
Usage	C/Contained
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	See the following Table 3 for a list of the control options by bit and applicable function block.

Table 12: IO_OPTS Bit Selections

Bit	Meaning	Function Block			
		AI	DI	AO	DO
0	Invert		X		X
1	SP-PV Track in Man			X	X
2	Reserved				
3	SP-PV Track in LO or IMan			X	X
4	SP Track retained target			X	X
5	Increase to close			X	
6	Fault state to value			X	X
7	Use Fault state value to restart			X	X
8	Target to Man if fault state activated			X	X
9	Use PV for BKCAL_OUT			X	X
10	Low Cutoff	X			
11	Reserved				
12	Reserved				
13	Reserved				
14	Reserved				
15	Reserved				

22.62 IN

Classification	Record
Description	Represents the primary input value of the block. Blocks that filter the input to get the PV require this parameter.
FF Data Type	DS-65
Range	
Usage	I/Primary Input
Length	5
Valid Views	VIEW_3
Storage	Non-Volatile
Remarks	<p>Read Only</p> <p>The Data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.63 IN_1

Classification	Record
Description	Represents the auxiliary input value to the block. It is used for values other than the PV.
FF Data Type	DS-65
Range	
Usage	I/Input
Length	5
Valid Views	VIEW_3
Storage	Non-Volatile
Remarks	<p>Read Only</p> <p>The Data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.64 LIM_Notify

Classification	Simple Variable
Description	Defines the maximum number of unconfirmed alert notify messages allowed.
FF Data Type	Unsigned 8
Range	0 to MAX_NOTIFY
Usage	C/Contained
Length	1
Valid Views	VIEW_2
Storage	Static
Remarks	Initial value is MAX_NOTIFY. This parameter describes the number of alerts that the device can send out at the same time. A setting of zero results in never transmitting any alarm notifications. It must be set greater than zero for alarming to work.

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.65 L_TYPE

Classification	Simple Variable
Description	Determines whether the values passed by the Transducer block to the Analog Input block may be used directly (DIRECT) or, if the value is in different units, must be converted linearly (indirectly); or with square root (Ind Sqr Root), using the input range defined by the transducer and associated output range.
FF Data Type	Unsigned 8
Range	1. Direct 2. Indirect 3. Ind Sqr Root
Usage	C/Contained
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.66 LO_ALM

Classification	Record
Description	Represents the status of the low alarm and its associated time stamp.
FF Data Type	DS-71
Range	
Usage	C/Alarm
Length	16
Valid Views	
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The Data type consists of data that describes floating point alarms. It uses the following five elements.</p> <ul style="list-style-type: none"> • 1 Unacknowledged • 2 Alarm State • 3 Time Stamp • 4 Subcode • 5 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.67 LO_LIM

Classification	Simple Variable
Description	Defines the setting for the low alarm in engineering units.
FF Data Type	Float
Range	- Infinity, PV_SCALE
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is - Infinity

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.68 LO_LO_ALM

Classification	Record
Description	Represents the status of the low low alarm and its associated time stamp.
FF Data Type	DS-71
Range	
Usage	C/Alarm
Length	16
Valid Views	
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The Data type consists of data that describes floating point alarms. It uses the following five elements.</p> <ul style="list-style-type: none"> • 1 Unacknowledged • 2 Alarm State • 3 Time Stamp • 4 Subcode • 5 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.69 LO_LO_LIM

Classification	Simple Variable
Description	Defines the setting for the low low alarm in engineering units.
FF Data Type	Float
Range	- Infinity, PV_SCALE
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Initial value is - Infinity

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.70 LO_LO_PRI

Classification	Simple Variable
Description	Represents the priority of the low low alarm.
FF Data Type	Unsigned 8
Range	0 to 63
Usage	C/Alert Priority
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.71 LO_PRI

Classification	Simple Variable
Description	Represents the priority of the low alarm.
FF Data Type	Unsigned 8
Range	0 to 63
Usage	C/Alert Priority
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.72 LOW_CUT

Classification	Simple Variable
Description	Represents the limit used for the flow sensor input processing by the Analog Input block, if the Low Cutoff selection is chosen in IO_OPTS. If the calculated PV falls below this limit, the PV value is set to zero (0).
FF Data Type	Float
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	This function may be used to eliminate noise near zero from a flow sensor.

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.73 MANUFAC_ID

Classification	Simple Variable
Description	Defines the manufacturer's identification number. An interface device uses this number to locate the DD file for the resource.
FF Data Type	Unsigned 32
Range	Set by manufacturer
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.74 MAX_NOTIFY

Classification	Simple Variable
Description	Defines the maximum number of unconfirmed notify messages possible.
FF Data Type	Unsigned 8
Range	Set by manufacturer
Usage	C/Contained
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
manski@cambid.com +86 18030205725

22.75 MEMORY_SIZE

Classification	Simple Variable
Description	Represents the available configuration memory in the empty resource.
FF Data Type	Unsigned 16
Range	Set by manufacturer
Usage	C/Contained
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.76 MIN_CYCLE_T

Classification	Simple Variable
Description	Defines the time duration of the shortest cycle interval that the resource can support.
FF Data Type	Unsigned 32
Range	Set by manufacturer
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.77 MODE_BLK

Classification	Record
Description	Represents the mode record of the block. Contains the Actual, Target, Permitted, and Normal modes.
FF Data Type	DS-69
Range	
Usage	C/Mode
Length	4
Valid Views	VIEW_1, VIEW_3
Storage	Mix
Remarks	<p>Normally, the operator has permission to write these values, but PROGRAM or LOCAL remove that permission and grant it to a supervisory computer or a local control panel.</p> <p>This block has a mixture of storage types. Static for modes Normal and Permitted, Non-Volatile for Target mode, and Dynamic for Actual mode.</p> <p>The data type consists of bit strings for Actual, Target Permitted and Normal modes. It uses the following four elements.</p> <ul style="list-style-type: none"> • 1 Target • 2 Actual • 3 Permitted • 4 Normal

<https://maxautoland.com/>
 manski@cambid.com +86 18030205253

22.78 NV_CYCLE_T

Classification	Simple Variable
Description	Defines interval between writing copies of Non-Volatile (NV) parameters to NV memory. Zero means never.
FF Data Type	Unsigned 32
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_2
Storage	Static
Remarks	Ready Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.79 OFFNETALM_ENABLED

Classification	Simple Variable
Description	Represents enabling or disabling the Block Offnet Diagnostic Alarm. By default, this is disabled.
FF Data Type	Bit String
Range	Enable Disable
Usage	Device Offnet Process Alarm
Length	
Valid Views	
Storage	Dynamic
Remarks	This is not a Fieldbus block parameter. It is a Honeywell parameter, which is stored internally on the FIM but appears to reside on the Fieldbus block template.

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.80 OUT

Classification	Record
Description	Represents the primary analog value calculated as a result of executing the function.
FF Data Type	DS-65
Range	OUT_SCALE +/- 10 percent
Usage	O/Primary Output
Length	5
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	<p>Normally, the operator has permission to write this value, but PROGRAM or LOCAL remove that permission and grant it to a supervisory computer or a local control panel.</p> <p>The Data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.81 OUT_D

Classification	Record
Description	Represents the primary discrete value calculated as a result of executing the function.
FF Data Type	DS-66
Range	OUT_STATE
Usage	O/Primary Output
Length	2
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	<p>Normally, the operator has permission to write this value, but PROGRAM or LOCAL remove that permission and grant it to a supervisory computer or a local control panel.</p> <p>The data type consists of the value and status of discrete value parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.82 OUT_HI_LIM

Classification	Simple Variable
Description	Defines the maximum output value limit in all modes, unless the CONTROL_OPTS selection No Out limits in Manual is chosen.
FF Data Type	Float
Range	OUT_SCALE +/- 10 percent
Usage	C/Contained
Length	4
Valid Views	VIEW_2
Storage	Static
Remarks	Initial value is 100.

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.83 OUT_LO_LIM

Classification	Simple Variable
Description	Defines the minimum output value limit in all modes, unless the CONTROL_OPTS selection No Out limits in Manual is chosen.
FF Data Type	Float
Range	OUT_SCALE +/- 10 percent
Usage	C/Contained
Length	4
Valid Views	VIEW_2
Storage	Static
Remarks	Initial value is 0.

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.84 OUT_SCALE

Classification	Record
Description	Defines the high and low scale values, engineering units code, and number of digits to the right of the decimal point to be used in displaying the OUT parameter and parameters that have the same scaling as OUT.
FF Data Type	DS-68
Range	
Usage	C/Scaling
Length	11
Valid Views	VIEW_2
Storage	Static
Remarks	<p>The Data type consists of data that describes floating point values for display purposes. It uses the following four elements.</p> <ul style="list-style-type: none"> • 1 Engineering Units at 100 percent • 2 Engineering Units at 0 percent • 3 Units Index • 4 Decimal Point

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.85 OUT_STATE

Classification	Simple Variable
Description	Represents the index to the text describing the states of a discrete output.
FF Data Type	Unsigned 16
Range	
Usage	C/Contained
Length	2
Valid Views	VIEW_2
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.86 PV

Classification	Record
Description	Represents either the primary analog value for use in executing the function, or a process value associated with it. It may also be calculated from the READBACK value of an Analog Output block.
FF Data Type	DS-65
Range	
Usage	C/Process Variable
Length	5
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.87 PV_D

Classification	Record
Description	Represents either the primary discrete value for use in executing the function, or a process value associated with it. It may also be calculated from the READBACK_D value of a Discrete Output block.
FF Data Type	DS-66
Range	
Usage	C/Process Variable
Length	2
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of discrete value parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.88 PV_FTIME

Classification	Simple Variable
Description	Defines the time constant of a single exponential filter for the Process Variable in seconds.
FF Data Type	Float
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.89 PV_SCALE

Classification	Record
Description	Defines the high and low scale values, engineering units code, and number of digits to the right of the decimal point to be used in displaying the PV parameter and parameters that have the same scaling as PV.
FF Data Type	DS-68
Range	
Usage	C/Scaling
Length	11
Valid Views	VIEW_2
Storage	Static
Remarks	<p>The Data type consists of data that describes floating point values for display purposes. It uses the following four elements.</p> <ul style="list-style-type: none"> • 1 Engineering Units at 100 percent • 2 Engineering Units at 0 percent • 3 Units Index • 4 Decimal Point

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.90 PV_STATE

Classification	Simple Variable
Description	Defines the index to the text describing the states of a discrete PV.
FF Data Type	Unsigned 16
Range	
Usage	C/Contained
Length	2
Valid Views	VIEW_2
Storage	Static
Remarks	

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.91 RA_FTIME

Classification	Simple Variable
Description	Defines the time constant of a single exponential filter for the value to be ratioed in seconds.
FF Data Type	Float
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.92 RATE

Classification	Simple Variable
Description	Defines the derivative time constant in seconds.
FF Data Type	Float
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.93 RCAS_IN

Classification	Record
Description	Represents target set point and status provided by a supervisory host to the analog control or output block.
FF Data Type	DS-65
Range	
Usage	C/Remote-Cascade In
Length	5
Valid Views	VIEW_3
Storage	Non-Volatile
Remarks	<p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

22.94 RCAS_IN_D

Classification	Record
Description	Represents target set point and status provided by a supervisory host to the analog control or output block.
FF Data Type	DS-66
Range	
Usage	C/Remote-Cascade In
Length	2
Valid Views	VIEW_3
Storage	Non-Volatile
Remarks	<p>The data type consists of the value and status of discrete value parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.95 RCAS_OUT

Classification	Record
Description	Represents block set point and status after ramping. It serves as input to a supervisory host for back calculation that allows action to be taken under limiting conditions or mode change.
FF Data Type	DS-65
Range	
Usage	C/Remote-Cascade Out
Length	5
Valid Views	VIEW_3
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205125

22.96 RCAS_OUT_D

Classification	Record
Description	Represents block set point and status. It serves as input to a supervisory host for back calculation that allows action to be taken under limiting conditions or mode change.
FF Data Type	DS-66
Range	
Usage	C/Remote-Cascade Out
Length	2
Valid Views	VIEW_3
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of discrete value parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.97 READBACK

Classification	Record
Description	Represents the 'readback' of the actual continuous valve or other actuator position in transducer units.
FF Data Type	DS-65
Range	
Usage	C/Contained
Length	5
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.98 READBACK_D

Classification	Record
Description	Represents the 'readback' of the actual discrete valve or other actuator position in the transducer state.
FF Data Type	DS-66
Range	
Usage	C/Contained
Length	2
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of discrete value parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.99 RESET

Classification	Simple Variable
Description	Represents the Integral time constant in seconds. It is the inverse of repeats per minute.
FF Data Type	Float
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.100 RESTART

Classification	Simple Variable
Description	Allows a manual restart to be initiated. The following degrees of restart are possible. <ul style="list-style-type: none"> • 1: Run • 2: Restart Resource • 3: Restart with Defaults • 4: Restart Processor
FF Data Type	Unsigned 8
Range	1: Run 2: Restart Resource 3: Restart with Defaults 4: Restart Processor
Usage	C/Contained
Length	1
Valid Views	
Storage	Dynamic
Remarks	Changing this parameter, may be fatal to communication. Note that the Restart with Defaults function restarts the Fieldbus device with factory default values instead of Experion ones. To restore Experion default values, re-load the device block through Control Builder with associated blocks set for Full instead of Partial Load .

https://maxautolamp.com/10030205725
manski@cambid.com

22.101 ROUT_IN

Classification	Record
Description	Represents target output and status provided by a host to a control block for use as the block's output in ROUT mode.
FF Data Type	DS-65
Range	
Usage	C/Remote-Output In
Length	5
Valid Views	VIEW_3
Storage	Dynamic
Remarks	<p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.102 ROUT_OUT

Classification	Record
Description	Represents block output and status. It serves as input to a host for back calculation in ROut mode that allows action to be taken under limited conditions or mode change
FF Data Type	DS-65
Range	
Usage	C/Remote-Output Out
Length	5
Valid Views	VIEW_3
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.103 RS_STATE

Classification	Simple Variable
Description	Defines the state of the function block application state machine.
FF Data Type	Unsigned 8
Range	<ol style="list-style-type: none"> 1. Start/Restart 2. Initialization 3. On-Line Linking 4. On-Line 5. Standby 6. Failure
Usage	C/Resource State
Length	1
Valid Views	VIEW_1, VIEW_3
Storage	Dynamic
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.104 SEL_1

Classification	Record
Description	Represents first input value to the selector.
FF Data Type	DS-65
Range	
Usage	I/Cascade Input
Length	5
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.105 SEL_2

Classification	Record
Description	Represents second input value to the selector.
FF Data Type	DS-65
Range	
Usage	I/Cascade Input
Length	5
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.106 SEL_3

Classification	Record
Description	Represents third input value to the selector.
FF Data Type	DS-65
Range	
Usage	I/Cascade Input
Length	5
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.107 SEL_TYPE

Classification	Simple Variable
Description	Defines the type of selector action as High, Medium, or Low.
FF Data Type	Unsigned 8
Range	1: High 2: Low 3: Medium
Usage	C/Contained
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.108 SET_FSTATE

Classification	Simple Variable
Description	Allows the fault state condition to be manually initiated by selecting Set.
FF Data Type	Unsigned 8
Range	1: Off 2: Set
Usage	C/Contained
Length	1
Valid Views	
Storage	Dynamic
Remarks	The operator can control PROGRAM or LOCAL access to this value.

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.109 SHED_OPT

Classification	Simple Variable
Description	Defines action to be taken on remote control device timeout.
FF Data Type	Unsigned 8
Range	<p>1: Normal Shed, normal return -See Note 1 in Remarks</p> <p>2: Normal Shed, no return - See Note 2 in Remarks</p> <p>3: Shed to Auto, normal return</p> <p>4: Shed to Auto, no return - See Note 3 in Remarks</p> <p>5: Shed to Manual, normal return</p> <p>6: Shed to Manual, no return - See Note 4 in Remarks</p> <p>7: Shed to Retained target, normal return (Not used in Experion)</p> <p>8: Shed to Retained target, no return ((Not used in Experion)</p>
Usage	C/Shed Option
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	<p>Note 1: Actual mode changes to the next lowest priority non-remote mode permitted but returns to the target remote mode, when the remote computer completes the initialization handshake.</p> <p>Note 2: Target mode changes to the next lowest priority non-remote mode permitted. The target remote mode is lost, so there is no return to it.</p> <p>Note 3: Target mode changes to Auto on detection of a shed condition.</p> <p>Note 4: Target mode changes to Man on detection of a shed condition.</p>

<https://maxaut.com/>
 manski@cambria.com/8618030205125

22.110 SHED_RCAS

Classification	Simple Variable
Description	Defines timeout in milliseconds for computer writes to function block RCas locations.
FF Data Type	Unsigned 32
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_2
Storage	Static
Remarks	

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.111 SHED_ROUT

Classification	Simple Variable
Description	Defines timeout in milliseconds for computer writes to function block ROut locations.
FF Data Type	Unsigned 32
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_2
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.112 SIMULATE

Classification	Record
Description	Allows the transducer analog input or output to the block to be manually supplied, when SIMULATE is enabled. When SIMULATE is disabled, the simulate value and status track the actual value and status.
FF Data Type	DS-82
Range	
Usage	C/Simulate
Length	11
Valid Views	
Storage	Dynamic
Remarks	<p>The data type consists of simulate and transducer floating point value and status and a simulate enable/disable discrete. It uses the following five elements.</p> <ul style="list-style-type: none"> 1: Simulate Status 2: Simulate Value 3: Transducer Status 4: Transducer Value 5: Simulate Enable/Disable

<https://maxautoland.com/>
 manski@cambid.com +86 18030205125

22.113 SIMULATE_D

Classification	Record
Description	Allows the transducer discrete input or output to the block to be manually supplied, when SIMULATE is enabled. When SIMULATE is disabled, the simulate value and status track the actual value and status.
FF Data Type	DS-83
Range	
Usage	C/Simulate
Length	5
Valid Views	
Storage	Dynamic
Remarks	<p>The data type consists of a simulate and transducer discrete value and status and a simulate enable/disable discrete. It uses the following five elements.</p> <ul style="list-style-type: none"> 1: Simulate Status 2: Simulate Value 3: Transducer Status 4: Transducer Value 5: Simulate Enable/Disable

<https://maxautoland.com/>
 manski@cambid.com +86 18030205125

22.114 SP

Classification	Record
Description	Defines the set point of any analog block.
FF Data Type	DS-65
Range	PV_SCALE +/- 10 percent
Usage	C/Set point
Length	5
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	<p>SP (SP_D) is normally written by an operator occasionally while in Auto mode. It is not intended to be written as a cascade setpoint input. Instead, a connection to CAS_IN is intended to provide a value into SP (SP_D) when in Cas mode and a write into RCAS_IN is intended to provide a value into SP (SP_D) when in RCas mode. However, SP (SP_D) may be updated when operating in ROut mode in order to provide a reasonable setpoint, if failing from ROut to Auto mode upon a failure of the ROUT_IN update.</p> <p>The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambiala.cn +86 18031205169

22.115 SP_D

Classification	Record
Description	Defines the set point of any discrete block.
FF Data Type	DS-66
Range	PV_STATE
Usage	C/Set point
Length	2
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	<p>SP (SP_D) is normally written by an operator occasionally while in Auto mode. It is not intended to be written as a cascade setpoint input. Instead, a connection to CAS_IN is intended to provide a value into SP (SP_D) when in Cas mode and a write into RCAS_IN is intended to provide a value into SP (SP_D) when in RCas mode. However, SP (SP_D) may be updated when operating in ROut mode in order to provide a reasonable setpoint, if failing from ROut to Auto mode upon a failure of the ROUT_IN update.</p> <p>The data type consists of the value and status of discrete value parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205169

22.116 SP_HI_LIM

Classification	Simple Variable
Description	Defines the high limit for set point entry.
FF Data Type	Float
Range	PV_SCALE +/- 10 percent
Usage	C/Contained
Length	4
Valid Views	VIEW_2
Storage	Static
Remarks	Initial value is 100 percent

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.117 SP_LO_LIM

Classification	Simple Variable
Description	Defines the low limit for set point entry.
FF Data Type	Float
Range	PV_SCALE +/- 10 percent
Usage	C/Contained
Length	4
Valid Views	VIEW_2
Storage	Static
Remarks	Initial value is zero (0)

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.118 SP_RATE_DN

Classification	Simple Variable
Description	Defines the downward ramp rate in PV units per second for set point changes to invoke action in the Auto mode.
FF Data Type	Float
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	If the ramp rate is set to zero or the block is not in Auto mode, the set point change is invoked immediately.

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.119 SP_RATE-UP

Classification	Simple Variable
Description	Defines the upward ramp rate in PV units per second for set point changes to invoke action in the Auto mode.
FF Data Type	Float
Range	Positive
Usage	C/Contained
Length	4
Valid Views	VIEW_4
Storage	Static
Remarks	If the ramp rate is set to zero or the block is not in Auto mode, the set point change is invoked immediately.

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.120 ST_REV

Classification	Simple Variable
Description	Defines the revision level of the static data associated with the function block. The revision value is incremented each time a static parameter value in the block is changed.
FF Data Type	Unsigned 16
Range	
Usage	C/Static Revision
Length	2
Valid Views	VIEW_1, VIEW_2, VIEW_3, VIEW_4
Storage	Static
Remarks	Read Only

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.121 STATUS_OPTS

Classification	Simple Variable
Description	Defines user-selectable options for the block processing of status.
FF Data Type	Bit String
Range	
Usage	C/Contained
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	See the following Table 4 for a list of the control options by bit and applicable function block.

Table 13: STATUS_OPTS Bit Selections

Bit	Meaning	Function Block									
		AO	DO	ML	BG	CS	PD	PID	RA		
0	IFS if BAD IN					X	X	X	X	X	X
1	IFS if BAD CAS_IN			X	X		X		X	X	X
2	Use Uncertain as Good					X	X	X	X	X	X
3	Propagate Failure Forward	X	X								
4	Propagate Failure Backward			X	X		X				X
5	Target to Manual if BAD IN								X	X	
6	Uncertain if Limited	X									
7	BAD if Limited	X									
8	Uncertain if Man Mode	X	X					X			X
9	Do not select if not Auto mode	X	X						X	X	
10	Do not select if not Gas mode								X	X	
11	Reserved										
12	Reserved										
13	Reserved										
14	Reserved										
15	Reserved										

22.122 STRATEGY

Classification	Simple Variable
Description	Assists in grouping blocks. This data is not checked or processed by the block.
FF Data Type	Unsigned 16
Range	
Usage	C/Strategy
Length	2
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.123 TAG_DESC

Classification	Simple Variable
Description	Serves as user defined description of the block.
FF Data Type	Octet String
Range	
Usage	C/Tag Description
Length	32
Valid Views	
Storage	Static
Remarks	Initial value is 32 space characters

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.124 TEST_RW

Classification	Record
Description	Defines read/write test parameter.
FF Data Type	DS-85
Range	
Usage	C/Test
Length	112
Valid Views	
Storage	Dynamic
Remarks	<p>The data type consists of function block test read/write data. It uses the following 15 elements.</p> <ul style="list-style-type: none"> • 1 Value 1 (Boolean) • 2 Value 2 (Integer 8) • 3 Value 3 (Integer 16) • 4 Value 4 (Integer 32) • 5 Value 5 (Unsigned 8) • 6 Value 6 (Unsigned 16) • 7 Value 7 (Unsigned 32) • 8 Value 8 (Floating Point) • 9 Value 9 (Visible String) • 10 Value 10 (Octet String) • 11 Value 11 (Date) • 12 Value 12 (Time of Day) • 13 Value 13 (Time Difference) • 14 Value 14 (Bit String) • 15 Value 15 (Time Value)

<https://maxautoclimate.com/>
 manski@cambria.com 18030205725

22.125 TRK_IN_D

Classification	Record
Description	Represents the discrete input for initiation of the external tracking function.
FF Data Type	DS-66
Range	
Usage	I/Input
Length	2
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	<p>Read Only</p> <p>The data type consists of the value and status of discrete value parameters. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.126 TRK_SCALE

Classification	Record
Description	Defines the high and low scale values, engineering units code, and number of digits to the right of the decimal point associated with TRK_VAL.
FF Data Type	DS-68
Range	
Usage	C/Scaling
Length	11
Valid Views	VIEW_4
Storage	Static
Remarks	<p>The Data type consists of data that describes floating point values for display purposes. It uses the following four elements.</p> <ul style="list-style-type: none"> • 1 Engineering Units at 100 percent • 2 Engineering Units at 0 percent • 3 Units Index • 4 Decimal Point

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725
 manski@cambi.com.cn

22.127 TRK_VAL

Classification	Record
Description	Represents the input value for external tracking.
FF Data Type	DS-65
Range	
Usage	I/Input
Length	5
Valid Views	VIEW_1, VIEW_3
Storage	Non-Volatile
Remarks	<p>Read Only The data type consists of the value and status of floating point parameters that are Inputs or Outputs. It uses the following two elements.</p> <ul style="list-style-type: none"> • 1 Status • 2 Value

<https://maxautoland.com/>
 manski@cambi.a.cn +86 18030205725

22.128 UPDATE_EVT

Classification	Record
Description	Represents an alert generated by any change to the static data.
FF Data Type	DS-73
Range	
Usage	C/Event Update
Length	1, 4
Valid Views	
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type consists of data that describes a static revision alarm. It uses the following five elements.</p> <ul style="list-style-type: none"> • 1 Unacknowledged • 2 Update State • 3 Time Stamp • 4 Static Revision • 5 Relative Index

<https://maxautoland.com/>
 manski@cambia.cn +86 18030205725

22.129 WRITE_ALM

Classification	Record
Description	Represents alert that is generated if the write lock is cleared.
FF Data Type	DS-72
Range	
Usage	C/Alarm
Length	1, 3
Valid Views	
Storage	Dynamic
Remarks	<p>Read Only</p> <p>The data type describes discrete alarms using the following five elements:</p> <ul style="list-style-type: none"> • 1 Unacknowledged • 2 Alarm State • 3 Time Stamp • 4 Subcode • 5 Value

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.130 WRITE_LOCK

Classification	Simple Variable
Description	Used to disallow writes from anywhere, except to unlock/clear this parameter, when it is locked/set. Inputs will continue to read.
FF Data Type	Unsigned 8
Range	1: Unlocked 2: Locked
Usage	C/Contained
Length	1
Valid Views	VIEW_2
Storage	Static
Remarks	The operator can control PROGRAM and LOCAL access to this value.

<https://maxautoland.com/>
 manski@cambid.com.cn +86 18030205725

22.131 WRITE_PRI

Classification	Simple Variable
Description	Defines the priority of the alarm generated by clearing the WRITE_LOCK.
FF Data Type	Unsigned 8
Range	0 to 63
Usage	C/Alert Priority
Length	1
Valid Views	VIEW_4
Storage	Static
Remarks	

<https://maxautoland.com/>
manski@cambi.a.cn +86 18030205725

22.132 XD_SCALE

Classification	Record
Description	Defines the high and low scale values, engineering units code, and number of digits to the right of the decimal point used with a specified channel value obtained from the Transducer.
FF Data Type	DS-68
Range	
Usage	C/Scaling
Length	11
Valid Views	VIEW_2
Storage	Static
Remarks	<p>The Data type consists of data that describes floating point values for display purposes. It uses the following four elements.</p> <ul style="list-style-type: none"> • 1 Engineering Units at 100 percent • 2 Engineering Units at 0 percent • 3 Units Index • 4 Decimal Point

<https://maxautoland.com/>
 manski@cambid.com +86 18030205725

22.133 XD_STATE

Classification	Simple Variable
Description	Represents index to the text describing the states of a discrete for the value obtained from the Transducer.
FF Data Type	Unsigned 16
Range	
Usage	C/Contained
Length	2
Valid Views	VIEW_2
Storage	Static
Remarks	

<https://maxautoland.com/>
 manski@cambiala.cn +86 18030205725

<https://maxautoland.com/>
manski@cambiala.cn +86 18030205725

23 Glossary of Fieldbus Terms

The following table lists some Fieldbus terms and abbreviations for general reference.

Term	Abbreviation	Description
Application Process	AP	
Capability File		The Capability file contains some or all of the given Fieldbus device's information that can be read from a device online. It consists of both resource information (what the device can potentially do) and value information (how the device should actually be set up).
Common File Format	CFF	The format of a Capability file is a readable text document based on a Windows Initialization (INI) file type.
Connection Manager		A Fieldbus Foundation service to manage connection information about device types, devices, and blocks that are actively communicating with a host application.
Data Link Entity	DLE	
Data Link Layer	DLL	Defined in ISO 7498
Data Link Layer Management Entity	DLME	
Data Link Protocol Data Unit	DLPDU	
Device Description	DD	A binary file (*.ff0) that provides the definition for parameters in the FBAP of a device. For example, what Function Blocks a device contains, and what parameters are in those blocks.

<https://maxautolab.com/2016/06/10/fieldbus-terms/>
 manski@cambria.ch

Term	Abbreviation	Description
Device Description Item	DD Item	Item is a fundamental concept of the Device Description Language (DDL). It makes up the description of the device and can be any of the following constructs: <ul style="list-style-type: none"> • Array* • Block* • Collection • Domain • Edit Display • Item Array • Menu • Method • Program • Record* • Refresh Relation • Response Code • Variable* • Variable List* • WAO Relation <p>* These items are of the most interest to Block Type templates.</p>
Device Description Language	DDL	The language that vendors use to define their device's Function blocks and parameters.
Device Description Object	DDO	The suffix name for incremental DD binary files supplied by vendors that are to be converted to full and complete DD binary files by the Fieldbus Foundation Synthesizer.
Device Description Service	DDS	A software library developed by the Fieldbus Foundation that provides a generic access to a DD.
DD Synthesizer		A tool supplied by the Fieldbus Foundation. It combines incremental DDs, with unresolved references, with Fieldbus Foundation standard DDs to produce a complete/full DD that can be used with DDS.
Enhanced Device Description	EDD	A newer version of the binary file (*.ff5) that provides the definition for parameters in the FBAP of a device. For example, what Function Blocks a device contains, and what parameters are in those blocks.
Enhanced Device Description Language	EDDL	The language that vendors use to define their device's Function blocks and parameters.
Fieldbus Access Sublayer	FAS	
Fieldbus Foundation Object	FFO or FF5	The suffix name for the complete/full DD binary file.
Fieldbus Foundation Tokenizer		A Fieldbus Foundation tool that converts an ASCII text file written in conformance with the Device Description Language specification into a DD binary file.
Fieldbus Message Specification	FMS	
H1 Fieldbus Segment		An independent electrical environment consisting of wire, terminators and a power source per IEC 61158-1/ISA S50.1 for supporting Fieldbus devices.
H1 Fieldbus Link		The logical medium by which H1 Fieldbus devices are interconnected. It is composed of one or more physical segments interconnected by bus Repeaters or Couplers. All of the devices on a link share a common schedule, which is administered by that link's current LAS.

Term	Abbreviation	Description
Immediate Response Recovery Delay	IRRD	
International Organization For Standardization	ISO	
Link Active Scheduler	LAS	A Link bus scheduler that maintains a list of transmission times for all data buffers in all devices that need to be periodically transmitted. Only one Link Master (LM) device on an H1 Fieldbus Link can be functioning as that link's LAS.
Medium Attachment Unit	MAU	For wire media MAU = transceiver.
Medium Dependent Sublayer	MDS	
Network Management Agent	NMA	
Object Dictionary	OD	Contains the Object Descriptions for communication objects such as DataType, DataTypeStructureDescription, and SimpleVariable.
Open Systems Interconnection	OSI	
Pass Token Data Link Protocol Data Unit	PT DLPDU	
Physical Layer	PhL	
Physical Layer Overhead	PhLO	
Physical Layer Protocol Data Unit	PhPDU	
Production Rules		The grammar, in BNF format, used to describe a language. The Common File Format used to construct the Resource file follows specific production rules.
Release Directory		A directory structure used to store the DD and related files. Each manufacturer has a directory name that is the registered manufacturer ID number. There is a directory for each device type that a manufacturer produces under their ID directory.
Resource File		The part of the Capability file that is supplied by the manufacturer. It describes the communication profile, device capacity, internal record address assignments, and certain default values for a field device. A Capability file that has only this content is often called a Resource file.
Standard Dictionary		A Fieldbus Foundation file that contains standard strings and enumerations. A compressed form of the file is called the IMPORT.DCT and it is used by the Type function in Control Builder.
Symbol File	SYM	Contains symbolic names that were used in the DDL file for the FBAP of the device. It is produced by the Fieldbus Foundation Tokenizer.
System Management Kernel	SMK	
System Management Kernel Protocol	SMKP	
Virtual Communications Relationship	VCR	Sets up communications for host to talk to a device. It acts like a speed dialer to provide for the transfer of data between applications. FOUNDATION Fieldbus describes these three types of VCRs: <ul style="list-style-type: none"> • Publish/Subscribe • Client/Server • Source/Sink

Term	Abbreviation	Description
Virtual Field Device	VFD	The management or FBAP section of a device that is addressable by a VFD tag.

<https://maxautoland.com/>
manski@cambiala.cn +86 18030205725

24 Notices

Trademarks

Experion®, PlantScape®, SafeBrowse®, TotalPlant®, and TDC 3000® are registered trademarks of Honeywell International, Inc.

OneWireless™ is a trademark of Honeywell International, Inc.

Other trademarks

Microsoft and SQL Server are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.

Trademarks that appear in this document are used only to the benefit of the trademark owner, with no intention of trademark infringement.

Third-party licenses

This product may contain or be derived from materials, including software, of third parties. The third party materials may be subject to licenses, notices, restrictions and obligations imposed by the licensor. The licenses, notices, restrictions and obligations, if any, may be found in the materials accompanying the product, in the documents or files accompanying such third party materials, in a file named third_party_licenses on the media containing the product, or at <http://www.honeywell.com/ps/thirdpartylicenses>.

Documentation feedback

You can find the most up-to-date documents on the Honeywell Process Solutions support website at:

<http://www.honeywellprocess.com/support>

If you have comments about Honeywell Process Solutions documentation, send your feedback to:

hpsdocs@honeywell.com

Use this email address to provide feedback, or to report errors and omissions in the documentation. For immediate help with a technical problem, contact your local Honeywell Process Solutions Customer Contact Center (CCC) or Honeywell Technical Assistance Center (TAC).

How to report a security vulnerability

For the purpose of submission, a security vulnerability is defined as a software defect or weakness that can be exploited to reduce the operational or security capabilities of the software.

Honeywell investigates all reports of security vulnerabilities affecting Honeywell products and services.

To report a potential security vulnerability against any Honeywell product, please follow the instructions at:

<https://honeywell.com/pages/vulnerabilityreporting.aspx>

Submit the requested information to Honeywell using one of the following methods:

- Send an email to security@honeywell.com.

or

- Contact your local Honeywell Process Solutions Customer Contact Center (CCC) or Honeywell Technical Assistance Center (TAC) listed in the “Support” section of this document.

Support

For support, contact your local Honeywell Process Solutions Customer Contact Center (CCC). To find your local CCC visit the website, <https://www.honeywellprocess.com/en-US/contact-us/customer-support-contacts/Pages/default.aspx>.

Training classes

Honeywell holds technical training classes about Experion PKS. These classes are taught by experts in the field of process control systems. For more information about these classes, contact your Honeywell representative, or see <http://www.automationcollege.com>.

<https://maxautoland.com/>
manski@cambiala.cn +86 18030205725